

USER GUIDE

UF Transportation Institute UNIVERSITY of FLORIDA

Contents

Introducti	on	1
	License Agreement Acknowledgements Trademarks and Copyrights	1 4 4
	ntor 10	F
	pter 18	σ
	Limitations of the Methodology	5
HCM Chap	pter 19	5
	Limitations of the Methodology	5
HCM Chap	pter 23	6
	Limitations of the Methodology	6
Getting St	tarted	6
	System Requirements	6
	Getting Started	6
	Templates	6
General C	controls	7
	File	7
	View	8 8
	Windows	9
	Reports	9
	Shortcuts	10 10
Operation	al Data	11
-	General	
	Traffic	12
	Phasing and Timing	
	Detailed Input Data	13 14
	Interchange Ramp Terminals	14
	Alternative Intersections	14
	Signals/Streets Reports	14
Visual Mo	de	15
	Overview of Visual Mode	15
	Toolbar Icons in Visual Mode	17

Advanced Features

Quick Animation	
CORSIM	
Quick Optimization	
Full Optimization	
Time-Space Diagram	
Flow Profile Diagram	

Diverging Diamond Interchange (DDI)

Overview	
Interchanges and Alternative Intersections	
Coding Movements	
Diverging Diamond Data	
EDTT Data	
Signal Timing Inputs	
Output Reports	

Alternative Intersections

Modeling Capability in HCS	
Creating New Alternative Intersection Datasets	
Steps to Build an RCUT with Signals	
Steps to Build an MUT with Stop Signs	43
Steps to Build a Partial DLT	45

How To

Create a New File	
Open an Existing File	
Save a File	
Close a File	
Exit the Program	
Change the Mode	
Run Animation	
Run Optimization	
Import	
Export	
View Results of the Analysis	
Print a Report	

Glossary of Terms

Index

Introduction

License Agreement

HIGHWAY CAPACITY SOFTWARE™ (HCS2024™) AND TRANSYT-7F™

HCS2024[™] END USER LICENSE AGREEMENT

Copyright © 2023 University of Florida. All rights reserved.

This is an agreement between you and the University of Florida Board of Trustees for the benefit of the McTrans Center.

BY USING THE SOFTWARE PROGRAMS WITHIN THE ELECTRONIC TRANSMITTED PACKAGE OR DIRECT DOWNLOAD ("SOFTWARE"), YOU AGREE TO BE BOUND BY THE TERMS OF THIS LICENSE AGREEMENT. DO NOT USE THE SOFTWARE WITHOUT FIRST READING AND UNDERSTANDING THE TERMS OF THIS LICENSE AGREEMENT.

If you do not agree with the terms of this license, discontinue use, delete, and/or return the unused Software immediately to the distributor from which it was obtained.

1. LICENSE: In consideration of the required license fee, the University of Florida McTrans Center (hereinafter called "McTrans") hereby grants you (hereinafter called "End User") a nonexclusive license to use the enclosed HIGHWAY CAPACITY SOFTWARE (HCS2024) (hereinafter called "Software") as described in the applicable portion of section 3 for a period in which the End User pays the subscription fee established by McTrans.

2. OWNERSHIP: This license is not a sale of the Software; it is a license to use the Software under the terms of this License Agreement.

3. USE: The Software is licensed to End Users for a particular use, depending on the particular license that is designated on order and described in this Section.

a. Single Office License. The End User may use the Software on any number of computers within the End User's immediate office, defined as a single organizational unit with a unique function, comprising one or more contiguous rooms in a single location. All persons using the Software are also End Users. End Users may also use the Software on portable computers, such as laptops, while on official travel and on home computers, AS LONG AS ALL SUCH USE IS ON BEHALF OF THE OFFICE FOR WHICH THIS SOFTWARE LICENSE WAS PURCHASED. This Software License does not authorize the use of the Software at any offices related to that single organizational unit but not located at the same geographic

location, even if the Software is stored on a portable computer. If you have any questions as to the validity of your End User License, contact McTrans. The End User may use the Software directly on the computer that has been installed. The end User may not use the Software remotely via any technology, such as a remote desktop (see section 4). The End User should consult with section 13 of this EULA on other restrictions for the Software's use.

b. Academic License. The End User may use the Software only within a laboratory within the End User's immediate school, which is defined as a single school unit having a unique function, comprising one or more contiguous rooms in a single location, up to the permitted (purchased) number of copies, provided the use is supervised in a classroom setting for teaching or research purposes, and appropriate protection is in place against students copying the Software and taking it out of the lab. The responsibility for ensuring this protection of the Software rests with the End User. Multiple laboratories require multiple licenses. The Software may not be installed or used on any computer outside of the licensed laboratory under the Academic License, including (but not limited to) any office, home, networked, or portable computer. If you have any questions as to the type or validity of your End User License, contact McTrans. The End User may use the Software directly on the computer that has been installed. The End User may not use the Software remotely via any technology, such as a remote desktop (see also section 4). The End User should consult with section 13 of this EULA on other restrictions for the Software's use.

c. Single Computer License. The End User may use the Software on a single computer, a desktop, a PC, or a portable laptop. All persons using the Software are also End Users. The End User may use the Software anywhere, such as a business office, home office, travel, etc. The End User should consult with section 13 of this EULA on other restrictions for the Software's use. End User is only allowed to use the Software directly on the computer that has been installed. End User may not use the Software remotely via any technology (see also Section 4), such as remote desktop.

WARNING! If this license is a Single Office or Single Computer License for use in traffic and transportation applications, the Software may not be used for classroom or workshop instruction without the express, written consent of McTrans. (Contact McTrans for an Academic License.) If this license is an Academic License for use in training or educational applications, the Software may not be used for traffic and transportation applications or other similar purposes without the express, written consent of McTrans. (Contact McTrans for an Academic License for use in training or educational applications, the Software may not be used for traffic and transportation applications or other similar purposes without the express, written consent of McTrans. (Contact McTrans for an Applications License.)

4. VIRTUALIZATION AND REMOTE ACCESS: The End User may not use this Software in a virtualized environment. All installations under any available license types discussed in section 3 should be performed on a physical computer such as a desktop, PC, or laptop. The End User may use the Software directly on the computer that has been installed. End User may not use the Software remotely via any technology, such as remote desktop.

VIRTUALIZATION FOR VIRTUAL CLASSROOMS: Under academic license, the End User may ask permission to utilize a virtual environment to install and use the Software only with written consent from McTrans.

5. NETWORK USE: No network use is permitted, including but not limited to using the Software either directly or through commands, data, or instructions from or to a computer not already licensed and part of the internal network for Internet or web hosting services or by any user not licensed to use this copy of the Software through a valid license from McTrans. The Software is not designed for network use, and such use is not supported. McTrans is not able to provide technical support for issues resulting from network incompatibilities.

6. COPY RESTRICTIONS: Unauthorized copying, distribution, or dissemination of the Software is expressly prohibited. End User may be held legally responsible for any copyright infringement that is caused, encouraged, or enabled by failure to abide by the terms of this license. Subject to these restrictions, the End User may make copies of the Software for backup purposes and for use of the Software on any computers located within its office complex, as described in paragraph 3. Under no circumstances may the Software or associated printed documentation be copied for sale, distribution, or

dissemination, except as provided in paragraph 3, without the express, written consent of McTrans. End User may reproduce the associated documentation as necessary to use within the geographic location for which the license is granted. End User may not modify, adapt, translate, reverse engineer, decompile, disassemble, or create derivative work from the Software or any associated written materials without the prior written consent of McTrans. ANY SUCH ACTIVITY OR PRODUCT BECOMES THE PROPERTY OF McTRANS.

7. TRANSFER RESTRICTIONS: The Software is licensed only to the End User, and this License Agreement may not be assigned or transferred to anyone without the prior written consent of McTrans. Any authorized transferee of this License Agreement shall be bound by the terms of this License Agreement. End User may not transfer, assign, rent, lease, sell, or otherwise dispose of the Software except as expressly provided in this License Agreement.

8. REGISTRATION AND SUPPORT: This license is automatically registered to the person or entity that purchased it. If the End User wishes to change the registration, he or she must provide in writing the registration information. McTrans may, from time to time, revise or update the Software to correct bugs or add minor improvements. McTrans will supply, at its discretion, minor updates to the End User without additional charge and will provide reasonable telephone or email support to the End User during the normal business hours of McTrans for the period for which the End User pays the subscription fee established by McTrans. McTrans reserves the right to determine the extent of the support. McTrans reserves the right to make substantial revisions and enhancements to the Software and to market such substantially revised versions as separate products. End User shall not be entitled to receive such separate products without additional charge. Upon release of any such revised version of the Software, the obligation to provide the above-described technical support services to the End User shall cease unless the End User chooses to pay to license the enhanced version of the Software, whether or not the End User has previously requested or received support on the prior version.

9. LIMITED WARRANTY AND LIMITATIONS OF REMEDIES: End User agrees that it is the responsibility of End User to understand fully the limitations of and assumptions underlying the Software and not to make use of the Software without the assistance of personnel with appropriate expertise. The End User accepts all responsibility for the program output's review, interpretation, application, and use and accepts all responsibility for ensuring that the output meets any applicable design code, standard, or project specification provisions.

Except as provided above, the product is provided "AS IS" without warranty of any kind, either expressed or implied, including, but not limited to, implied warranties of merchantability and fitness for a particular purpose. McTrans does not warrant that the functions contained in the Software will meet the End User's requirements or that the operation of the Software will be uninterrupted or error-free. The entire risk as to the quality and performance of the product is with the End User. In no event will McTrans be liable to the End User for any damages, including any lost profits, lost savings, or other incidental or consequential damages arising out of the use of or inability to use the Software, even if McTrans has been advised of the possibility of such damages, or for any claim by any other party. The above warranty gives the End User specific legal rights, and the End User may also have other rights in the United States, which vary from state to state. Use of the Software where the End User believes or has reason to believe that damage may occur is a violation of any and all warranties. McTrans has no knowledge of the hardware or Software configurations of the End User and assumes no liability for their damage.

10. TERMINATION: This license is effective from the date the End User receives the Software until this License Agreement is terminated. End User may terminate it by returning or destroying all copies of the Software and associated documentation in End User's possession or control. If the End User breaches any terms of this license, the license shall terminate immediately.

11. GOVERNING LAW: This License Agreement shall be governed by the laws of the State of Florida, U.S.A. Venue for all disputes related to this License Agreement shall be in the United States District Court of the Northern District of Florida, Gainesville Division, or in the Circuit Court of the Eighth Judicial Circuit for Alachua County, Florida.

12. U.S. GOVERNMENT RESTRICTED RIGHTS: The Software and associated documentation are provided with RESTRICTED RIGHTS. Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subdivision (c)(1)(ii) of The Rights in Technical Data and Computer Software clause at 52.227-7013 or subparagraphs (c)(1) and (2) of the Commercial Computer Software - Restricted Rights at 48CFR52.227-19. The contractor is McTrans, University of Florida, PO Box 116585, Gainesville, FL 32611-6585.

13. EXPORT REGULATION: The Software may be subject to U.S. export control laws, including the U.S. Export Control Reform Act and its associated regulations. End User will not directly or indirectly export, re-export, or release the Software to, or make the Software accessible from, any country, jurisdiction, or person to which export, re-export, or release is prohibited by applicable law. End User will comply with all applicable laws and complete all required undertakings (including obtaining any necessary export license or other governmental approval) prior to exporting, re-exporting, releasing, or otherwise making the Software available outside the U.S.

14. INTEGRATION: This License Agreement is the complete and exclusive statement of the agreement between End User and McTrans and supersedes any proposal or prior agreement, oral or written, and any other communications between End User and McTrans relating to the subject matter of this License Agreement. This License Agreement may only be modified by a written agreement made subsequent to the date hereof and signed by both parties.

15. SEVERABILITY: If any portion of this License Agreement shall be declared void or a nullity by a court of competent jurisdiction, then the remainder shall survive and remain in full force. Should you have any questions concerning this license, you may contact the McTrans Center, University of Florida, PO Box 116585, Gainesville, FL 32611-6585, U.S.A., [1] (800) 226-1013.

Acknowledgements

McTrans Center, University of Florida Transportation Institute PO Box 116585, Gainesville FL 32611-6585 Telephone: 1-800-226-1013 Fax: 352-392-6629 Web: mctrans.ce.ufl.edu Email: mctrans@ce.ufl.edu

We acknowledge the Transportation Research Board (TRB), the USDOT's Federal Highway Administration (FHWA), the American Traffic Safety Services Association (ATSSA), the Institute of Transportation Engineers (ITE), and the American Association of State Highway and Transportation Officials (AASHTO) for all text, figures, and references included in HCS and express our sincere appreciation for permission to include this information.

Trademarks and Copyrights

- Microsoft(R), MS-DOS(R), and Windows(TM) are registered trademarks of Microsoft Corporation.
- McTrans(TM), HCS(TM), HSS(TM), TSIS-CORSIM(TM), and TRANSYT-7F(TM) are registered trademarks of the University of Florida.
- HCS, HCS2024, HCS2023, HCS2022, HCS7, HCS 2010, HCS+, HSS, HSS2024, TRANSYT-7F, and T7F are copyright University of Florida.
- TSIS-CORSIM, TSIS-CORSIM2024, TSIS-CORSIM2023, TSIS-CORSIM2022, TSIS, CORSIM, NETSIM, FRESIM, TRAFED, TRAFVU, and TShell are copyright University of Florida, with portions copyright ITT Industries, Inc., Systems Division.

HCM Chapter 18

The computational procedure in this chapter can be used to estimate the capacity and level of service (LOS) of urban street segments. The analysis considers a wide variety of conditions including but not limited to, the amount and distribution of traffic movements, traffic composition, geometric considerations, and details of movement phases and timing. Urban Street LOS is estimated as a function of arterial travel speed and arterial volume-to-capacity ratio. Signalized intersection operations are modeled largely on the basis of the HCM Chapter 19 procedures, albeit with key adjustments for signal coordination and platooned vehicle arrivals.

Limitations of the Methodology

The HCM Chapter 18 procedure does not directly account for mid-block parking activity, mid-block significant grade, mid-block capacity constraints, queue spillback between intersections, and turn bay queue spillover. The HCM Chapter 18 procedure is also affected by the same limitations contained within the HCM Chapter 19 procedure.

HCM Chapter 19

The procedure in this chapter can be used to analyze the capacity and level of service (LOS) of signalized intersections. The analysis considers a wide variety of conditions including, but not limited to, the amount and distribution of traffic movements, traffic composition, geometric considerations, and details of movement phases and timing. The primary focus is the determination of approach and intersection delay as well as the corresponding LOS. Signalized intersections, as addressed by HCM, are consistent with Urban Streets.

Limitations of the Methodology

This chapter does not account for turn-bay overflow and queue spillback. A queue storage ratio is calculated, but does not provide any adjustments to the capacity of the adjacent through lane. Free right

turns for movements not under signal control are not modeled by this method. Right turn on red (RTOR) volumes are subtracted from the total right-turn flow since they are not processed during the green. The procedure does not allow for gap reduction or rest-in-walk for actuated signals.

HCM Chapter 23

The computational procedure in this chapter can be used to estimate the capacity and level of service (LOS) of interchange ramp terminals and alternative intersections. The analysis considers a wide variety of conditions including but not limited to, the amount and distribution of traffic movements, traffic composition, geometric considerations, and details of movement phases and timing. Interchange Ramp Terminal LOS is estimated as combination of delays for a series of origin-destination movement pairs and the volume-to-capacity ratio and queue-storage ratio for each movement. Alternative Intersection LOS is dictated by the experienced travel time (ETT) for each origin-destination movement and the volume-to-capacity ratio and queue-storage ratio for each movement. Signalized intersection operations are modeled largely on the basis of the HCM Chapter 19 procedures, albeit with key adjustments for signal coordination and platooned vehicle arrivals.

Limitations of the Methodology

This chapter does not account for turn-bay overflow and queue spillback. A queue storage ratio is calculated, but does not provide any adjustments to the capacity of the adjacent through lane. Right turn on red (RTOR) volumes are subtracted from the total right-turn flow since they are not processed during the green. HCS does not allow for gap reduction or rest-in-walk for actuated signals.

Getting Started

System Requirements

HCS is designed for standard Windows installations. For optimal performance, the system should be Windows 10 or newer. While HCS may be compatible with older versions of Windows, any installation

and operational issues arising from using these older versions will be the sole responsibility of the end user.

Getting Started

To begin, click on File then New (or the "New File" icon). You will be presented with a dialog box to input the basic phase timing and base values for the intersection. (NOTE: It is important to set the Forward Direction as the direction for your project. The software does not allow for the user to change this information once the program starts.) Once these choices are made, click on "OK" to continue the input data process.

Normal Windows keyboard and mouse functions are available. Arrow keys now navigate through the data fields. Tabbing, clicking to a new field, or pressing the Enter key will trigger a recalculation and update the Report pane.

Templates

The Signals and Streets modules of HCS provide the ability to import and export input data "templates", to define intersections more efficiently. The Template feature allows important subsections of input data (lane configurations, phasing sequences, signal timings) to be automatically imported, or transferred between intersections, or transferred between datasets. If the desired data cannot be found within the existing templates, users can create and customize their own templates. When creating a brand-new dataset it is also possible to select a template on the Quick Start screen.

Importing a Template - Templates can be imported by selecting File > Import > Template and then choosing from a list of available templates. A short description is provided for each template. If a user has already created and exported a template, it can be found under the All Templates option and the specific category option within which it was created. For example if a template was exported as a Detailed Input template, it can be found under the All Templates option) from the Import Template dialog.

Exporting a Template - Users can create and customize their own templates by selecting File > Export > Template. The subsequent menu will allow the user to specify a template file name, provide a short description, and then save the template into the appropriate folder. Once a template has been saved it can then be imported in the future as needed.

General Controls

File

New – Creates a new Streets file (*.xus) and starts a new analysis project.

Open – Opens an existing HCS Streets file (*.xus), HCS2010 Signals file (*.xhs), or DAITA file (*.xhd). **Example Folder** – Opens folder with all HCS examples in File Explorer

Recent Files - Allows quick access to files that have recently been created or altered.

Close – Closes an existing Streets file (*.xus).

Save – Saves an opened Streets file (*.xus) using the current file name.

Save As – Saves an opened Streets file (*.xus) using a specified file name.

Print – Prints a Signals/Streets report to the printer or specified electronic file.

Print Preview – Displays preview of current report before printing.

Import

Streets CSV File – Imports data from a Streets CSV file. QuickStreets CSV File – Imports data from a QuickStreets file. Synchro-To-Streets Converter – Imports data from a Synchro CSV file. Streets Data Template – Imports data from an existing template file. DAITA File – Imports data from a DAITA file.

CSV Import Wizard – Opens import wizard for importing data from a Streets CSV file. **Export** - Exports data in template form.

Streets CSV File – Exports data in a CSV file.

Streets Data Template – Exports data in template form.

CORSIM

View Animation – Sends data to the TSIS-CORSIM program for simulation and/or animation purposes; TRAFVU can be opened within TSIS-CORSIM to allow user to view animation

Generate TRF File – Saves an open Streets file (*.xus) as a CORSIM file (*trf), which is a file that contains the input data used to define a CORSIM network and to drive the CORSIM simulation for a single simulation case

Generate Input and Output Files – Saves an open Streets file (*.xus) as a CORSIM file (*trf), which is a file that contains the input data used to define a CORSIM network and to drive the CORSIM simulation for a single simulation case

Exit – Exits Streets.

View

Toolbar – Toggles shortcuts from file menu near the top of the program.

Status Bar – Provides additional information about the active input data field.

Startup Screen – Opens the startup screen that initially showed when opening Streets

Reports – Allows user to switch view of reports to either below or to the right of the input screen.

Classic / Visual Mode - Toggles between Classic Mode and Visual Mode.

Primary Data – Expands/collapses the screen to include/hide the primary data screen.

Detailed Data – Expands/collapses the screen to include/hide the detailed input data screen.

Interchange Data – Expands/collapses the screen to include/hide the detailed input data screen which includes interchange inputs

Multimodal Data - Expands/collapses the screen to include/hide the multimodal input data screen.

Quick Lanes – Toggles enlarged lanes input screen.

Quick Phases – Toggles enlarged phases input screen.

Reports Panel – Toggles view of the report panel.

Information – Toggles view of information (error and warning messages) regarding the current file.

Auto-Calculate – Activates auto-calculate mode for whenever input values are changed. Auto-calculate mode can sometimes slow down the program when there are multiple intersections and/or time periods.

Force Calculations – Forces a calculation whenever the user needs to refresh output data. Force Calculations is only applicable when Auto-Calculate mode is turned off.

Quick Animation – Exports data to TSIS-CORSIM for animation purposes.

Quick Optimization – Exports data to TRANSYT-7F to provide optimization of the urban street.

Full Optimization – Internally performs HCM-based genetic algorithm optimization for the urban street.

Time-Space Diagram – Provides a time-space diagram of the urban street.

Flow Profile Diagram – Provides flow profile diagrams for the urban street.

Edit

Undo – Reverse previous editing operation.

Redo – Revert to previous editing operation.

Cut – Deletes data and moves it to clipboard.

Paste – Places data from clipboard into the input panes.

Settings – Provides preferences for exporting data and appearance of data in the reports. Also provides defaults for Analyst, Agency/Co, Time Period, Jurisdiction, and units.

Windows

New Window – Opens a new window for a new intersection.

Cascade - Places the current files into smaller windows to allow a better view to multiple files.

Tile Vertical – Files appear in column form for side-by-side analysis.

Tile Horizontal – Files appear in row form for side-by-side analysis.

Close All - Closes all windows, but leaves the HCS program open.

Reports

Signals/Streets Text Report – The text report contains mostly unformatted text outputs, although zoom magnification is available. The text report also contains a small number of outputs that are not available in the formatted reports.

Input Report – The input report, which is formatted to display enhanced fonts and graphics, provides an echo of the input data.

Results Report – The results report, which is formatted to display enhanced fonts and graphics, provides a summary of the most important output measures of effectiveness from the Chapter 19 procedure.

Intermediate Report – The intermediate report, which is formatted to display enhanced fonts and graphics, provides additional outputs that are not available in the results report. Many of these outputs are called "intermediate" because they are computed prior to the final results, and because they are used to influence the final results.

Graphical Summary – The graphical summary, which is formatted to display enhanced fonts and graphics, provides a visual representation of the intersection delay, queue, and LOS.

Messages Report – The messages report contains warning messages and/or error messages, which are automatically generated by HCS upon analyzing the input/output data. These warning and error messages can also be viewed in a dialog screen by clicking on the "Information" toolbar icon. The messages report may also contain any user "comments" entered inside the Information screen.

Full Report – The full report is a combination of the input, results, intermediate, and messages reports.

Safety and Emissions Report – The safety and emissions report, which is formatted to display enhanced fonts and graphics, provide a summary of the most important output measures related to safety and emissions.

Segment Report – The segment report, which is formatted to display enhanced fonts and graphics, provides a summary of the most important output measures of effectiveness from the Chapter 18 procedure.

Access Point Report – This report provides information on each access point with lanes, volumes, balanced flow, proportion time blocked (for use in TWSC), and thru vehicle delay estimates.

Street Heatmap – The street heatmap, which is formatted to display enhanced fonts and graphics, provides a visual representation of the % of BFFS and LOS of the urban street.

Flow Profile Data – This report provides a text printout of flow profile values for each intersection and each segment.

Interchanges Results – The Interchanges report details demand, delay and LOS by origin-destination pairs, as well as providing input and results summaries for each signalized intersection.

Alternative Intersections Report – The alternative intersections report details flow rate, control delay, EDTT, ETT, and LOS by origin-destination, as well as providing input and results summaries for each intersection.

Phasing and Time Summary – The phasing and timing summary, which is formatted to display enhanced fonts and graphics, provides a summary of the phasing and timing of each intersection within the dataset.

Intersection Summary – The intersection summary, which is formatted to display enhanced fonts and graphics, provides a summary of each intersection within the dataset.

None - Blanks out the report pane, and sometimes allows for faster program operation.

Help

Contents – Provides access to a glossary, acknowledgements, copyrights, information on Visual Mode, and information on the Chapter 18/19 procedures.

Index/Search – Allows user to search for key terms or phrases within the contents.

User Guide - Provides a comprehensive user guide in PDF format.

HCM Reference Guide – Opens a reference guide for the HCM in PDF format.

HCS Updates – Sends the HCS version number anonymously without any personally identifiable information to McTrans to check for a newer version.

HCM/HCS Training – Opens the McTrans Training Page in the default web browser to view the latest training opportunities.

HCQS Web page – Opens the TRB Highway Capacity and Quality of Service Committee website in the default web browser.

Support – Provides user access to any FAQs, as well as McTrans contact information for any issues or concerns.

About HCS – Opens an about window with software version information, EULA, general acknowledgements, contact information, and other relevant links.

Toolbar Icons

New – Creates a new Streets file (*.xus) and starts a new analysis project.

Open – Opens an existing HCS Streets file (*.xus), HCS2010 Signals file (*.xhs), or DAITA file (*.xhd).

Save – Saves an opened Streets file (*.xus) using the current file name.

Print – Prints a Signals/Streets report to the printer or specified electronic file.

Quick Animation – Exports data to TSIS-CORSIM for animation purposes.

Quick Optimization – Exports data to TRANSYT-7F to provide optimization of the urban street.

Full Optimization – Internally performs HCM-based genetic algorithm optimization for the urban street.

Time-Space Diagram – Provides a time-space diagram of the urban street.

Flow Profile Diagram – Provides flow profile diagrams for the urban street.

Auto-Calculate – Activates auto-calculate mode for whenever input values are changed. Auto-calculate mode can sometimes slow down the program when there are multiple intersections and/or time periods.

Force Calculations – Forces a calculation whenever the user needs to refresh output data. Force Calculations is only applicable when Auto-Calculate mode is turned off.

Information – Toggles view of information (error and warning messages) regarding the current file.

Shortcuts

- Ctrl N = create a new file
- Ctrl O = open an existing file
- Ctrl S = save data to file
- Ctrl P = print report
- **Ctrl I** = pop up the "information" dialog
- **Ctrl F1** = view the "help contents"

F5 = toggle between Classic Mode and Visual Mode

F6 = collapse/expand the "detailed input data" section

- **F7** = collapse/expand the "multimodal input data" section
- **F8** = pop up the "quick lanes" dialog
- **F9** = pop up the "quick phases" dialog
- F11 = toggle the "reports panel"
- **Ctrl Shift A** = toggle the "auto-calculate" mode
- Ctrl Shift R = force calculations (if auto-calculate is turned off)
- Ctrl Shift L = launch "quick animation"
- Ctrl Shift O = launch "quick optimization" via one-touch export to TRANSYT-7F
- Ctrl Shift F = launch "full optimization" via HCM-based internal genetic algorithm
- Ctrl Shift T = view the time-space diagram
- Ctrl Shift P = view the flow profile diagrams

Operational Data

General

The user will first enter the General Information into the respective fields: Urban Street, Intersection and Project Description. The user may change the forward direction of the major street as well as the area type. The forward direction is important for relating the intersection to other intersections and upstream filtering when dealing with arterials or urban streets. The Area Type is defined as being in a "CBD or Similar" environment or not. Choosing this option will affect the Area Type Adjustment Factor for the saturation flow rate. The user may also enter the duration of the study and the peak hour factor (PHF). The duration is coded as the analysis period, which is normally 15 minutes (T=0.25 hours) to represent the length of time the peak flow is constant. The PHF is coded to change the volumes into flow rates, generally for planning applications. For operational applications, demands are coded in vehicles per period for a multiple-period analysis without use of the PHF.

The input data screen and report screen are placed concurrently in the window. The user has the ability to place the report screen below or to the right of the input data screen.

Note: The Status Bar at the bottom of the screen will identify the current field, the possible range or choices to input into the field, and default values that the software provides for a new file.

The Quick Lanes control can be used for graphical coding of lane configuration data. Text input fields for number of lanes and shared lanes are also available under Detailed Input Data, if non-graphical coding of lane configuration data is needed. On the Quick Lanes control, lane combinations can be selected by clicking on the appropriate arrows to place them on the diagram for each approach. The geometry of each approach is described by coding the number of lanes and the movements allowed in each lane, including whether movements are exclusive or shared. This data is coordinated with the normal data entry screen, so changes in either view are reflected in the other. The Clear button can be used to delete all existing lanes if needed.

Traffic

Demand is coded for each movement of the intersection. Arrival demand in vehicles per period is required for any movement to be included in the analysis. If actual demand data are not collected for congested conditions, the rate cannot exceed capacity (by definition) and the analysis can significantly underestimate delay and queue.

Note: Counting vehicles as they cross the stop line is not adequate for collecting data to analyze congested conditions. If demand approaches or exceeds capacity, arrival rate must be known to use demand in this methodology by collecting arrival data upstream of all queues associated with the approach, then reconciling the approach rate to each movement at the stop line.

Multiple-Period Analysis is necessary to analyze congested conditions and properly model the operation for reasonable delay, queue and level of service results. Otherwise, the initial queue (d3) delay that builds and dissipates over the peak period is not considered in these computations. This analysis must begin and end with undersaturated periods to capture the complete oversaturated process.

Note: If a user wishes to analyze additional time periods, they may add periods at the top of the screen. Adding a period will allow a user to change demand related data, but intersection geometry and phasing data will remain constant through all periods.

Lane Width is entered as an average width for all the lanes in the lane group.

Storage Length can be coded into the software and will have a direct effect on the Queue Storage Ratio (QSR). Users must take caution with the QSR. If the QSR exceeds 1.0, HCS will not identify that there will be spillovers into other lanes and cause unforeseen delays. If possible, any QSR above 1.0 should be alleviated prior to finalizing the analysis. If not possible, simulation is recommended.

Base Saturation Flow Rate is available by lane group, but one value for all lane groups is typical. In fact, this is normally a jurisdiction-wide parameter that should be calibrated for each local area. It is adjusted to account for different factors and prevailing conditions.

Note: Calibration from field data is detailed in HCM Chapter 31 and involves measuring the prevailing saturation flow rate for at least 15 cycles including a minimum of 8 vehicles in queue per cycle, excluding the first five vehicles (to account for start-up lost time) and permitted left turn lane groups (because of the complexity involved). The prevailing rate is compared with the computed rate to generate a proportion to apply to the base saturation flow rate to be used for any analyses performed within the jurisdiction. The HCM suggests this calibration be performed only every few years or when there is evidence of a change in driver behavior. Calibration of base saturation flow rate for local conditions is critical for accurate results within this procedure, since these rates can vary dramatically by jurisdiction. For example, larger cities typically have base rates well over 2000, while smaller towns can be well under 1600 – and this significantly changes the basis for capacity, ultimately used to compute delay and level of service.

Percent Heavy Vehicles is coded to adjust the saturation flow rate for the effects of heavy vehicles in the traffic stream. Heavy vehicles occupy more space and have different operating capabilities with respect to passenger cars. The Heavy Vehicle Factor typically assumes 2.0 passenger cars per heavy vehicle, but this can be modified under Detailed Input Data.

Percent Grade is entered for each approach to determine the Grade Adjustment Factor for saturation flow adjustment to account for the effects of grade on all vehicles.

Buses

Parking

Bicycles

Pedestrians

Arrival Type is used to describe the quality of traffic progression as it approaches the intersection in question. The arrival type ranges between 1 and 6 with 1 being poor progression, 2 being unfavorable progression, 3 being random arrivals, 4 being favorable progression, and 6 being exceptional progression. These values and descriptions can be found in Chapter 19 of the HCM.

Upstream Filtering (I) allows the user to select an upstream Signals data file for calculating the I-factor, for each approach with a signalized intersection within 0.6 miles.

If there is an Initial Queue (unmet demand from the previous period), this value is coded by lane group in units of total vehicles. This value will have a direct effect on the value of d_3 in the intersection delay calculations.

Speed Limit

Detector Length

RTOR

Phasing and Timing

The signal phasing sequence is specified by clicking on the dual-ring phasing diagram (phases 1 through 8), also known as "Quick Phases". Only the left-turn phasing needs to be specified, because thru movements and right-turn movements are automatically added to the phasing sequence as a function of laneage. The dual-ring phasing diagram contains logic to prevent invalid phasing sequences from being entered, given the available laneage. Left-turn movements in odd-numbered phases are used to reflect protected left-turns (i.e., "green arrow"), whereas left-turn movements in even-numbered phases are used to reflect permitted left-turns (i.e., "green ball" or "flashing yellow arrow"). When exclusive right-turn lanes exist, shielded right-turns may be added by clicking twice on the corresponding odd-numbered phase. Green, yellow, and all-red clearance times may be entered in the group box labeled "Timing". After the signal phasing and timing are entered a sequential phasing diagram (labeled "Phase Duration") will display the phase durations as computed by the HCM procedure in an equivalent "single-ring" format.

Note: Phase Durations are average times calculated for the fifteen-minute analysis period and may not represent times for any one cycle. For phases with very low demand, the average green may be lower than the minimum specified because some cycles would serve the minimum and some cycles would skip the phase. And, if the average is equal to the clearance time, the green may be displayed as zero. This is necessary to both show the averages and have them sum to the cycle length.

Each distinct phase time is defined by coding the Phase Split (if coordinated), Maximum Green (if uncoordinated), Yellow Change, Red Clearance and Minimum Green times. Users may also code passage time and mark any movement for having a lag phase, dual entry, simultaneous gap out, or Dallas Phasing. For coordinated intersections the software will automatically update non-actuated phase splits, to reflect the cycle length and the actuated phase splits.

The software also allows users to input field-measured phase times to be used directly if the actual values are known, eliminating the phase duration estimation procedure. If an intersection is labeled as coordinated, the cycle length and offset time become available options to coincide with the corresponding intersections. The timing lists an overall Phase Split which will change to keep the cycle length consistent for all movements. For coordinated intersections, the non-actuated phases (typically 2+6) will be computed from the sum of the actuated phase times honoring the specified cycle length. Uncoordinated intersections will not have the option of a cycle length or offset since the timing only affects the intersection in question. The phase split now becomes a Maximum Green and each phase is independent, so the user has the ability to change each movement.

Detailed Input Data

The user may input detailed information about the project including the Analyst, Agency or Company, Date, Time Period, Year and Jurisdiction of the Project. Many values within the Detailed Input Data screen are set values from the HCM, but the user has the ability to change any of them for local calibration.

Global Optimization contains an array of inputs for signal timing design, if desired. These inputs may affect Quick Optimization (via one-touch export to TRANSYT-7F) and/or Full Optimization (via HCM-based internal genetic algorithm).

Multimodal Input Data

If an intersection contains data for pedestrians and/or bicycles, the user can enter Signals multimodal data to determine a level of service score and corresponding LOS. Similar to vehicle data, the user may input multimodal volumes and geometry for the intersection in question. By entering this data, the user can obtain multimodal outputs and level of service in the reports section of the software. If an urban street contains segment-based data for pedestrians, bicycles, or transit, the user may enter Streets multimodal data to determine a segment-based multimodal LOS. For "operations only" analyses, checkboxes ("Hide Results") are available to hide multimodal outputs on the Results Report and the Intermediate Report.

Interchange Ramp Terminals

Beyond coding the signalized intersection(s), the user codes information specific to an interchange by defining the Interchange Type, Interchange U-Turn Volume and Turn Radius for (normally) two intersections selected as Interchange Intersections.

Alternative Intersections

To model an alternative intersection, the user first codes the inputs for a conventional intersection and then specifies the desired type of alternative intersection (e.g., MUT with TWSC, RCUT, DLT). This will convert the file to the specified alternative intersection, allow for additional inputs relevant to any supplemental junctions, and generate an alternative intersection report. *Note: Some alternative intersections such as MUT and RCUT require additional files to be attached before full results can be generated*.

Signals/Streets Reports

The lower pane (or right pane depending on user preference) displays the analysis outputs in a dynamic form, reacting to changes in the upper (or left) Entry pane. The Report portion of the screen can be viewed simultaneously with the Entry pane. All or a portion of the report can be copied to the Windows clipboard for insertion into other files by right-clicking into the Report pane, selecting all, and copying. The Report pane can also be printed or saved to an electronic file through File > Print.

For signalized intersection analysis the user will have the option of viewing reports for Input Data, Results Summary, Intermediate Values, Messages and Comments, or a combination of all four reports. These formatted reports contain enhanced fonts and graphics, but a text option is also available. The text report contains mostly unformatted text outputs, although zoom magnification is available. The text report also contains a small number of outputs that are not available in the formatted reports. If results (e.g., Delay and Level of Service) do not appear on the Results Summary report, the user can review the Messages Report (or Information button) for possible errors within the input data.

For urban street analysis, the user can choose between a segment-based formatted report, and a segment-based text report. These reports also contain access point input and output data, if any access points exist. As with the signalized intersection reports, the segment text report also contains a small number of outputs that are not available in the formatted reports.

Users who wish to print any report should ensure that this report is displayed in the report pane of the software. Accessing the print option under the File menu will present the traditional printing options. A preview of all pages to be printed is recommended. Changing the margins of the report will allow more information to fit on fewer pages, as opposed to having very little information appear on an extra page.

It is also possible to view the reports in XPS format. This format provides an image to be seen by using a XPS Viewer or an Internet Browser such as Internet Explorer. Mozilla Firefox is not compatible with showing XPS files. This procedure can be done by selecting File > Print and choosing "Microsoft XPS Document Writer." This will allow a user to save the file in (*.xps format) and can later be viewed by the recommended web browsers.

Visual Mode

Overview of Visual Mode

A map rendering screen ("Visual Mode") is available for displaying urban street geometry, and editing urban street input data. Visual Mode may allow the user to better understand the data entry process, and may assist in explaining the model to unfamiliar parties. In addition, the ability to display input and output data on the map can be useful for verification and validation of the model. User-supplied bitmap background images can be helpful for understanding the real-world signal system represented by the link-node diagram, and can be helpful when dragging and dropping intersections to their appropriate locations.

When an Urban Streets (*.xus) input file is open, a tab for switching to Visual Mode is located next to the Classic Mode tab, near the upper left-hand corner of the program screen. Pressing the F5 key will also toggle between Visual Mode and Classic Mode. Visual Mode currently offers the following features:

- Adding curvature
- Adding a new access point
- Showing or hiding the grid
- Easy bitmap background scaling
- Map colors and layout properties
- Zoom in, zoom out, pan, show all
- Align intersections vertically or horizontally
- Graphical adding and deleting of intersections
- Select and move entire groups of intersections
- Ability to underlay user-supplied bitmap backgrounds and aerial photos
- Right-click or double-click on intersections to edit their properties (tabular view)
- View intersection delay and LOS by moving the mouse pointer over an intersection
- Copy-and-paste intersections, to avoid re-coding lane configuration, volumes, and timings
- View option for showing Intersection Name, Intersection LOS, Intersection Delay, Segment Length, Segment Name, Speed Limit, Access points and Access Point Name

An example of Visual Mode is illustrated below.



The default segment length is typically 1000 feet for brand-new data files. The first time Visual Mode is selected, intersections will be placed at 1000-foot increments, unless the user has already modified segment lengths within Classic Mode. Intersections will be oriented according to the Urban Street Forward Direction.

There are two methods (manual and graphical) for entering segment lengths. If segment lengths are entered manually, intersections will continue to be positioned in a straight line, consistent with the Urban Street Forward Direction. In Classic Mode, segment lengths can be entered manually after clicking on the "All Segment Lengths" button. The Segment Lengths dialog for manual specification of segment lengths is shown below.

Segment Lengths	
Segment Number	Length, ft
1-2	1000
2-3	1000
3-4	1000
OK	Cancel

Segment lengths are adjusted graphically whenever the user 1) drags and drops intersections into different positions, or 2) the user right-clicks on intersections to enter specific node coordinates, or 3) adds curvature to a segment. In this case, segment lengths will be automatically re-calculated by Visual Mode as a function of node coordinates, and any segment curvature that might exist. Segment lengths can be changed graphically at all times, but they can only be entered manually when intersections are positioned in a straight line with no curvature. The Segment Lengths dialog for manual specification of segment lengths will be disabled if curvature exists, or if intersections are not positioned in a straight line.

Link connections (a.k.a. segments) between intersections automatically appear whenever intersections are added. Intersection details can be specified by right-clicking and selecting the "Edit" option, or by switching back to Classic Mode.

When Visual Mode is initially opened, the Pointer icon is activated on the toolbar toward the top of the screen. When the Pointer icon is activated, the user can select individual intersections (or groups of intersections), drag-and-drop intersections, and right-click on intersections to edit their properties. Other toolbar icons may be used to superimpose input/output information on the map, add or delete intersections, add or delete curvature, or change the view (zoom in, zoom out, show all). Certain toolbar icons will cause the mouse cursor to change shape, to indicate a different mode of operation. For example, if the "Zoom In" icon is selected, the mouse cursor takes the shape of a magnifying glass. To return to the default Pointer mode at any point during the session, the user can either right-click on the general map area, or click back on the Pointer icon.

The Pointer icon can be used to draw a "rubber band" around groups of intersections. To do this, left-click on the general map area, hold the mouse button down without releasing, drag the rubber band around a group of intersections, and then release the mouse button. Any intersections within the rubber band area should become highlighted. This group of intersections can then be dragged-and-dropped across the map, or lined up to have the same X or Y coordinate. After modifying a particular group of intersections, you can "unselect" them by clicking anywhere in the general map area.

Available "hotkeys" include F5 (toggle between Visual Mode and Classic Mode), F8 (Quick Lanes), F9 (Quick Phases), and F11 (Reports). Scrolling up and down via scroll wheel results in zoom in and zoom out.

Toolbar Icons in Visual Mode

Show All

When Visual Mode is initially opened, the "Show All" function is automatically applied. Typically after zooming or scrolling the map for some time, the user will want to return to that initial view where the link-node diagram was centered within the screen. Clicking on the Show All icon accomplishes this. If the link-node diagram is too large to fit within the screen, the Zoom Factor will be reduced to the largest possible value that makes the entire link-node diagram visible.

<u>Pointer</u>

The Pointer icon allows the user to select individual nodes (or groups of nodes), drag-and-drop nodes, and right-click on nodes to edit their properties. Groups of intersections can also be selected by dragging a rubber band around them.

<u>Zoom In</u>

After clicking on the Zoom In icon, the user can drag a rubber band around a section of the map to be magnified. If the horizontal and vertical proportions of this rubber band area match the horizontal and vertical proportions of the screen, the selected area can become the exact viewing area on the entire screen. Secondly, analog zooming can be achieved by simply left-clicking once inside the general map area. When analog zoom is used, Visual Mode will zoom in on the clicked spot by a fixed percentage.

Zoom Out

After clicking on the Zoom Out icon, the user can click on a map spot they wish to zoom out from. Visual Mode will then zoom out from the clicked spot by a fixed percentage.

<u>Pan</u>

After clicking on the Pan icon, the user can then drag the entire map in any direction.

New Intersection

After clicking on the New Intersection icon, the user can then drop a new intersection anywhere on the map. If the user wishes to add several new intersections in rapid succession, having the same default values, this can be performed by copying and pasting any chosen intersection.

Delete Intersection

After the Delete Intersection icon is selected, the user can then click on the most recent intersection to be deleted.

Add Curvature

After the Add Curvature icon is selected, two control points are automatically placed in the middle of each link (segment). Dragging and dropping either one of these control points will then create link curvature. When zooming and scrolling the map, link curvature is preserved. However, when dragging and dropping one or more nodes across the map, curvature control points are not automatically updated. Because of this, link curvature may need to be re-drawn after moving nodes across the map. It may be preferable to code link curvature after all nodes are already in their final positions. Curvature can also be added by left-clicking on any segment between two intersections.

New Access Point

After clicking on the New Access Point icon, access points can then be added on to any given segment. Access point input data can then be entered by right-clicking on the access point and selecting Edit.

Segment Pr	operties																>
Segment Data	O-D Seeds	Access Po	oints	Streets	Pedestrian	Bicycle	Transit										
Access Point Critical Headwa	y (left from majo	or), s 🛛	4.1		Access Points Active	_											
Follow-Up Head	way (left from r	major), s 2	2.2		PHF 1.00	+	1>			•	-	Count:	2	N	ew	De	elete
Right-Tum Equi	valency Factor	2	2.20			EBL	EBT	EBR	WBL	WBT	WBR	NBL	NBT	NBR	SBL	SBT	SBR
Maximum Tum I	Bay Length, ft	2	250.0		Demand, veh/h	80	1050	100	80	1050	100	80	0	100	80	0	100
Deceleration Ra	ate, ft/s2	e	5.7		Lanes	0	2	0	0	2	0	1	0	1	1	0	1
Right-Turn Spee	ed, ft/s	2	20.0		Name						Loca	tion, ft	600.0	0			

Align Nodes

Selecting a group of intersections causes the Align Nodes Horizontally and Align Nodes Vertically icons to appear on the toolbar. The dialog shown below can then be used to align all intersections horizontally or vertically, if desired.

Align	×
Align intersec	tions based on:
○ Node	1 ~
 Coordinate 	500
ОК	Cancel

Map Colors and Properties

This icon opens the Layout Properties dialog. Values and settings within this dialog are stored into memory on the computer every time the "OK" button is pressed.



Show Grid

If the Show Grid icon is activated, horizontal and vertical gridlines will be displayed across the map. This can be helpful for understanding the amount of real-world distance represented by the map.

Show Background Image

This icon can be used to show or hide the bitmap background. The icon is only enabled if a bitmap background image has been loaded (using Background Image Properties).

Background Image Properties

The Background Image Properties dialog screen is shown below. The Browse button allows the user to search for available bitmap background files on the computer. Image origin specifies the lower left-hand X, Y coordinates of the bitmap background (the adjacent picture allows the user to change the origin via drag-and-drop). The Bitmap Scaling icon is probably a more effective mechanism for bitmap background scaling, but the image scale coordinates below allow for manual scaling of the bitmap background.



Background Image Scaling

The Background Image Scaling icon is only enabled if a bitmap background image has been loaded (using Background Image Properties). After clicking on this icon, the user can draw a line between any two points on the map, where the distance between these two points is known. After the line has been drawn, the dialog screen shown below will pop up. After the actual distance (in units of feet) between these two points is entered, the bitmap background image will automatically scale itself to the proper size.

🛤 Background Image	Scaling	— ———————————————————————————————————
Distance on screen (without scaling)	0.229	inches
	220	coordinates
Actual distance (feet)	1000	
	ОК	Cancel

Advanced Features

Quick Animation

Please refer to the CORSIM section.

CORSIM

Selecting File > CORSIM > View Animation, will display CORSIM Animation (also known as TRAFVU) for the currently loaded HCS data file. HCS-Streets will automatically generate a CORSIM input (*.trf) file, process the TRF file through CORSIM and then launch TRAFVU to provide animation of the urban street (or signalized intersection, if only one intersection exists in the dataset).



This overall process may take a few seconds. Once TRAFVU is loaded, the user will need to:

- Click on the red "Vehicle" icon to display vehicles
- Zoom in on a certain part of the link-node diagram
- Adjust the "APC settings" to slow down animation
- Press "Play" to begin animation

CORSIM and HCS contain different modeling methodologies, so the visible results (e.g., queue lengths) from CORSIM animation may not always be consistent with HCM procedure results from HCS.

TRAFVU graphics are very informative for learning about actuated control. By turning on the map adornment for Sensors, it is possible to show typical detector layouts for semi-actuated or fully-actuated

control. Clicking on an actuated signal will reveal the dual-ring phasing sequence. For semi-actuated signals, pie charts are available for graphic display of permissive periods and force-offs.

The following HCS inputs are exported to CORSIM and displayed by TRAFVU: Peak adjusted traffic volumes, signal timing, lane configuration, adjusted saturation flow rates, start-up lost times, percent heavy vehicles, right-turns on red, duration of analysis, available queue storage, intersection names, and segment names. Link-specific mean discharge headways in CORSIM do not reflect any heavy vehicle or turn movement saturation flow rate adjustments from HCS, because this would constitute "double-counting" their effect on results.

The following HCS inputs are not exported to CORSIM: Average queue spacing, initial unmet demand, arrival type, I-factor, extension of effective green, pedestrian data

The following data ranges are enforced:

- Start-up lost time (0.0-9.9 seconds)
- Turn pocket or turn bay length (20-1000 feet)
- Link length (50-9999 feet)
- Saturation flow rate (1000-4000 vehicles per lane per hour)
- Number of turn pockets (maximum of 2 LT and 2 RT pockets)
- Volume (maximum of 9999 vehicles per hour)
- Green plus yellow time must be at least 8 seconds for non-overlap phases
- Green time must be at least 5 seconds for non-overlap phases

The following assumptions and limitations also exist: Vehicle arrivals to an isolated intersection in CORSIM are always random, and cannot be forced to be platooned by coding an "Arrival Type" other than '3' in HCS. Link lengths and turn pocket lengths for CORSIM are taken from the "Available Queue Storage" fields in HCS. If no queue storage lengths are coded in HCS, link lengths are automatically set to 2000 feet. When a left-turn in HCS is opposed by a right-turn, but is not opposed by a thru movement, assumptions are made in CORSIM regarding left-turn protection and signal phasing. For actuated coordination, if dual lagging left-turns are present on the major street, it is assumed that any protected left-turns on the minor street will also lag their associated thru movements. If a protected right-turn green arrow moves in the same phase as a conflicting thru movement in HCS, CORSIM may not illustrate this. Green time in HCS should not be given to any turning movements whose "adjusted" volumes are equal to zero. T-intersections in CORSIM will sometimes be illustrated with four approaches, where one approach contains no moving traffic. If three or more exclusive left-turn lanes are coded in HCS-Signals, only two exclusive right-turn lanes will be transferred to CORSIM. If six or more thru lanes are coded in HCS-Signals, only two exclusive right-turn lanes will be transferred to CORSIM.

These are not limitations of CORSIM, because CORSIM itself can simulate these conditions. These are only limitations of the conversion process between HCS and CORSIM. If any of these assumptions or limitations do not match conditions in the field, the user can select File > CORSIM > Generate TRF File, and customize the CORSIM input data within TSIS.

If an error message says "This feature requires TSIS-CORSIM" even after TSIS has been installed, it may be necessary to first run TSIS in the standalone mode, so that TSIS-CORSIM can be properly registered on the computer. If the user does not have administrator rights, they may encounter an error message that says "ERROR: Failed to find file". This error message should not hinder animation, so the user should simply click "OK" and then view animation normally.

Quick Optimization

There are two options for signal timing optimization: Quick Optimization (via one-touch export to TRANSYT-7F) and Full Optimization (via HCM-based internal genetic algorithm). Generally speaking, Quick Optimization is preferable for quickly finding a reasonable and effective timing plan, whereas Full Optimization is preferable for locating the "global optimum solution". The Minimum Cycle Length, Maximum Cycle Length, and Cycle Length Increment input fields (under Detailed Input Data > Global

Optimization) can be used to automatically request cycle length optimization. When the user clicks on the Quick Optimization icon, volumes and timings from the HCS dataset are automatically transferred to a corresponding TRANSYT-7F dataset, and the optimization process begins immediately. Following optimization, outputs are automatically displayed in the dual-ring report shown below.

T≓ Du	ual-Ring	g Report	(press	Ctrl-P to	print)							>
Noc	le Numb	ber 1	•						Systen	n Cycle	100 (Offset 0
Grn	13	49	5		19		-					116
Yel	3	4	3		4							21/2
Ded							E.			្រ		
Red	0		10	_ [9	_							10 11
Grn	13	49	5		19				~	ι	3	
Yel	3	4	3	F	4	_7			-	3	2	医小刀
Red	0	0	0	Ī	2							Ϋ́Ι.
	1			1						201220		
		Eastbou	nd		Westbo	und		Northbou	und	5	Southbou	Ind
	Left	Thru	Right	Left	Thru	Right	Left	Thru	Right	Left	Thru	Right
	Peak A	Adjusted	Volume	(vph)								
	200	1000	10	200	1000	10	100	500	50	100	500	50
	Satura	tion Flow	w Rate ((vphg)								
	1900	3800	1900	1900	3800	1900	1900	3800		1900	3800	
	Queue	Length	(veh)									
	6.3	17.5	0.1	5.3	19.2	0.1	2.0	14.5		2.0	14.5	
	Degree	e of Satu	ration (*	%)								
	81	54	1	81	54	1	38	77		38	77	
	Contro	Delay	(sec/vel	1)	_			_	(Inters	ection D	elay = 2	9)
	59	18	13	57	12	5	25	43		25	43	
	TRAN:	SYT Lev	el of Ser	vice					(TRAN	SYT No	de LOS	= C)
	E	B	В	E	В	A	C	D		C	D	
	TRANSY	T-7F Releas	se 12.2				Co	pyright (c) 3	2022 Univer	sity of Florid	da, All Right	s Reserved
	Analys	st					Date P	erforme	d	Nov 30,	2021	
	Agenc	У					Analys	sis Time	Period			
	Jurisd	iction										
	Run Ti	itle	Run Ti	itle								
	File Na	ame	tmpF2	1C.tin								

Compared to Full Optimization, the Quick Optimization feature has specific strengths and weaknesses. Quick Optimization employs the hill-climb optimization method, which is much faster than the genetic algorithm. However, the hill-climb method is also a less effective search technique than the genetic algorithm. Thus Quick Optimization is faster than Full Optimization, but may result in a less effective timing plan. Other miscellaneous advantages of Quick Optimization include queue spillback analysis and lane-by-lane analysis, which are innate features of TRANSYT-7F. Other disadvantages include model results that may differ from HCS (particularly in the case of permissive left-turns), and the inability to optimize multi-period datasets. To circumvent the disadvantages related to hill-climb optimization and multi-period optimizations, the user may launch TRANSYT-7F in stand-alone mode and import the *.xus files (s) from HCS. When running in stand-alone mode, TRANSYT-7F has the ability to perform genetic algorithm optimization and multi-period optimization; but such optimizations require more extensive run times on the computer, and would no longer be considered "quick optimization".

Full Optimization

Full optimizations may require extensive run times on the computer, but the user may terminate the optimization process at any time. The genetic algorithm search technique is specifically designed to locate the global optimum solution provided that 1) the original dataset already has a reasonable and effective timing plan, 2) the "number of generations" is sufficiently high, and 3) the detailed settings (population size, mutation probability, etc.) are reasonably tailored to the given urban street. Thus Full Optimization is slower than Quick Optimization, but it should result in a more effective timing plan. The optimization "dashboard" is shown below.

(Percent	Base FFS		
	Original	55.3%		
	Optimum	68.7%		
	Average	67.6%		
	Improvement	19.5%		
	Run	Status	_	
	Generation Number	6 out of 20		
	Generation Optimum	6		
	Total Time Elapsed	5 sec		
	Optimization in progre	ss		
				Start

When the user clicks on the Full Optimization icon, the optimization dashboard will be displayed. The Input Parameters section of the dashboard will be displayed by default; the user will then have the opportunity to adjust optimization settings before the optimization run. The Info button, which is linked to the Diagnostic Messages section, will be enabled if the dashboard detects any inputs that might make the optimization process less efficient. Clicking on the Start button will begin the optimization process. The dashboard value of "Generation Optimum" will increase each time a better signal timing plan is successfully located.

Currently there are three possible ways that the optimization process can terminate: 1) termination via convergence threshold, 2) termination via max number of generations, and 3) termination via user request. Termination via convergence threshold will occur whenever the optimization process detects that little additional improvement is possible. Termination via max number of generations will occur whenever the optimization process reaches the user-specified maximum number of generations. Termination via user request will occur whenever the user clicks on the Stop button. Because of the "start-stop-resume" feature, the user can stop and re-start the optimization process at any time.

Other miscellaneous advantages of Full Optimization include HCM-compliant modeling for each candidate timing plan, and optimized timings presented in the HCS format. Other disadvantages include the need to specify appropriate genetic algorithm settings for the given urban street, but the Info button (and Diagnostic Messages section) is designed to prevent the use of inefficient settings.

Larger urban streets will typically benefit from lower mutation probabilities, higher population sizes, and a larger number of generations. Apart from the number of generations, which must frequently be customized to match the amount of optimization needed, the default genetic algorithm settings should work well for most medium-sized urban streets. For a more detailed discussion of genetic algorithm theory, refer to Chapter 5 of the TRANSYT-7F User Guide.

Phasing sequence optimization is currently designed to optimize lead/lag phasing (and sometimes Dallas Phasing) on the major street, and will not modify phasing sequences on the minor street. If Full Optimization generates dual lagging left turns at one or more intersections, but the user's original timing plan does not contain dual lagging left turns at any intersections, values of lead/lag and Dallas Phasing will revert to the user's original values at the dual lagging intersections. If Full Optimization generates dual lagging left turns at one or more intersections, the user's original timing plan contained dual lagging left turns at one or more intersections, and the user's original timing plan contained dual lagging left turns at one or more intersections, the dual lagging values will be allowed to stick, and Dallas Phasing will be turned off at these intersections.

When performing phasing sequence optimization, the "Dallas Phasing Optimization" checkbox can be activated to prevent phasing sequences that would result in a "yellow trap" for the permissive left-turners. If the Phasing Sequence Optimization checkbox is selected without Dallas Phasing Optimization, the dashboard will post a warning message, but the optimization process will not modify the user's original values of Dallas Phasing. If Phasing Sequence Optimization is selected with Dallas Phasing Optimization, the optimization process will turn on Dallas Phasing when a lagging left turn is opposed by a permissive left turn, and will turn off Dallas Phasing when both left turns are leading.

Although the Info button (linked to the Diagnostic Messages section) will be enabled when detecting inputs that might make the optimization process less efficient, there are some macroscopic strategies that the user should also consider. One such strategy could involve turning off the "Allow Optimization" checkbox at intersections that are already performing well (level of service A or B), so the optimization process can focus on re-timing the poorly-performing intersections. Another strategy could involve turning off phasing sequence optimization for arterials that already have an effective phasing sequence in place, so the optimization process can focus on fine-tuning the splits and offsets. Another strategy could involve using a more narrow range of minimum and maximum cycle length values, because examining a wide range of ineffective cycle length values could definitely make the optimization process less efficient.

After a Full Optimization run has been completed, the amount of optimization improvement over time can be plotted on the Flow Profile Diagram. Refer to the Flow Profile Diagram section of the documentation for more details.

Time-Space Diagram

The Time-Space Diagram screen provides a mechanism for visualizing the available progression between intersections along the major street.



Timing Plan Representation

Signal timing plans are painted vertically, with only the major street green times and yellow times colored green and yellow. Green and yellow intervals for all minor movements are painted red, usually resulting in the appearance of numerous discrete and consecutive red intervals. Node numbers are listed in the white circles at the bottom of the Time-Space Diagram screen. If an uncoordinated intersection (based on the "Uncoordinated Intersection" checkbox) is included within a progression route, the entire vertical distance will be painted red, which will terminate any incoming progression bands.

Signal timing plans are fitted to the screen vertically, such that the vertical distances of each "bar diagram" represent the background system cycle length of the urban street. Thus, the green time painted for each bar diagram represents the proportion of the cycle length occupied by the major street through movements. The vertical location of a green interval is a function of the offset and the reference phase. Scrollbars at the side of the screen can be used to simultaneously change vertical locations of all intervals and green bands, but have no net effect on the offsets and reference phases.

When progression bands are being drawn in one direction (forward or reverse) only, the Time-Space Diagram screen is capable of painting multiple green intervals for major route movements. For example, if the forward direction is Eastbound, and the eastbound through movement begins before the westbound through movement, the eastbound movement will have multiple forward progression green intervals. When progression bands are being drawn in both directions, only the coordinated phase (with both major street segments moving simultaneously) is painted green.

Interactive Coding of Offsets

Moving the mouse cursor inside any of the vertical bar diagrams will allow the user to click and drag timing plans vertically. This automatically modifies the corresponding offset within the *.xus file. By adjusting the offsets interactively, it might be possible to quickly achieve an excellent bandwidth. When adjusting the offsets interactively, it is also helpful to take note of the efficiency and attainability values, as discussed later.

Forward Direction

The urban street forward direction (NB, SB, EB, or WB) is displayed in a disabled combo box, in the upper left-hand corner of the screen. The progression band direction (Fwd, Rev, or Both) is displayed in a second combo box. When the Time-Space Diagram screen is first loaded, progression bands are drawn in the "forward" direction of travel only. The user can switch the progression band combo box to draw these lines in the reverse direction, or in both directions, if desired. For one-way streets, this combo box is disabled and only displays the forward direction.

Efficiency and Attainability

When optimizing offsets interactively, the efficiency and attainability values at the top of the screen are updated automatically. By paying attention to comments such as "fair progression" and "increase shortest green", it can be possible to determine whether further improvements are needed. If an uncoordinated intersection is present on the urban street, the screen will state that "This artery contains uncoordinated nodes". Efficiency and attainability will always be zero for arteries that contain uncoordinated nodes, because it is not possible to achieve reliable progression through an uncoordinated intersection.

Cumulative Bands

The initial progression bandwidth is based on the major street through movement's green time at the "first" intersection only. As new intersections are encountered, it is possible to observe where the bandwidth is becoming partitioned, and gradually reduced.

Progression bands typically do not begin and end exactly when the major street green time begins and ends. Instead, the progression band begins a few seconds after the onset of green, and ends a few seconds after the onset of yellow. This is a reflection of the effective green time, which is affected by user-entered start-up lost times and extension of effective green times.

The progression bands are drawn as dashed lines across the screen; their slope is a function of segment length, and segment travel speed.

<u>Width</u>

When the Time-Space Diagram screen is first loaded, the initial view is a "fit to screen" view. All intersections on the urban street should be horizontally visible on the screen at one time. The horizontal distance from one end of the urban street to the other is displayed in the Width field. Although the width of the software screen remains constant, the displayed value (in units of feet) indicates the "represented" real-world distance of the urban street.

Number of Cycles

A drop-down combo box can be used to specify how many signal cycles will be displayed on the diagram. Note that displaying multiple cycles can cause the screen to operate more slowly, which could affect speed of the vertical scrollbars, or interactive offset adjustment.

Flow Profile Diagram

The Flow Profile Diagram screen can be used to view static graphics that describe Streets simulation results. To operate this screen, the user can select their desired segment number within the urban street. The user can also select their desired flow profile category. Available flow profile categories include Downstream Arrival Rate, Downstream Projected Rate, Upstream Departure Rate, Access Point Arrival Rate, and Optimization Improvement. Optimization Improvement can only be plotted if a Full Optimization run has been performed recently.



After selecting the desired segment number and flow profile category, the user can select their desired direction of travel, which is either forward ("Fwd") or reverse ("Rev"). For example, if the user views the Downstream Arrival Rate for segment #1 in the forward direction, the Flow Profile Diagram will display the arrival rate of vehicles at downstream intersection #2. Finally, the user can select their desired intersection turn movements for plotting flow profiles. Up to four turn movements can be selected if the user wishes to view aggregated results for left-turn, thru, right-turn, and midblock traffic movements. The aggregated midblock traffic movements can only be plotted for the Downstream Projected Rate and the Upstream Departure Rate.

For multiple period analyses, flow profiles are displayed for the "active" time period within the Streets user-interface. On the X-axis, the system background cycle length is used to compute flow profile dimensions. The Y-axis is automatically scaled to display the highest flow profile value. Flow profiles will not be displayed for any intersections specified as uncoordinated intersections, based on the

"Uncoordinated Intersection" checkbox.

The Average Value displayed at the top of the screen represents the average profile value across every step of simulation. This can be useful for validating some of the simulation results. For example, the average input flow rate value of 1177 veh/h shown in the screen image above suggests that the hourly flow rate for this segment was 1177 veh/h, despite platoon dispersion that temporarily caused flow rates as high as 2755 veh/h.

When plotting the Downstream Arrival Rate, the green shaded area is used to indicate when green time is occurring at the downstream signalized intersection. When plotting the Downstream Projected Rate and the Upstream Departure Rate, access point "zero" is used to indicate downstream intersection flows that originated at the nearest upstream access point. Moreover, access point #1 is used to indicate access point flows that originated at the upstream signalized intersection. If more than one access point exists on the segment, access point #2 is used to indicate downstream access point flows that originated at upstream access point. When plotting the Access Point Arrival Rate, access point "zero" is no longer applicable, and the access point number indicates which location along the segment is being plotted.

Diverging Diamond Interchange (DDI)

Overview

The Diverging Diamond Interchange (DDI) is a variation of the traditional diamond interchange in which arterial traffic briefly drives on the opposite side of the road from what is customary. This innovative roadway geometry allows a two-phase signal timing operation, which provides significant operational and safety benefits. The DDI geometric design also allows left-turning traffic from the arterial to enter the freeway on-ramp without stopping.

Given the unique nature of DDI movements and free-flowing left turns, specific data entry methods are needed to achieve accurate modeling of DDIs in an HCM context. These data entry methods, which are outlined in this guide and in the example datasets, are summarized as follows for the HCS Streets software (hereinafter referred to as 'Streets'):

- Major-street split phasing is achieved by entering lead-lag phasing with no overlap. (Section VI.)
- Off-ramp left turns on to the arterial must be defined as right turns, so they can move concurrently with outbound arterial through movements. *(Section III.)*
- Turning radii for the off-ramp left turns must be modified accordingly, because the default rightturn radii will produce incorrect capacities. *(Section III.)*
- Arterial left turns on the freeway must be defined as exclusive lanes even if they are shares lanes, to allow the phasing to work properly (a special checkbox is provided to indicate shared lanes for this case, to achieve proper lane utilization adjustment factor). (Section III.)
- Streets allows entry of high start-up lost times, for when off-ramp movements must be held longer. (Section III).
- Streets allows entry of negative extension of effective green times, for when off-ramp movements must terminate earlier. (Section III.)
- User inputs are now provided for extra distance travel time (EDTT). (Section V.)

Interchanges and Alternative Intersections

To define a DDI interchange in Streets, both intersections should be marked as Interchange Intersections, with the Interchange Type being set to Diverging Diamond. This input field is found under the Detailed Input Data section of Streets. Once these inputs are set, the Diverging Diamond Data and EDTT Data input buttons (details in a later section) become enabled.

In Streets, this appears as shown below:

Interchanges	Alternative
Interchange Intersection	Alternative Intersection
Interchange Type Diverging Diamon -	
Diverging Diamond Data	Intersection Type
EDTT Data	

Coding Movements

Below is a generic example of a DDI:



Source: HCM

Initially, DDI intersections should be coded in Streets as seen in real life. However, in order to analyze a DDI facility in Streets, adjustments need to be made to the coded intersections to allow for overlap phasing and general program function. Adjustments that need to be made are shown below:

- **M8/M4** In addition to the off-ramp right turn, a through movement (with demand of zero vehicles per hour) should be added along the same direction to allow phasing to operate normally.
- M7/M3 In order to create overlap phasing with M5/M1, this movement should be coded on the approach opposite of M8/M4 (meaning that if M8/M4 is a southbound movement, then M7/M3 should be a northbound movement, and vice versa). Once the direction is set, the approach lane configuration is coded as one through lane with demand of 1 veh/h, and one or more exclusive right turn lanes. Note that because these right-turn movements are in fact left turns in real life, the user should edit the right-turn radius so it reflects the actual off-ramp left-turning radius. Accepting the defaults right-turn radius in this situation will produce incorrect capacity estimates.
- **M6/M2** In order to create overlap phasing with M8/M4, an exclusive left turn lane (with demand of 1 veh/h) should be added to the approach. Additionally, the on-ramp right turn movement should be marked as an Unsignalized Movement.
- M5/M1 The on-ramp left-turn movement should be coded as an exclusive left-turn lane and marked as an Unsignalized Movement. If the on-ramp left-turn movement is made from a shared lane in real life, it must be coded as an exclusive left-turn lane and an additional through lane. A subsequent check box (described later) is available to indicate the exclusive left-turn lane and through lane as a shared lane.

Below are the adjusted lane configurations for both DDI intersections, as viewed within Streets, for the above example:



With the exception of specific demands mentioned in the prior list of adjustments, all other demands should be coded normally. Most other inputs such as Lane Width, Heavy Vehicle percentage, Turn Radius, etc. can be applied normally. However, off-ramp movements that flow towards the middle of the DDI are coded on the opposite sides of the intersection (e.g., northbound right turn instead of southbound left turn at intersection #1 in the above example, and southbound right turn instead of northbound left turn at intersection #2 in the above example), so their accompanying movement-specific characteristics should also be coded on the opposite sides of the intersection.

Note: The HCM does not provide a procedure to model any queue blockage that would delay left-turning vehicles from a DDI to a freeway on-ramp. For such cases, the use of alternative tools is advised.

Automation for the DDI Additional Lost Time procedure is not completed as of this release. In order to temporarily compensate for this, please compute overlap lost time on the Diverging Diamond Data screen (details in a later section) and estimate the other lost times. Once this is completed, then manually code the appropriate values of Start-Up Lost Time in order to model these effects.

Diverging Diamond Data

The purpose of this function is to determine lost time for the off-ramp movements (M7/M8/M3/M4) for each intersection in a DDI. Additionally, if a shared lane is present and was coded as an exclusive left-turn lane and an additional through lane, the check box available to indicate the exclusive left-turn lane and through lane as a shared lane is found here.

In Streets, this appears as shown below:

Diverging Diamond Inputs	11_	
Intersection 1		
On-Ramp Left Lane Shared (WBL)	\checkmark	
	Off-Ramp Left (M7)	Off-Ramp Right (M8)
Width of Clear Zone, ft	0.0	0.0
Shortest Distance, Stop Bar to Conflict Point, ft	0.0	0.0
Design Vehicle Length, ft	20.0	
Free-Flow Speed of the Vehicle, mi/h	35.0	35.0
Lost Time, s	0.4	0.4
Intersection 2		
On-Ramp Left Lane Shared (EBL)		
	Off-Ramp Left (M3)	Off-Ramp Right (M4)
Width of Clear Zone, ft	0.0	0.0
Shortest Distance, Stop Bar to Conflict Point, ft	0.0	0.0
Design Vehicle Length, ft	20.0	
Free-Flow Speed of the Vehicle, mi/h	35.0	35.0
Lost Time, s	0.4	0.4

The remaining input fields shown above are represented graphically in the image below:



EDTT Data

The purpose of this function is to calculate the Extra Distance Travel Time (EDTT) for each origindestination (O-D) Movement. The EDTT is then applied to the Total Control Delay to find the Experienced Travel Time (s/veh) for each O-D Movement. The extra distance traveled (ft) and the design speed (mi/h) for each O-D Movement, which can be measured from design drawings or aerial images, is used to calculate the Extra Distance Travel Time (EDTT). In Streets, this appears as shown below:

EDTT Data		- 🗆	×
O-D Movement	Extra Distance, ft	Design Speed, mi/h	EDTT
A NBL	100	35	1.9
B NBR	-100	35	-1.9
C SBR	-100	35	-1.9
D SBL	100	35	1.9
E EBL	100	35	1.9
F EBR	0	35	0.0
G WBR	0	35	0.0
H WBL	100	35	1.9
I EBT	40	35	0.8
J WBT	40	35	0.8
К	0	35	0.0
L	0	35	0.0
М	0	35	0.0
N	0	35	0.0

Signal Timing Inputs

The input settings listed below are strongly recommended. HCM example problem datasets (automatically installed along with the software) are available to demonstrate these coding techniques, and all other coding techniques described within this guide.

- Major-Street Split Phasing
 - The user-entered Phase Split for phase 1 should be equal to the user-entered Phase Split for phase 5. Additionally, one of the two major-street left-turn phases should be designated as the Lag Phase. Similarly, the user-entered Phase Split for phase 2 should be equal to the user-entered Phase Split for phase 6.
- Field-Measures Phase Times (this checkbox should be turned on)

A typical example of signal phasing entry is shown below.



Phases 1 and 5 are the overlap phases created by the adjustments made to M6/M2 and M7/M3. Signal phasing must be entered for both DDI intersections individually. Generally it will be necessary for phases 1 and 5 to be coded as overlap phases at both intersections. Additionally, there should not be any Permitted Left-Turn Phases in either intersection.

Timing inputs should be associated with the following movements:

- M6/M1 EBT
- M5/M2 WBT
- M8/M3 EBL (Due to overlap phasing)
- M7/M4 WBL (Due to overlap phasing)

For the 'dummy' through movements with a demand of 1 veh/h (NBT/SBT in the above example), these are represented by phases 4 and 8. The following timing is recommended to minimize their impact:

	NBL	NBT	SBL	SBT
Assigned Phase		(8)		(4)
Phase Split, s	0.0	1.0	0.0	1.0
Yellow Change, s	4.0	0.0	4.0	0.0
Red Clearance, s	0.0	0.0	0.0	0.0
Minimum Green, s	1	1	1	1

Output Reports

Results for a DDI are provided in both the Interchanges Text Report and the Interchanges Results Report. Once again, due to the unique nature of DDIs, there are differences in these reports from the ones generated for other interchanges. An explanation of the unique characteristics of each report is given below:

Interchanges Text Report – The text report provides detailed intermediate outputs that are required components of the DDI procedure, but are too extensive to fit on the formatted reports. These intermediate outputs include saturation flow rate adjustment factors, effective green times, queue storage ratios, and lost times for each movement and timer. The following adjustments to the base saturation flow rate are specifically related to the DDI procedure:

- DDI Factor (f_{DDI}) an adjustment factor of 0.913 for the crossover through movements in a DDI
- Lane Utilization Adjustment Factor (*f*_{LU}) the procedure for a DDI differs from other interchanges as the adjustments for the external crossover are a function of left-turn demand ratio at the internal crossover. Additionally, this procedure takes into consideration the lane configuration of the DDI and distinguishes between exclusive and shared lane configurations.
- Traffic Pressure Adjustment Factor (*f_V*)

An example of the Interchanges Text Report is shown below:

Current Interchange Intersection Intermediate Results

Movement: Lane Util. Adj. f_LU Left-Turn Adj. f_LT	EBL 5 1.000 0.952	EBT 2 0.729 0.000	EBR 12 1.000	WBL 1 1.000 0.952	WBT 6 1.000 0.000	WBR 16 1.000	NBL 3 1.000 1.000	NBT 8 1.000 1.000	NBR 18 1.000	5BL 7 1.000 1.000	5BT 4 1.000 1.000	SBR 14 1.000
Right-Turn Adj. f_RT DDI Adj. f_DDI Additional Lost Time	1.000	0.000 0.913 NaN	0.847	1.000	1.000 0.913 0	1.000	1.000	0.000	0.962	1.000	0.000 1.000 0	0.935
Effective Green Queue Storage Ratio RQ	34.3	30.1	30.1	25.2	25.2			0.7	16.1 0.00		0.7	30.0
Timer:		1		2	3	4		5	6		7	8
Assigned Phase Left-Turn Perm f_V		0.97		2	0	4		6	0.93		0	8
Left-Turn Prot f_V Thru f_V Right-Turn f_V		1 1 1	0.9	1 7 5	1 1 1	0.93 0.95	0	1 96 1	1 1 1		1 1 1	0.93 0.96

Interchanges Results Report – The formatted report summarizes the most important inputs and outputs associated with the DDI procedure. The relevant input information includes project-specific information, demand volumes at both DDI intersections, lane geometries at both DDI intersections, and signal timings at both DDI intersections. Relevant output data includes performance measures for each individual movement, O-D movement, and intersection within the DDI. The full report is shown in the next page:

					H	CS Ir	nter	chan	ges F	Res	ults	s Sun	nmary	/					
Correct		-										1.							
Gener		ation	1									II Ir	ntercha	nge Inf	ormatio	on	ivorging	Diamon	d
Analys	y st					Δ	nalve	ie Date	Nov	20 20	121	 	Segment	Distan	co ft		iverging	Diamon	iu
lurisdi	iction						urati	on h	0.250))	121	F	reeway	Directio	00, IL				
Interse								JII, II	0.250	,			rtorial D	irection))	E	act Wee	+	
File N	amo		Interch	anges5	Divergin	Diam	ond\	VithSia	nalCon	trol v		14		inection	1		asi-wes	ι	
Projec	t Descript	ion	Intercha	angess-	Diverging	JDiam	ionuv	viuroig	naicon	101.7	us								
Tiojec	t Descript			1. M.S. M.S. M.S.	1015 - 1015 - 2015 - 2015 -						West Merry		2011 - 2011 - 2011 - 20					1. XXX. XXX. XXX	
Dema	nd					E	EBL	EBT	EBR	2 V	VBL	WBT	WBR	NBL	NBT	NBR	SBL	SBT	SBR
Interse	ection One	e Dema	and (v),	veh/h			1	1300	200	3	300	500			0	300		0	200
Interse	ection Two) Dema	nd (v),	veh/h			600	1000			1	450	300		0	200		0	350
			1 1																
Signa	l One Infe	ormatio	on		1	4	1											14791	Ja La
Cycle,	s	70	0.0			€ .		177						\rightarrow	2	¹ xt	4		
Offset,	s		0	Green	25.0	34.0	1.0	0 0	.0 (0.0	0.	.0			2	3	4	N 10	
Uncoo	rdinated	N	10	Yellow	4.0	4.0	0.0	0 0	.0 (0.0	0.	.0		-			Þ	~	1 () () () () () () () () () (
Force	Mode	Fix	ked	Red	1.0	1.0	0.0	0 0	.0 (0.0	0.	.0	5		6	7	8	11147	14
									1						1				E 11
Signa	l Two Info	ormatio	on			4	님사											ŢŢ	
Cycle,	S	70	0.0		F			17					* 🗗	→	2	3	4 →		- 4 ×
Offset,	S		0	Green	34.0	25.0	1.0	0 C	.0 0	0.0	0.	.0		<u>ь</u>			***	• ***	÷
Uncoo	rdinated	N	10	Yellow	4.0	4.0	0.0	0 0	.0 (0.0	0.	.0					2	- + r	e e
Force	Mode	FD	ked	Red	1.0	1.0	0.0	5 0	.0 (0.0	0.	.0	5		6	7	8	54144	¥ 11
Interel	hanga Da	oulto																	
merci		liuctod			Con	trol	-	Total	Evt	· _]									
O-D	Dema	and	Move	ement	Del	ay	c	ontrol	Dista	nce	Е	DTT	ETT	LC	os		C D N N	6	
	(veh	/h)			Compo	nents		Delay	(ft))	(s/	/veh)	(s/veł	ר)			/// 11	1	
							(s	/veh)							_			11	
A	36	8	N	BL	M3 +	M5		39.6	100	0		1.9	41.6	(C			11	
В	21	1	NE	BR	M	1		23.7	-10	0	-	1.9	21.8		3	/			
С	21	1	SE	BR	M	3		15.0	-10	0	-	·1.9	13.0		4				
D	31	6	St	3L	M7 +	M1	-	61.5	100)		1.9	63.5				\sim	\sim	H J
E	63	2	Et	BL	M	<u>,</u>		26.5	100)		1.9	28.4		3 <u>i</u>	_		γ	
F	21	1	Et	3R	N/.	4	-	0.0	0	_		0.0	0.0		4				
G	31	0	VVI	BR	IN/.	4		0.0	0			0.0	0.0		4			117	
H	31	0		BL	IVI.	<u> </u>		29.7	10			1.9	31.0						
	13	0				IVI I	-	30. I	40			0.0	30.0					//	
M	15	0	VVI	DI	IVIZ T	IVIS	-	+7.0	40	_		0.0	40.0				+++ / /	!	
N							-												
			Inter	rchange	FTT (s/	eh) ai	ndIC	25					30.8						
			inter	Shange	_ 1 7 (3/1	siri) ai							00.0						
Signal	lized Inte	rsectio	n One F	Results				EB				WB			NB			SB	
Approa	ach Move	ment					L	Т	R	L	.	Т	R	L	Т	R	L	Т	R
Contro	l Delay (d), s/v	reh			9	9.3	26.5	0.0	0.	0	18.1			0.0	49.9	1	0.0	15.0
Level	of Service	(LOS)					А	С	A	A	1	В				D			В
Approa	ach Delay	, s/veh	/LOS				22.9)	С	· ·	11.3		В	49.9	9	D	15.0)	В
Interse	ection Del	ay, s/ve	h / LOS						2	1.9							С		
Signal	lized Inte	rsectio	n Two F	Results				EB				WB			NB			SB	
Approa	ach Move	ment					L	Т	R	L		Т	R	L	Т	R	L	Т	R
Contro	l Delay (d), s/v	reh			(0.0	11.6		14	.5	29.7	0.0		0.0	23.7		0.0	21.5
Level of	of Service	(LOS)					Α	В		E	3	С	Α			С			С
Approa	ach Delay	, s/veh	/LOS				7.2		Α		17.8		В	23.7	7	С	21.5	5	С
Interse	ection Del	ay, s/ve	h / LOS						1	2.8							В		

Alternative Intersections

Modeling Capability in HCS

HCS has the capability of modeling five types of alternative intersections supported by HCM:

- Restricted Crossing U-Turn Intersections (RCUT) with Signals
- Restricted Crossing U-Turn Intersections (RCUT) with Stop Signs
- Restricted Crossing U-Turn Intersections (RCUT) with Merges
- Median U-Turn Intersections (MUT) with Stop Signs
- Partial Displaced Left-Turn Intersections (DLT)

The computations procedure for each type of alternative intersection can be used to estimate the control delay, extra distance travel time (EDTT), and experienced travel time (ETT) per origin-destination (O-D) demand movement. The level of service (LOS) for alternative intersections is dictated by the ETT value. RCUT with Signals, MUT with Stop Signs, and Partial DLT are applicable to the Streets module.

Creating New Alternative Intersection Datasets

Steps to Build an RCUT with Signals

To conduct a full RCUT analysis, two separate Streets (*.xus) files are needed. Each file will contain two intersections, essentially splitting the 4-intersection RCUT in half. The second file must have a forward direction opposite of the first file. The figure below presents the structure of the two RCUT files along with the lane configurations for each intersection.



File One - Intersections 1 and 2

- Create a new Streets (*.xus) file. This will serve as the conventional intersection file. Enter the conventional intersection demand and any desired universal inputs such as the peak hour factor, % heavy vehicles, speed limit, and timing data.
 - a. The universal inputs will be copied over to the two intersections generated by converting the conventional file to RCUT
 - b. The demand input, outlined in red below, will be redistributed to the two intersections generated by converting the conventional file to RCUT

PRIMARY INPUT	DATA												
General									2 4	J. A.	44	L.	
Urban Street										7+	Ļ		_
Intersection								14					*
Description								*				~_ ←	- 2-
Forward Direction	SB	•	Area T	ype	Other	-		*	1			ĸ	← *
Segment Length, ft			Duratio	n	0.25			-				_	e.
All Segment L	engths		PHF		0.93				ጉዳ	<u>ጎ</u> † ተቀ	۲ ۲	r	
Traffic													
		EBL	EBT	EBF	R WBL	WBT	WBR	NBL	NBT	NBR	SBL	SBT	SBR
Demand, veh/h		20	300	10	30	100	200	150	420	10	60	1900	50

Save the conventional intersection file. This file will be used to create the first set of RCUT intersections (1&2), but it is also needed to create the second set of RCUT intersections (3&4).
 Do not overwrite the conventional intersection file.

3. Go to the Alternative group box, which is found in the Detailed Input Data. Check the Alternative Intersection box.

nterchanges and Alternati Interchanges Interchange Intersection	ive Intersections		Alternative	
Interchange Type	Diamond	· •		
EDTTI	Data		Intersection Type	-

- 4. The Intersection Type dropdown will now become editable. Select RCUT and click Yes on the confirmation pop-up message.
- 5. The file is now of type RCUT.
- 6. Use the **Save As** command to save the current RCUT file.
- 7. Open the original conventional intersection file. It will now be used to create the second set of RCUT intersections, as mentioned in Step 2.
- 8. Change the forward direction to the opposing direction as the first RCUT file. For example, if the forward direction was SB for the first RCUT conversion, switch it to NB for this conversion.

General				لي	4 4 4 4 4	L.
Urban Street						
Intersection				_* 		۲. 4
Description				→_* +>	N WHE	
Forward Direction NB	 Area Type 	Other	-	-¥4		_ ↓ _ ↓
Segment Length, ft	Duration	0.25		-		- i
All Segment Lengths	PHF	0.93		1	<u>ן</u> אימי איז א	r.

- 9. Repeat steps 3 6.
- 10. Now that there are two separate RCUT files containing two intersections each, the full RCUT can be constructed. In either RCUT file, navigate back to the Alternative group box and select Open RCUT File. Select the opposing RCUT file.

Interchanges Interchange Intersection	ı 🗌	, i i	Alternative Alternative Intersection		
Interchange Type	Diamond	-	ntersection Type	RCUT	*
EDTT	Data		Open RCUT File	Additional	RCUT Inputs

11. Upon opening the opposing RCUT file, a pop-up titled Additional RCUT Inputs will appear.

-Turn Crossover	Median	Midth										
0	larrow (<	35ft)			Typic	al (35-80f	t)		0	Very Wid	de (> <mark>80ft</mark>)	
Conventional RCU	JT Deman	ds										
	EBL	EBT	EBR	WBL	WBT	WBR	NBL	NBT	NBR	SBL	SBT	SBR
Demand, veh/h	20	300	10	30	100	200	150	420	10	60	1900	50

Specify the type of median at the U-Turn crossover. This is used to apply a saturation adjustment factor to the crossover movement. Conventional demand fields are already populated with the demand values from the conventional intersection file, as shown in Step 1. Any desired changes to the original conventional demand values may be edited here.

a. Note: Streets automatically redistributes the Conventional RCUT Demand to the two intersections in the currently active file. The individual intersection demand input fields are greyed out but populated with the redistributed demand, as displayed below. This is by design and implemented to keep in accordance with the HCM procedure. If changing individual intersection demands is desired, the Conventional RCUT Demands in **both** of the RCUT files must be edited. Similarly, if the U-Turn Crossover Median Widths differ from Typical, this must be specified in each of the RCUT files.

	EBL	EBT	EBR	WBL	WBT	WBR	NBL	NBT	NBR	SBL	SBT	SBR
Demand, veh/h	320	0	0	0	0	0	0	580	0	0	0	0

- b. Note: The Additional RCUT Inputs button only becomes active once a second RCUT file has been opened.
- 12. To view results, go to the Reports dropdown in the top menu and select Alternative Intersections Report.



13. Note: The EDTT for RCUT is calculated based on the Field Free-Flow Speed. This input field is found in the Segment group box of the Detailed Input Data. Please edit this field in each of the RCUT intersections – coding the speed limit will not change the EDTT.

Name				
	NB	SB		
Upstream Width, ft	50	50		
Restrictive Median, ft	0	0		
Right-Hand Curb, %	70	70		
Right-Hand Access Points	0	0		
Mid-Segment Delay, s/veh	0.0	0.0		
Field Travel Speed, mi/h	21.79	42.25		
Field Free-Flow Speed, mi/h	50.00	50.00		
On-Street Parking, %	0	0		
Speed Calibration Factor, mi/h	0.0	0.0		

Steps to Build an MUT with Stop Signs

To conduct an MUT with stop signs analysis, both the Streets module and the Two-Way Stop Control module are used. The main intersection is coded in a Streets (*.xus) file, while the upstream and downstream crossover junctions are coded in TWSC (.xtw) files. The TWSC files are then attached in the Streets module.

- 1. Start a new Streets (*.xus) file and enter the conventional intersection demand.
 - a. Note: The demand entered now will automatically be redistributed to the MUT intersection after conversion.
- 2. Go to the Alternative group box which is found in the Detailed Input Data. Check the Alternative Intersection box.

Interchanges and Alterna Interchanges Interchange Intersection	itive Intersections		Alternative	
Interchange Type	Diamond	Ŧ		
EDTT	Data		Intersection Type	-

- 3. The Intersection Type dropdown will now become editable. Select MUT with TWSC and click Yes on the confirmation pop-up message.
- 4. Return to the Alternative group box to attach the upstream and downstream stop-controlled intersection files, which are created in the TWSC module.

Interchanges		Alternative		Segment		
Interchange Intersection		 Alternative Intersection			Segment 1	Segment 2
Interchange Type	Diamond				ooginonii 1	oognon z
		Intersection Type	MUT with TW ·	Free-Flow Speed, mph	50.0	50.0
EDTT	Data			Length ft	000	000
	50.57 (S. 1	Upstream	Downstream	Conger, re	800	800

a. If these files have not been created, open the TWSC module and code the upstream/downstream crossovers. *Note: TWSC crossover junctions should only have major street through lanes and a single major street U-Turn coded. Streets will not accept files*

coded differently. The image below presents a sample downstream crossover configuration for an East-West arterial with an EB forward direction specified in Streets. Keep in mind that the upstream/downstream TWSC files created should be relative to the forward direction specified in Streets.



- b. Enter the redistributed volume for the movements at the crossover. *Note: The crossover* volume distribution must be determined manually. *Neither TWSC nor Streets automatically* redistributes conventional demand in the crossover files. See Example Problem 15 in Chapter 34 of the HCM for reference.
- c. Once all input data has been coded in the two crossover junctions and the files have been saved, return to the Streets module.
- 5. Navigate back to the Alternative group box and use the Upstream/Downstream buttons to attach the respective TWSC (.xtw) files. A confirmation message with inputs and results from the crossover file will appear if the file was opened successfully.

terchanges	Alternative	Segment		
terchange Intersection	Alternative Intersection		Segment 1	Segment 2
terchange Type	Intersection Type MUT with TW *	Free-Flow Speed, mph	50.0	50.0
EDTT Data		Length, ft	800	800

6. In the Segment group box, edit the Free-Flow Speed and Length fields as appropriate. *Note: EDTT is calculated using these inputs.*

Interchanges and Alternative Intersections		
Interchanges	Alternative	Segment
Interchange Intersection	Alternative Intersection	Segment 1 Segment 2
Interchange Type Diamond *	Intersection Type MUT with TW -	Free-Flow Speed, mph 50.0 50.0
EDTT Data	Upstream Downstream	Length, ft 800 800

7. To view results, go to the Reports dropdown in the top menu and select Alternative Intersections Report. *Note: The Alternative Intersections Report only becomes accessible after at least one TWSC crossover file has been attached using the Upstream/Downstream buttons.*



Steps to Build a Partial DLT

To conduct a partial DLT analysis, one Streets (*.xus) file is needed. This file will then be converted to a DLT composed of three intersections: an upstream crossover, a main intersection, and a downstream crossover.

- 1. Start a new Streets (*.xus) file. This will serve as the conventional intersection file. Enter the conventional intersection demand and any desired universal inputs such as the peak hour factor, % heavy vehicles, speed limit, and timing data.
 - a. The universal inputs will be copied over to the three intersections generated by converting the conventional file to DLT.
 - b. The demand input will be redistributed to the three intersections generated by converting the conventional file to DLT.
- 2. Go to the Alternative group box which is found in the Detailed Input Data. Check the Alternative Intersection box.

Interchanges and Alternation Interchanges Interchange Intersection	ve Intersections		Alternative	_
Interchange Type	Diamond	-		
EDTT	Data		Interaction Type	

- 3. The Intersection Type dropdown will now become editable. Select DLT and click Yes on the confirmation pop-up message.
- 4. The file is now of type DLT.
 - a. Note: After converting the conventional intersection to a partial DLT alternative intersection with a set of three intersections, there may be an error generated by Streets. It is due to the existing data in the conventional file that causes a phase split summation

error after conversion. This can be easily corrected by adjusting the phase split values at Intersection Two. Intersections One and Three may also show errors due to a refreshing issue. Navigating to the upstream and downstream intersection once, or twice in some cases, will eliminate those errors.

- b. Note: Offsets at the upstream and downstream intersections are disabled. This is by definition. The DLT procedure automatically calculates offsets at the supplemental intersections based on free-flow travel times, phase durations, reference phases, reference points, and the background cycle length.
- 5. To view the results, go to the Reports dropdown in the top menu and select Alternative Intersections Report.



How To

Create a New File

1. There are four options for creating a new file:

a. Selecting the New tab in the initial window when first opening the Streets program and selecting the mode to create a new dataset



b. Selecting *File > New* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar and then selecting "New"



- c. Using the keyboard shortcut "Ctrl+N" for New
- d. Selecting the New icon in the toolbar; this can be found in the top left-hand corner of the screen in the toolbar; it is the first icon from the left and has an image of a blank paper



 Once a new file is created, a Quick Start window will appear allowing you to specify general inputs for the new file; these inputs can be changed after the file is created. When finished changing any of the necessary defaults, select OK.

Default Selections						
Number of Intersections	1 ≑	Cycle Length, s	120			
Forward Direction	EB 🗸	Minimum Green, s	6			
Number of Periods	1 😫	Yellow Change, s	4.0			
Analysis Duration, h	0.250	Red Clearance, s	0.0			
Base Saturation Flow, pcphpl	1900	Passage Time, s	2.0			
Speed Limit, mi/h	35	Detector Length, ft	40			
Units	O Metric Units					
Template Help 🕜			Select Template			

3. A Forward Direction dialog box will appear confirming if you want to proceed with the Forward Direction you selected. Select 'Yes' if you want to proceed or 'No' if you do not want to proceed. This message can be hidden in the future when creating new files if the 'Do not show this again' checkbox is checked.



- a. Selecting 'Yes' will create a new file with the inputs specified in the Quick Start dialog box.
- b. Selecting 'No' will bring you back to the Quick Start dialog box to make any changes.
- 4. A new file will be created and you will be brought to whichever mode was last used if not specified using the first option.

Open an Existing File

- 1. There are six options for opening an existing file:
 - a. Selecting the Open tab in the initial window when first opening the Streets program and selecting a file from either the 'EXAMPLE FILES' list or 'RECENT FILES' list, or by clicking the 'Browse' button and selecting a file in the Open dialog box.

HCS Streets V	ersion 2024 X
Open	New
 EXAMPLE FILES Interchanges1-Diamond.xus Interchanges2-ParcloA2Q.xus Interchanges3-DiamondWithQueueSpillba Interchanges4-DiamondWithDemandStare Interchanges5-DivergingDiamondWithSig Interchanges7-SPUI.xus Interchanges8-DiamondWithAdjacentInte Signals1-MotorizedVehicle.xus Signals2-Pedestrian.xus Streets1-MotorizedVehicle.xus Streets3-Bicycle.xus Streets4-Transit.xus Streets4-Transit.xus RECENT FILES 	ack.xus vation.xus nalControl.xus rsection.xus
	Browse Open

b. Selecting *File > Open* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar and then selecting "Open"

11.	ICS Streets	5		
File	View	Edit Wi	ndows	Help
ß	New	Ctrl+N	_	‡ 🛌 📑 🖻 🕚
8	Open	Ctrl+O		
	Example	Folder	_	
	Close		_	
B	Save As	Ctrl+S		
	Daint	Chrl. D	_	
8	Print Pre	view		
-	Import	867.09		
	CSV Imp	ort Wizard		
	Export			
	CORSIM		•	
	Frit		-	
-	LAIL		_	

- c. Using the keyboard shortcut "Ctrl+O" for Open
- d. Selecting the Open icon in the toolbar; this can be found in the top left-hand corner of the screen in the toolbar; it is the second icon from the left and has an image of an open folder with an arrow



e. Selecting *File > Example Folder* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar and then selecting "Example Folder". Opening the example folder will open the path of the HCS example files in File Explorer. The desired example file can be double-clicked or right-clicked and selecting 'Open', which will open the example file in the Streets program.

III F	ICS Streets	
File	View Edit V	Vindow
B	New Ctrl+	N
8	Open Ctrl+ Example Folder	υ
	Close	
	Close	c
B	Save As	5
-	Print Ctrl+	p
	Print Preview	
	Import	+
	CSV Import Wizard	
	Export	×
	CORSIM	÷
	Exit	

f. Selecting *File* > *Recent Files* > **.xus* from the main meu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar, hovering over "Recent Files", and then selecting the desired Streets file.

View Edit Wie	dows	Help			
New Ctrl+N Open Ctrl+O Example Folder	luows		_	-	
Recent Files	•	C:\Program Files (x86)\McTrans\HCS\Example\Signals1-MotorizedVehicle.xus			
Close		C:\Program Files (x86)\McTrans\HCS\Example\Interchanges1-Diamond.xus			
Save Ctrl+S Save As		C:\Program Files (x86)\McTrans\HCS\Example\Streets1-MotorizedVehicle.xus			
Print Ctrl+P Print Preview					
Import CSV Import Wizard	+				
Export	\rightarrow				
CORSIM	+				
Exit					
	New Ctrl+N Open Ctrl+O Example Folder Recent Files Close Save Ctrl+S Save As Print Ctrl+P Print Preview Import CSV Import Wizard Export CORSIM Exit	New Ctrl+N Open Ctrl+O Example Folder Recent Files ▶ Close Save Ctrl+S Save As Print Ctrl+P Print Preview Import ▶ CSV Import Wizard ▶ Export ▶ CORSIM ▶	New Ctrl+N Open Ctrl+O Example Folder Recent Files C:\Program Files (x86)\McTrans\HCS\Example\Signals1-MotorizedVehicle.xus Close C:\Program Files (x86)\McTrans\HCS\Example\Interchanges1-Diamond.xus C:\Program Files (x86)\McTrans\HCS\Example\Streets1-MotorizedVehicle.xus Save As Print Ctrl+P Print Preview Import CORSIM Exit	New Ctrl+N Open Ctrl+O Example Folder Recent Files C:\Program Files (x86)\McTrans\HCS\Example\Signals1-MotorizedVehicle.xus Close C:\Program Files (x86)\McTrans\HCS\Example\Interchanges1-Diamond.xus C:\Program Files (x86)\McTrans\HCS\Example\Streets1-MotorizedVehicle.xus Save As Print Ctrl+P Print Preview Import CORSIM CCNRSIM Exit	New Ctrl+N Open Ctrl+O Example Folder Recent Files C:\Program Files (x86)\McTrans\HCS\Example\Signals1-MotorizedVehicle.xus Close C:\Program Files (x86)\McTrans\HCS\Example\Interchanges1-Diamond.xus C:\Program Files (x86)\McTrans\HCS\Example\Streets1-MotorizedVehicle.xus Save As Print Ctrl+P Print Preview Import CORSIM CCNSIM Exit

2. Once an existing file is opened, you will be brought to whichever mode was last used.

Save a File

1. There are five options for saving an open file:

a. Selecting *File > Save* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar and then selecting "Save'



b. Selecting *File > Save As* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar and then selecting "Save As"

N	New Ctrl+N		2	B B	0	Inters	ection:	1>			-	+ -	- Star	Time: 7:00	Period:	1> 7:00	- +	- Segn	ent:	1 .	0 -							
E	xample Folder																	^			HCS	Signali	ized In	nters	ectic	on Res	ults	Sur
R	Recent Files	•							J	4 1.4	. 1 5	iu i		Phasing				_		General Inform	ation						Inte	ersei
C	lose		-														·	_		Agency							Dur	ratio
										* 1	4		_	Cycle, s	Ľ	20				Analyst		An	alysis D	Jate 8/	15/20	22	Arei	:8 1
Si Si	iave Ctrl+S							-					۰.	Pre-Time	Signal		 Image: A start of the start of			Jurisdiction		Tir	me Perio	bt.	0.00	_	PHF	Ę.
S	ave As							4					A.		6			1		Internection		An	la Name	ear 20	JZZ	No.	Ana	sy:
		_					_		~				- 2	Uttset, s	2					Project Descript	tion		- Harris		o cecari			-
P	Print Ctrl+P		Area T	ype	Othe	r	-	2	*				순	Phase 2	Virection	EB 🔹	,				100							
B P	rint Preview				0.26/				*					Phase 4	Inaction	- 93	_	·		Demand Inform	nation		E	B	_	_	WB	_
• :	inter retreat		Duratio	in	0.23	/		-						11036 4	Arection .			5		Approach Move	ment	_	L .	T	R	L	T	-
In	mport		PHF		0.92					-		-		Reference	Phase	•		Se		Demand (V), V	enn				0	0	0	÷
C	SV Import Wizard		0	+ CAN	0		_			1				Reference	Point I	nd •	Phasi	ng Lin		Signal Informa	tion			5				Г
ĩ			Prop. c	II CAV	0				٦	414	1 1	1		Course Ma			Wiza	rd Oil		Cycle, s	120.0 Reference Phase	2	8					L
ь	xport	•												Force Mc	le i	nxed •		He		Offset, s	0 Reference Point	End Gr	een 11	0.0 0	0.0	0.0	0.0	0
0	ORSIM		COT		LLUDI	MIDT	MIDD	NIDI	NOT	NIDO	CDI	COT	000	Phase D	ration					Uncoordinated	No Simult Gap E/W	On Ye	sllow 4.0	0 0	0.0	0.0	0.0	10
-	ONDIN	· ·	EBI	EBH	WBL	WBI	WBR	NBL	NBI	NBH	SBL	281	SBR			1	1			Porce Mode	Poted Sindic Capite's	On TRe			.0	0.0	1.0	ľ
E	xit		0	0	0	0	0	0	0	0	0	0	0		i i i	=				Timer Results	5		EBL	EB	т	WBL	W	вт
ane W	/idth.ft	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0		⇒				1	Assigned Phase	2		5	2		1	6	3
	I smath A	0	0	0	0	0	0	0	0	0	0	0	0	0	110.0	0.0	0.0	0.0	-	Case Number			2.0	3.0		2.0	3.0	.0
orage	bengui, it	<u> </u>	-	v	<u> </u>	<u> </u>	<u> </u>	-	Green	110.0	0.0	0.0	0.0	¢	Phase Duration	.5	_	0.0	120.	0	0.0	120	2.0					
ase Sa	aturation, pc/h/ln	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	Tellow	4.0	0.0	0.0	0.0		Max Allow Heat	(PHR +), a		0.0	4.0	, I	4.0		-
avy \	Vehicles, %	0	0	0	0	0	0	0	0	0	0	0	0	Red	0.0	0.0	0.0	0.0		Queue Clearan	ce Time (g z), s		0.0	0.0	-	0.0	-	~
ada .	47		0			0			0	1		0	1	250230						Green Extensio	n Time (g .), s		0.0	0.0	,	0.0	0.4	0
aue,	7a				1	V	-	1	0		1	0	-	Timing						Phase Call Prol	pability							
uses, p	perh			0			0			0			0		E	BL EBT	WBL	WBT		Max Out Probal	olity				_	_		
arking.	, per h	0	N -	0	0	N *	0	0	N -	0	0	N -	0	Assigned F	nase (5) (2)	(1)	(6)		Movement Gro	up Results		E	в			NB	-
-	e nerh		0			0	1		0	1		0	1	Phone Sold			00.0	1000		Approach Move	ment		LT	r r	R	L	T	R
- June	a, per m		0			-	1		0	1		-	-	Thase Spir	° 20.	50.0	20.0	50.0		Assigned Move	ment		5 2	2 1	12	1	8	16
edestri	ians, per h		0			0			0			0		Yellow Cha	nge.s 4.0	4.0	4.0	4.0		Adjusted Flow F	Rate (v), veh/h		0 0) (0	0	0	0
rival T	Type	3	3	3	3	3	3	3	3	3	3	3	3	Red Cleara	ce.s no	0.0	0.0	0.0		Adjusted Satura	soon ⊨idw Rate (a), veh/h/in		0 19	00 16	010	0 1	1 000	101
netro a	m Eltering (I)	L.	FR	1.00	L	WR	1.00	L	NR	1.00		SR	1.00	11	0.0		0.0	0.0		Cycle Queue C	lime (gr), s learance Time (g,) s		1 0	0 0	10	0.1 0	10	0.0
- Ca	an									L		10		Minimum G	een,s 6	6	6	6		Green Ratio (g	(C)	-	0.6	97 0.	97		97 0	0.9
tial Qu	ueue, veh	0	0	0	0	0	0	0	0	0	0	0	0	Lag Phase		EL 🗌 ET	WL	WT		Capacity (c), v	eh/h		0 183	37 15	556	0 1	337 1	155
			25			35	1		35	1		35	1	Deres T					1									

- c. Using the keyboard shortcut "Ctrl+S" for Save
- d. Selecting the Save icon in the toolbar; this can be found in the top left-hand corner of the screen in the toolbar; it is the third icon from the left and has an image of a floppy disk



e. Exiting the program or closing the file without saving changes beforehand; this will prompt you to save changes to the file before anything is closed



- i. Selecting "Yes" will save the file if it is an existing file. If the file has not been previously saved, the Save As dialog box will pop up allowing you to change the file name and save it.
- ii. Selecting "No" will exit the program or close the file without saving the file
- iii. Selecting "Cancel" will prevent the file from closing

Note: Using Save with an existing file will save a file without prompting you to specify a file name. Using Save with a new file will bring up the Save As dialog box for you to specify a file name for saving. Using Save As will always bring up the Save As dialog box for you to specify a file name for saving.

Close a File

- 1. There are four options for closing a file:
 - a. Selecting *File* > *Close* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar and then selecting "Close"



b. Selecting *Windows* > *Close All* from the main menu; this can be found by selecting "Windows" in the top left-hand corner of the screen above the toolbar and then selecting

"Close All"

File View Edit Wi	ndows Reports He	elp						-
	New Window		+ + -	Start Time: 7:00 Peri	iod: 1> 7:00 • + -	- Segment: 1 • 🕜 •		
n Mode Mauel Made	Cascade							
visual Mode	Tile Vertical					HCS	Signalized Intersection [Results Sum
RIMARY INPUT DAT	The University						- 5	
neral	The Horizontal		144444	Phasing		General Information		Interse
	Close All					Agency		Duratio
an Street				Cycle, s	100	Analyst	Analysis Date Nov 30, 202	1 Area Ty
rsection	1 Streets1-Motorized	/ehicle.xus	*	Pre-Timed Signal		Jurisdiction	Time Period	PHF
	2 Interchanges1-Diam	nond.xus	- × ×	*		1 Urban Street	Analysis Year 2021	Analysi
cription U	2 Signals 1-Motorized	Vehicle xur	N A	2- Offset, s	0	Project Description Chapter 20: Evanole	Prie Name Streets I-Mo	torized vehicle.
ward Direction Eb-	o Signals I-INIOCOTIZED	veniciexus		Phase 2 Direction	n EB 🔹 🖕	· · · · · · · · · · · · · · · · · · ·		
1000				-		Demand Information	EB	WB
ment Length, ft 1800	Duration 0.23	50	7	Phase 4 Direction	n 58 •	5 Approach Movement	LTRL	TR
All Segment Lengths	PHF 1.00	0	·	Reference Phase	- 2 -	Demand (v), veh/h	200 1000 10 20) 1000 10
			ግ ተ የ	Reference Point	End . Phasing	Signal Information		
	Prop. of CAV 0		5 + + + + + + + A	Therefore Fork	Wizard	Un Cycle, s 100.0 Reference Phase	2 1 1 2 4	• · · · ·
				Force Mode	Fixed *	Fie Offset, s 0 Reference Point I	End Gross 12.0 0.2 49	81 19
ffic and Geometry						Uncoordinated No Simult. Gap E/W	On Yellow 3.0 0.0 4.0	3.0 4.0
	EBL EBT EBR WB	L WBT WBR	NBL NBT NBR SBL SBT	SBR Phase Duration		Force Mode Fixed Simult. Gap N/S	On Red 0.0 0.0 0.0	0.0 0.0
mand web/b	200 1000 10 200	1000 10	100 500 50 100 500	0	<u>5</u>			
						Timer Results	EBL EBI W	JL WBI
e Width, ft	12.0 12.0 12.0 12.0	12.0 12.0	12.0 12.0 12.0 12.0 12.0	2.0	- i - i	, Assigned Frase	20 20 2	0 20
rage Length, ft	200 999 200 200	1800 200	200 999 1000 200 999	000 Green 12.9	0.2 48.7	6.1 Phase Duration a	18.1 52.9 14	9 527
Catalantin and the	1000 1000 1000 100	0 1900 1900	1900 1900 1900 1900 1900	ono Yellow 30	0.0 4.0	3.0 Change Period. (Y+R+) s	3.0 4.0 3	0 4.0
e saturation, pc/n/in	1300 1300 1300 130	0 1300 1300	1300 1300 1300 1300 1300	500 P. L. 0.0	0.0 4.0	Max Allow Headway (MAH), s	3.1 0.0 3	1 0.0
avy Vehicles, %	0 0 0	0 0	0 0 0 0	Hed U.U	0.0 0.0	0.0 Queue Clearance Time (g +), s	12.8 12	.6
de %	0	0	0 0			Green Extension Time (g .), s	0.3 0.0 0	3 0.0
	-	-		Timing		Phase Call Probability	1.00 1.0	10
es, per h	0	0	U		EBL EBT WBL	WBT Max Out Probability	0.00 0.1	0
king, per h	0 N = 0 0	N - 0	0 N - 0 0 N -	Assigned Phase	(5) (2) (1)	(6) Movement Group Results	EB	WB
olos por b	0	0	0	Dhave Calk		Approach Movement	LTRL	TR
roles, per tr	•	<u> </u>		Fridae Spill, a	20.0 35.0 20.0	35.0 Assigned Movement	5 2 12 1	6 16
lestrians, per h	0	0	0 0	Yellow Change, s	3.0 4.0 3.0	4.0 Adjusted Flow Rate (v), veh/h	200 1000 10 194	968 10
val Type	3 4 3 3	4 3	3 3 3 3 3	Red Clearance e		Adjusted Saturation Flow Rate (a), veh/h/in	1810 1900 1610 1810	1900 1610
	100	0.82	100	an a	0.0 0.0 0.0	U.U Queue Service Time (g .), s	10.8 14.1 0.3 10.6	17.4 0.3
stream Hitering (I)	I-EB 1.00	I-W/B 0.62	I-NB I-SB	Minimum Green, s	5 5 5	5 Cycle Queue Clearance Time (g =), s	10.8 14.1 0.3 10.6	17.4 0.3
al Queue, web	0 0 0 0	0 0	0 0 0 0 0	Lag Phase		Green Kato (gC)	237 1857 787 233	1840 784

- i. "Windows" is the fourth menu item from the left
- ii. Selecting "Close All" will close all open files
- c. Selecting "x" in the top right-hand corner of the file window; this can be found below in the red boxes

Classe Mode Vecue Mode Control	Signals1-MotorizedVehicle.xus			
Traffic and Geometry EBL EBT EBR WBL WBT VBR NBT NBT SBL SST	Classic Mode Venuel Mode PRIMARY INPUT DATA General Uton Street Interaction Description Forward Direction EB Segment Length, # 1900 Al Segment Lengths Traffic and Geometry E Demand, veh/h 20 Lane Width, ft 172 Lane Width, ft 20 C	0. Example Problem 1 • Area Type Other Duation 0.250 PH 100 Pro, of CAV 0 BL< EBR WEL VED 220 120 100 0000 100 100 0000 100 100 0000 100 100 200 120 100 120 120 120 120 120 120 120 120 120 120 120 120 120 120 120 120 120 120 120 120	Phasing Cycle. s Pro: Timed Signal 0 Offset. s Phase 2 Direction EB Reference Pairs 2 Reference Pairs 2 Reference Pairs 2 Phase Duration Froe Mode Phase Duration Froe Mode Phase Duration Froe Mode Reference Pairs 2 Reference Pai	HCS SI

d. Exiting the program itself; please see How To: Exit the Program

Exit the Program

1. There are three options for exiting the program:

a. Selecting *File* > *Exit* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar and then selecting "Exit"

H	ICS Streets			
File	View Edit Win	dows Help		
B	New Ctrl+N	H 🖢 健 🗉 O		
D	Open Ctrl+O			
	Example Folder			
	Recent Files	•		
	Close			
B	Save Ctrl+S			
	Save As			
8	Print Ctrl+P			
B	Print Preview			
	Import	•		
	CSV Import Wizard			
	Export	•		
	CORSIM	→		
	Exit			
_				

- b. Using the keyboard shortcut "Alt+F4" for Exit
- c. Selecting "X" in the top right-hand corner of the screen; this can be found below in the red box



Change the Mode

1. There are two main mode options: Classic and Visual

a. Classic Mode: provides a split screen of all inputs with a results report located either to the right of the inputs or below the inputs; the inputs are sectioned off into PRIMARY INPUT DATA, DETAILED INPUT DATA, and MULTIMODAL INPUT DATA



b. Visual Mode: provides a split screen of a map of the intersection(s) and segment(s) with a results report located either to the right of the map or below the map; the inputs can be accessed by either double clicking the intersection nodes or segment lines within the map or by right clicking them and selecting Edit from the menu. *Note: Please see the Visual Mode section for more details.*



2. To change between modes, there are four options:

a. Selecting the desired mode when creating a New file on the initial start of the Streets program



b. Selecting the desired mode by selecting one of the tabs at the top left-hand corner of the screen when a file is open



c. Selecting *View > Classic / Visual Mode* from the main menu; this can be found by selecting "View" in the top left-hand corner of the screen above the toolbar and then

ic Mo	Status bar							_											-
PRIM	the second second second second											_	1100 01	Pasad					6
	startup screen										^		nus sigr	nalized	Inter	secu	on Re	suits	Sur
-energ	Reports		•	UNATE	shi li ka	11	Phasing					General Inform	ation					lin	terse
	Classic / Wanted Marks				I I		Thomas					Agency						D	uratio
Jrban	Classic / Visual Mode			× .	+ 5		Cycle, s	1	20			Analyst		Analysi	s Date	8/15/2	022	Ar	ea T
terse	Primary Data			1		N	Day Target	Cinnal				Jurisdiction		Time Pe	eriod			P	HF
	Detailed Data	F6		4		4	Fie-Timeu	Signal				Urban Street		Analysi	s Year	2022	_	Ar	nalys
lescri		513		→ [*]		×_)-	Offset, s	C			-	Intersection		File Nat	me	Streets	1.xus		_
0.000	Interchanges Data	FIZ		$\Rightarrow \rightarrow$		< ÷	Phase 2 D	inaction F	R •	10443		Project Descrip	ton						-
orwai	Multimodal Data	F7				¥—+	Thuse 2 G	iceboii i				Demand Infor	nation		EB	_		WB	_
egme			-	*		*	Phase 4 D	irection S	в •	-	5	Approach Mow	ement	L	T	R	L	т	
	Quick Lanes	F8				e	Reference	Phase 2	-	-		Demand (v), v	eh/h	0	0	0	0	0	
	Quick Phases	F9		5	5.4						Sic	Clauselinder	No.						-
	Reporte Danel	E11					Heterence	Point B	nd •	Wizard	Un	Cycle s	120.0 Reference Phase 2	1 1	_ ≈				
	Reports Parler			1.5.1	-47 T P		Force Mod	le F	ixed -	THEORY	Fie	Offset a	0 Reference Point End		7				4.
raffic	Information	Ctrl+I										Uncoordinated	No Simult Gap E/W On	Vellow	4.0	0.0	0.0	0.0	-6
	Auto Coloulate	Chill Children A	BT WBR	NBL NBT NBF	R SBL	SBT SBR	Phase Du	ation			-	Force Mode	Fixed Simult Gap N/S On	Red	0.0	0.0	0.0	0.0	Ō
00000	Auto-Calculate	Ctri+Shirt+A		0 0 0	0	0 0		5	-										
ernar	Force Calculations	Ctrl+Shift+R	-			0 0		L. *				Timer Results		EBL	E	BT	WBL	V	WBT
ane V 🛛	0.114.1.11	C1 1 1 10 1	.0 12.0	12.0 12.0 12.0	12.0	12.0 12.0		F 4				Assigned Phas	e	20	-	2	20	-	8
torag	Quick Animation	Ctrl+Shift+L	0	0 0 0	0	0 0	Green	116.0	0.0	0.0	0.0	Bhare Duration		2.0	12	20.0	2.0		3.0
	Quick Optimization	Ctrl+Shift+O	00 1900	1900 1900 190	0 1900	1900 1900	Yellow	4.0	0.0	0.0	0.0	Change Period	(Y+R)) s	4.0	4	1.0	4.0	1	4.0
lase 3	Full Ontimization	Ctrl+Shift+E	00 1300	1300 1300 130	0 1300	1300 1300	Ded	0.0	0.0	0.0	0.0	Max Allow Hea	dway (MAH), s	0.0	0	0.0	0.0	1	0.0
leavy		curr shine r	0	0 0 0	0	0 0	Red	0.0	0.0	0.0	10.0	Queue Clearan	ce Time (g ;), s						
irade	Time-Space Diagram	Ctrl+Shift+1		0		0						Green Extensio	n Time (g.), s	0.0	0	0.0	0.0	1	0.0
	Flow Profile Diagram	Ctrl+Shift+P		0	-		Timing					Phase Call Pro	bability			_		_	
suses),				U		U		E	IL EBT	WBL	WBT	Max Out Proba	bilty			_			-
arking, per h	0 N	• 0 0	N • 0	0 N • 0	0	N 🕶 0	Assigned Ph	ase (!) (2)	(1)	(6)	Movement Gro	oup Results		EB			WB	
icucles nerb	0		0	0		0	Phase Cole		50.0	00.0	0.00	Approach Mov	sment	L	Т	R	L	T	R
noyoice, peri		_	-	-		-	Theory Spin,	° 20.	0.00	20.0	0.00	Assigned Move	ment	5	2	12	1	6	16
edestrians, p	verh U		0	U		U	Yellow Char	ge.s 4.0	4.0	4.0	4.0	Adjusted Flow	Rate (v), veh/h	0	0	0	0	0	0
inival Type	3 3	3 3	3 3	3 3 3	3	3 3	Red Clearar	ce.s no	0.0	0.0	0.0	Adjusted Satur	ation Flow Rate (s), veh/h/in	0	1900	1610	0	1900	161
Instance Cha	(I) I ED	1.00 1.1	/P 1.00	LNR 100		P 100		0.0	0.0	0.0	0.0	Queue Service	Time (g,), s	0.1	0.0	0.0	0.1	0.0	0.0
pstream nite	ang (i)	1.00	/B 1.00	PIND		1.00	Minimum Gr	sen, s 6	6	6	6	Green Ratio ((c)	9.1	0.07	0.07	0.1	0.07	0.0
nitial Queue, r	veh 0 0	0 0	0 0	0 0	0	0 0	Lag Phase		L ET	U WL	WT	Capacity (c),	eh/h	0	1837	1558	0	1837	155
n fimil been	ni/h 35		35	35		35	Passage To					<							_
				-2			rassage IIr	ie, a 2.0	12.0	12.0	2.0			1					

selecting "Classic / Visual Mode"; "View" is the second menu item from the left

d. Using the keyboard shortcut F5 to switch between the two modes

Run Animation

1. There is one option for running animation: CORSIM



 Course (16959, 21014)
 Zoom Factor 1.65
 Screen Origin (14786, 17395)
 Bitmap Origin (0, 0)
 Time Period #1

 Note: Please see CORSIM under the Advanced Features section for more details.

2. There are four options for running animation through Streets:

- HCS Streets [Streets1-MotorizedVehicle.xus] σ × - @ x 🗅 🗁 🖹 🔒 💽 🎟 ඊ 🖨 🦕 📳 🕼 Intersection: 1> • + - | Start Time: 7:00 Period: 1> 7:00 • + - | Segment: 1 - 0-Assic Mode Visual Mode Quick Animation HCS Signalized Intersection Results Sumn General Intersection Duration, In Area Type PHF Analysis Date Nov 30, 2021 Time Period Urban Street Cycle, s 100 Intersection Pre-Timed Signal Analysis Year 2021 File Name Stree 0 Chapter 30: Example Problem 1 e1.Moto Offset, s ÷, Forward Direction EB Area Type Other Phase 2 Direction EB • Segment Length, ft 1800 Duration 0.250 Phase 4 Direction SB L T R L T R 200 1000 10 200 1000 10 2 1.00 Reference Phase • PHF All Segment Lengths 48.7 End Prop. of CAV Reference Point Phasing Force Mode Eved Refe Traffic and Geo Phase Du EBL EBT EBR WBL WBT WBR NBL NBT NBR SBL SBT SBR
 200
 1000
 10
 200
 1000
 10
 500
 50

 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 12.0
 Demand, veh/h Lane Width, ft 100 500 50 5 ¥ 12.0 12.0 12.0 1000 200 999 ⇉ Storage Length, ft Base Saturation, pc/h/h 200 999 200 200 1800 200 200 999 48 Green Yellow Red 12.9 Y+R :). 5 0 0 0 3.1 12.6 0.3 1.00 0.00 Heavy Vehicles, % 0 0 0 0 0 0 0 0 0 3.1 Grade, % Timing Buses, per h EBL (5) EBT WR WR Parking, per h 0 N • 0 (2) (1) (6) Assigned Phase 0
 0
 3 20.0 35.0 20.0 35.0 s 3.0 4.0 3.0 4.0 L T R 5 2 12 Bicycles, per h 0 0 0 Phase Split, s Yellow Change, s Pedestrians, per (v), veh/h Flow Rate (s), veh/h/in 0 0 0 3 4 3 4 3 3 3 3 3 HEB 1.00 HWB 0.82 HNB 1.00 3 sted Satu Arrival Type
 Red Clearance, s
 0.0
 0.0

 Minimum Green, s
 5
 5

 Lag Phase
 EL
 ET
 0.0 îme (g≠), s sarance Time (g∈), s
 10.8
 14.1

 10.8
 14.1

 0.13
 0.49

 237
 1857
 Queue Service Cycle Queue Cl Upstream Filtering (I) I-SB 1.00 5 5 0 0 0 35 Green Ratio (g/C) Capacity (c), veh/t Initial Queue, veh 0 WT 00 20 Speed Limit, mi/h Passage Time, s 20 00 P
- Selecting the Quick Animation button from the toolbar a.

b. Selecting File > CORSIM > View Animation from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar, hovering over "CORSIM", and then selecting "View Animation"



Selecting View > Quick Animation from the main menu; this can be found by selecting C. "View in the top left-hand corner of the screen above the toolbar and then selecting

	Edla Mindaura	Demoste II-																	
The Vie	w Edit windows	Reports He	P															-	-
ð 🚺 🖌	Toolbar		ersectio	n: 1>			+ -	Start	Time: 7:00	Period:	1> 7:00	- +	- Segme	ent: 1 🔹 🕜 •					
	Status Bar		_	_		_	-	-											-
: Mo	Startup Crean														a allowed look		les Deer	14 - C	_
RIM	startup screen												^	HCS SIG	nalized int	ersect	ion Rest	its su	n
	Reports		•		internet.		100		Disaster					General Information				Interne	
enera	a				140	44 4 44			Phasing					Agency				Duratio	0
ban	Classic / Visual Mode	FD				τų.			Cycle, a	10	00			Analyst	Analysis Dar	e Nov 3	0.2021	Area Ty	, in
	Primary Data			100			1	100			_			Jurisdiction	Time Period			PHF	î
erse	Detailed Data	56						2	Pre-Timed	Signal		ĸ		Urban Street	Analysis Yez	ar 2021		Analysi	ŝ
scrip	Detailed Data	10			*		×-	- 20	Offset, s	0			1	Intersection	File Name	Street	s1-Motorize	Vehicle.	x
	Interchanges Data	F12		-6	•	N	+	- Å		_				Project Description Chapter 30: Example Pro	slem 1			_	
war	Multimodal Data	F7		-	•		+	-	Phase 2 L	irection E	8 *	7		Demand Information	50			-	đ
me				7	*		*	*	Phase 4 D	irection S	B 🕶	-		Approach Movement	T	P		r P	ł
	Quick Lanes	F8		-				£	Deferre	D		_	-	Demand (v), veh/h	200 100	0 10	200 1	00 10	õ
	Quick Phases	FQ		_	K				Helefence	ridae 2	•		Sic	And the second se	distant in the local distance of the local d			and the second	l
	Quick i Hoses					<u> 1 r</u>			Reference	Point E	nd 🔹	Phasin	Un	Signal Information	1	- 2	5	572	Å
_	Reports Panel	F11			141	****	1		Forme Mor	6 B	vad v	Wizan	1	Cycle, s 100.0 Reference Phase 2	- F'	R	3	5 5	5
ffic	Information	Ctrl+I							TOICE MOI	e 11	Xeu .		- He	Offset, s 0 Reference Point End	Green 12.9	0.2	48.7 6	1 18	
			DT ME			CDI	COT	CDD	Phase Du	ation				Encre Mode Eved Simult Gap N/S On	Yellow 3.0	0.0	4.0 3	3 4.0	ł
	Auto-Calculate	Ctrl+Shift+A		N INDL	IND I INDE	1 JDL	301	JDN		T	1				1100 0.0	10.0	0.0		Í
mar	Force Calculations	Ctrl+Shift+R	00 10	100	500 50	100	500	50		2.	_7		=	Timer Results	EBL	EBT	WBL	WBT	1
ne V			0 12	12.0	12.0 12.0	12.0	12.0	12.0		- e	\equiv	1		Assigned Phase	5	2	1	6	1
	Quick Animation	Ctrl+Shift+L	00 000	000	000 100	000	000	1000	-		3	-		Case Number	2.0	3.0	2.0	3.0	
rag	Quick Ontimization	Ctrl+Shift+O	200	200	333 100	200	999	1000	Green	12.9	0.2	48.7	6.1	Phase Duration, s	16.1	52.9	15.9	52.7	
se S	Quick optimization	Cur+Shirt+O	00 190	0 1900	1900 1900	1900	1900	1900	Yellow	3.0	0.0	4.0	3.0	Change Period, (Y+R c), s	3.0	4.0	3.0	4.0	1
-	Full Optimization	Ctrl+Shift+F	0	0	0 0	0	0	0	Red	0.0	0.0	0.0	0.0	Max Allow Headway (MAH), s	3.1	0.0	3.1	0.0	-
avy	Time-Space Diagram	Ctrl+Shift+T			· ·	U		0						Corea Estanda Time (gr.) s	12.0	0.0	12.0	0.0	
ade.	51 D (1 D)	G1 1 01 0 0			0		0		Timing					Bhase Call Probability	1.00	0.0	1.00	0.0	-
963	Flow Profile Diagram	Ctri+Shift+P	0		0			0	-	50		MIDI	MDT	Max Out Probability	0.00		0.00		
		0 0				0		0		CD	L CDI	WDL	WDI						8
nong, per	n v N	• 0 0	N + U	U	N • U	U	N T	U	Assigned Pr	hase (5) (2)	(1)	(6)	Movement Group Results	EB		W	3	
ycles, pe	rh 0		0		0		0		Phase Split	\$ 20.0	35.0	20.0	35.0	Approach Movement	LT	R	LT	R	_
destring		_	0		0		0			20.0	00.0	20.0		Assigned Movement	5 2	12	1 6	16	4
uestrians,	pern o		<u> </u>		<u> </u>		<u> </u>		Tellow Char	ige, s 3.0	4.0	3.0	4.0	Adjusted Flow Hate (V), venin	200 1000	10	194 90	5 10	-
ival Type	3 4	3 3	4 3	3	3 3	3	3	3	Red Clearan	nce, s 0.0	0.0	0.0	0.0	Adjusted Securation Flow Rate (2), Veninin	10.0 1000	0.2	1010 10	4 0.2	4
stream Fil	tering (I) I-FR	1.00	WR 0.8	2 14	IR 1.00		SB	1.00	Main or Co		-			Cycle Queue Clearance Time (g +) s	10.8 14.1	0.3	10.6 17	4 0.3	
	100							_	minimum Gr	5011,8	5	5	5	Green Ratio (g/C)	0.13 0.49	0.49	0.13 0.4	0 0.49	î
ial Queue	, veh 0 0	0 0	0 0	0	0 0	0	0	0	Lag Phase	□ E	L	WL	WT	Capacity (c), veh/h	237 1857	787	233 184	9 784	đ
			25		25		25					-		1	-			-	1

d. Using the keyboard shortcut Ctrl+Shift+L

Run Optimization

- 1. There are two main options for running optimization: Quick Optimization and Full Optimization
 - a. Quick Optimization; this is a one-touch export to TRANSYT-7F

÷	TRANSYT-	7F						—		×	<
File	e <mark>Ed</mark> it	View Ru	n Windo	w Option	s Help						
)	ビ 🛃 Тл	- 🚻 🔇	💿 🖊 d) 🗋 🖪	Output Q	uick Jum	•	Time P	eriod		+
Tř	tmp6F5A.t	tof								×	
ГI	NGS>									'	^
e	Total	Travel	l Time		De	alay					
t	Travel	Total	Avg	Uniform	n Random	Total	Average	Unit	Form		
	veh-mi	veh-h	sec/v		veh-h		sec/veh				
		-									
	0.00	5.63	36.9	5.36	0.27	5.63	36.9	481.9(88%)		
	0.00	0.64	23.1	0.63	0.01	0.64	23.1	77.6(78%)		
	0.00	5.63	36.9	5.36	0.27	5.63	36.9	481.9(88%)		
	0.00	0.64	23.1	0.63	0.01	0.64	23.1	77.6(78%)		
	0.00	7.11	25.6	6.47	0.64	7.11	25.6	763.3(76%)		
	0.00	2.54	45.7	2.21	0.33	2.54	45.7	182.9(91%)		
	0.00	0.05	17.1	0.05	0.00	0.05	17.1	5.6(56%)		
	341.13	13.68	49.3	3.42	0.46	3.88	14.0	806.1(81%)		
	68.23	4.91	88.4	2.72	0.23	2.95	53.1	150.3(75%)		
	3.41	0.11	39.5	0.01	0.00	0.01	4.2	3.6(36%)		
	412.77	40.95		26.87	2.22	29.09	28.2	3030.6(81%)	1	
										,	-
<			<i></i>							>	

Dual-R	ting Report	t (press	Ctrl-P to	print)							1
Node Nu	umber 1	•						System	n Cycle	100	Offset 0
Grn 13	49	5		19		2					
rel 3	4	3	4	4		e-	-		15		2052
Red 0	0	0	6	2					ો		
Grn 13	49	5		19				See. 1		i	
(el 3	4	3		4				₩.	5	<u>а</u>	
					2.55						512
ked ju	0	10	le		3						10.55
	Fasthou	nd		Westhou	Ind		Northbo	ind	4	Southbou	und
Le	eft Thru	Right	Left	Thru	Right	Left	Thru	Right	Left	Thru	Right
Pea	ak Adjusted	Volume	(vph)								
200	1000	10	200	1000	10	100	500	50	100	500	50
Sat	uration Flow	w Rate ((vphg)								
190	3800	1900	1900	3800	1900	1900	3800		1900	3800	
Que	eue Length	(veh)									
6.3	17.5	0.1	5.3	19.2	0.1	2.0	14.5		2.0	14.5	
Deg	gree of Satu	ration (S	%)								
81	54	1	81	54	1	38	77		38	77	
Cor	trol Delay	(sec/veh	1)					(Inters	ection D	elay = 2	9)
59	18	13	57	12	5	25	43		25	43	
	ANSYT Lev	el of Ser	vice					(TRAN	SYT No	de LOS	= C)
TR		В	E	В	A	С	D		С	D	
	В		-							-	Deserved
	B NSYT-7F Release	se 12.2				Co	pyright (c) 3	2022 Univer	sity of Flight	sa, Ali Rign	IS Neselveu
	B NSYT-7F Release Blyst	se 122				Co Date P	erforme	d	Nov 30,	2021	S Nese Yeu
TR/ E TRAI Ana Age	B NSYT-7F Release allyst ancy	se 122				Co Date P Analys	erforme is Time	d Period	Nov 30,	2021	
TR/ E TRA/ Ana Age Jun	B NSYT-7F Release alyst ency isdiction	se 12.2				Co Date P Analys	pyright (c) : Performe sis Time	d Period	Nov 30,	2021	
TRA TRAN Ana Age Jun Rur	<i>B</i> NSYT-7F Release allyst ency isdiction n Title	Run Ti	itle			Co Date P Analys	pyright (c) : Performe sis Time	d Period	Nov 30,	2021	

Note: Please see Quick Optimization under the Advanced Features section for more details.

b. Full Optimization; this is an HCM-based internal genetic algorithm

Optimization Include this Intersection in Optimization Objective Function Objective Function Cycle Length Percent Base FFS Cycle Length Dallas Phasing Offsets Offsets Optimization Status Diagnostic Messages Safety, Emission, Delay Values	Minimum Cycle, s Maximum Cycle, s Cycle Increment, s Master Intersection Forward Weighting, % Reverse Weighting, %	100 Number of Generations 100 Population Size 10 Crossover Probability, % 1 Mutation Probability, % 50 Convergence Threshold, % 50 Random Number Seed	20 10 30 1.0 5 0.010 7781	Start Info
---	---	---	--	---------------

Note: Please see *Full Optimization* under the *Advanced Features* section for more details.

- i. Inputs for optimization can be found under the Optimization section in the DETAILED INPUT DATA but can again be accessed in the Full Optimization window under Input Parameters
- ii. The Full Optimization window includes four drop down sections:

1. Input Parameters

Include this I Objective Fu Cycle Length Splits Offsets	nterseconction	tion in Optimization Delay & Safety & Em Phasing Sequence Dallas Phasing	Minimum Cycle, s Maximum Cycle, s Cycle Increment, s Master Intersection Forward Weighting, Reverse Weighting,	100 100 10 10 1 50 % 50	Number of Generations Population Size Crossover Probability, % Mutation Probability, % Convergence Threshold, % Random Number Seed	20 10 30 1.0 0.010 7781	
Optimizatio	n Sta	tus					Star

2. Optimization Status

(Delay & Safe	ty & Emission		
	Original	1.0		
	Optimum	1.0		
	Average	1.0		
		1 1%		
)	
	Run	Status)	
	Generation Number	2 out of 20		
	Generation Optimum	2		
	Total Time Elapsed	7 sec		
	•			
	Optimization in progres	ss	J	
			1	Sta
 O Diagnostic N ⊙ Safety, Emis 	<i>l</i> lessages ssion, Delay Values	Save	Cancel	 Infe Store
 O Diagnostic M O Safety, Emis 	Messages ssion, Delay Values	Save	Cancel	🔵 Inf
 > Diagnostic N > Safety, Emis 	Messages ssion, Delay Values > Messages	Save	Cancel	C Inf
 Diagnostic N Safety, Emis Diagnostic Diagnos	Messages ssion, Delay Values Messages on	Save	Cancel	
 Diagnostic I Safety, Emis Safet	Messages ssion, Delay Values > Messages on eters 1 Status	Save	Cancel	C Inf
 > Diagnostic N > Safety, Emis > Diagnostic N > Diagnostic N 	Messages ssion, Delay Values C Messages on leters 1 Status Aessages	Save	Cancel	
 Diagnostic N Safety, Emission Safety, Emission Safety, Emission Plagnostic N Optimization Optimization Diagnostic N 	Messages ssion, Delay Values C Messages on leters 1 Status Aessages	Save	Cancel	
 Diagnostic N Safety, Emis Safety, Emis Input Param Optimization Diagnostic N With few process 	Messages ssion, Delay Values > Messages on leters h Status Messages let than 5 intersections, Mutation Prot to converge too quickly on a local opt onduition to earb earge a Mutation Prot	Save	Cancel e optimization the global fractive	 Inf St
 Diagnostic N Safety, Emis Safety, Emis Safety, Emis Full Optimization Optimization Diagnostic N With few process optimum To find the second seco	Messages ssion, Delay Values > Messages on leters n Status Messages er than 5 intersections, Mutation Prot to converge too quickly on a local opt to converge too quickly on a local opt	Save	Cancel e optimization the global ffective.	
 Diagnostic N Safety, Emission Safety, Emission Safety, Emission Full Optimization Optimization Diagnostic N With few process optimum To find t least (20) 	Messages ssion, Delay Values > Messages on leters h Status Messages er than 5 intersections, Mutation Prob to converge too quickly on a local opt i solution. In such cases, a Mutation F he global optimum solution, the Maxin " #intersections).	Save babilities below 3% may cause th imum solution, instead of finding Probability of 4% may be more ef num Number of Generations may	Cancel e optimization the global ffective. y need to be at	
 > Diagnostic N > Safety, Emis > Safety, Emis > Safety, Emis > Pull Optimization > Optimization > Optimization > Diagnostic N > With few process optimum > To find the least (20) > The defa Reducin 	Messages ssion, Delay Values > Messages on teters n Status Messages rer than 5 intersections, Mutation Prob to converge too quickly on a local opt i solution. In such cases, a Mutation F he global optimum solution, the Maxin # #intersections). ult Number of Calculation Iterations (i g the Number of Calculation Iterations (i	Save Save Save Save Save Save Save Save	Cancel e optimization the global ffective. y need to be at eral) is 15. sduce	
 Diagnostic N Safety, Emis Safety, Emis Safety, Emis Full Optimization Optimization Optimization Optimization Writh few process optimum To find t least (20) The defer Reducin optimization 	Messages ssion, Delay Values > Messages on leters n Status Messages rer than 5 intersections, Mutation Prob to converge too quickly on a local opt i solution. In such cases, a Mutation F he global optimum solution, the Maxin I* #intersections). sult Number of Calculation Iterations (g the Number of Calculation Iterations tion run times by 30% without compro-	Save Save Save Save Save Save Save Save	Cancel e optimization the global ffective. y need to be at eral) is 15. aduce	
 > Diagnostic N > Safety, Emis > Safety, Emis > Safety, Emis > Piul Optimization > Optimization > Optimization > Diagnostic N > With few process optimum > To find the least (20) > The define Reducin optimization 	Messages ssion, Delay Values > Messages on teters n Status Messages ter than 5 intersections, Mutation Prot to converge too quickly on a local opt to converge too quickly on a local opt to solution. In such cases, a Mutation F he global optimum solution, the Maxin * #intersections). nult Number of Calculation Iterations tion run times by 30% without compro-	Save abilities below 3% may cause th imum solution, instead of finding Probability of 4% may be more e num Number of Generations may under Detailed Input Data > Gen if from 15 to 10 can sometimes re mising model accuracy.	Cancel e optimization the global ffective. y need to be at eral) is 15. educe	

) Input Paran) Optimizatio	neters n Status		
) Diagnostic) Safety, Emi	Messages ission, Delay Values		
	Total Crashes, 5 Yea	ars 19.0	
	Total Emissions	1550.1 g	Start
	Overall Delay	27.3 sec	
	Overall Delay	27.3 sec	Sto

- iii. There Full Optimization window includes five buttons:
 - 1. Start; clicking this will start running full optimization using the inputs specified under Input Parameters

ptimization Include this Ini Objective Funi Cycle Length Splits Offsets	tersection	tion in Optimization Percent Base FFS Phasing Sequence Dallas Phasing	•	Minimum Cycle, s Maximum Cycle, s Cycle Increment, s Master Intersection Forward Weighting, % Reverse Weighting, %	100 100 10 1 50 50	Number of Generations Population Size Crossover Probability, % Mutation Probability, % Convergence Threshold, % Random Number Seed	20 10 30 1.0 0.010 7781	Start
ptimizatior iagnostic N	n Sta //ess	tus ages) Info

2. Info; clicking this will show the Diagnostic Messages

Diagnostic Messages	
With fewer than 5 intersections, Mute process to converge too quickly on a optimum solution. In such cases, a M To find the global optimum solution, least (20 * #intersections).	ation Probabilities below 3% may cause the optimization local optimum solution, instead of finding the global Mutation Probability of 4% may be more effective. the Maximum Number of Generations may need to be at
The default Number of Calculation It	erations (under Detailed Input Data > General) is 15.
Reducing the Number of Calculation optimization run times by 30% without	Iterations from 15 to 10 can sometimes reduce ut compromising model accuracy.

3.	Stop; clicking this will stop full optimization in the middle of a run

Delay & Safe	ety & Emission	
Original	1.0	
Optimum	1.0	
Average	1.0	
Improvement	1.1%	
Generation Number	2 out of 20	
Generation Optimum	2	
lotal lime Elapsed	/ sec	
Optimization in progre	ss	

4. Save; clicking this will save the changes as a result of running optimization

Original 1.0
Optimum 1.0
Average 1.0
Improvement 1.4%
Generation Number 20 out of 20 Generation Optimum 17 Total Time Elapsed 31 sec
Termination via max number of generations

5. Cancel; clicking this will exit the Full Optimization window without saving any changes

Difference Full Optimization			×
Input Parameters			
 Optimization Status 			
	Delay & Safe	ty & Emission	
Orig	ginal	1.0	
Opt	imum	1.0	
Ave	erage	1.0	
Imp	rovement	1.4%	
	Runs	Status	
Ger	neration Number	20 out of 20	
Ger	neration Optimum	17	
Tota	al Time Elapsed	31 sec	
Ter	mination via max n	umber of generations	
Diagnostic Messages Sefety Emission Delay	Values		Stop
Safety, Emission, Delay	values		
		Save	Cancel

- 2. There are multiple ways to run optimization for a Streets file:
 - a. Using the toolbar icons
 - i. T7F Optimization (Quick Optimization)

🖳 File View Edit Windows Reports	Help				
: D 🖻 🛱 O 🎫 Ö 🛱 🔽 🕞 🗏	Intersection: 1>	- + - Start Time: 7:0	D Period: 1> 7:00	• + - Segment: 1	- ?
Classic Mode Visual Mode					
Platoon Dispersion Fact. T7F Optimization 0.138	On-Street Parking, %		Safety Input Data	^	
		0			
		0			
Full Optimization		0			
Full Optimization		0			
Full Optimization	Help				
Full Optimization	Help Intersection: 1>	• + - Start Time 7.0	0 Period: 1> 7:00	✓	• 6
Full Optimization III HCS Streets - [Streets - Motorized/Whicle.xus] IIII HCS Streets - [Streets - Motorized/Whicle.xus] III HCS Streets - [Streets - Streets - St	Help Intersection: 1>	• + - Start Time: [7:0]	0 Period: 1> 7:00	• + - Segment: 1	•

- b. Using the View menu items
 - i. To run Quick Optimization, select *View > Quick Optimization* from the main menu; this can be found by selecting "View" in the top left-hand corner of the

	Status Bar		ersection: 1>	• + -	Start Tin	ne: 7:00 Pe	riod: 1> 7:0	0	+ - Segmer	nt: 1 • 🕜 •					_	_
sic mo	Startup Screen		Domet Parking		-	Cafaba	Innut Data		^		HCS Signalize	d Inte	rsecti	on Res	ults S	um
	Reports	•	Calibration E		0		- por boto			General Information					Intera	
emand	Classic / Visual Made	55	peeu Calbrabon ry	0.0	0.0		Safety and Er	nission		Apency					Durat	ion
	classic / visual would	13							_	Analyst	Analy	sis Date	Aug 15	3, 2022	Area 7	Ty
	Primary Data		100.00							Jurisdiction	Time	Period			PHF	
ccess	Detailed Data	F6	as Points							Urban Street	Analy	sis Year	2022		Analy:	
dias l										Intersection	File N	lame	Streets	s1-Motoriz	ed/lehicle	e:
u.a.i	Interchanges Data	F12		1.1	100.0		-		-	Project Description Chapter 30: E	xample Problem 1					_
-wolk	Multimodal Data	F7	1.00 +	= 1>	•	Count:	2	New	Delv	Demand Information		50	-	-	1012	4
aht-Tu			- E8	IL EBT EBR WBL	WBT	WBR NBL	NBT NB	R SBL	SBT	Annon Mountain		T	P	1	T	5
and and a	Quick Lanes	F8	and, veh/h 80	1050 100 80	1050	100 80	0 100	80	0 1	Demand (v), veh/h	200	1000	10	200	1000	10
avinui	Quick Phases	F9		2 0 0	2		0 1	1	0 1					(and the second s		8
celer			s		<u> </u>					Signal Information		2 -		1	60	ų
de T	Reports Panel	F11				Location, ft	600.0			Cycle, s 100.0 Reference Pt	nase 2	6	R.	8	5	
	Information	Ctrl+I	_							Offset, s 0 Reference Po	ant End Green	12.0	0.2	48.7	0.1 1	18
			-							Enco Mode Eved Simul Cap 2	VV On Yellow	v 3.0	0.0	4.0	3.0 4	4
stimize	Auto-Calculate	Ctrl+Shift+A				Origin-Destinat	ion			Porce Mode Poted Simul: Capit	es on Rec	10.0	0.0	0.0	0.0 10	f
nclude	Force Calculations	Ctrl+Shift+R	e.s 100	Number of Generations	20			U	lpstream	Timer Results	EB	L 1	EBT	WBL	WBT	ĩ
de la cale			de. s 100	Population Size	10	Direction co				Assigned Phase	5	_	2	1	6	7
ojecu	Quick Animation	Ctrl+Shift+L	100			LU		T	<u>R</u> :	Case Number	2.0		3.0	2.0	3.0	
vole I	0.110 0.1 0	C1 C1 C C	ent.s 10	Crossover Probability, %	30		L 0.02	0.10	0.05 «	Phase Duration, s	10.	1 5	52.9	15.9	52.7	
	Quick Optimization	Ctri+Shift+O	ection 1	Mutation Probability, %	10		T 0.91	0.79	0.92	Change Period, (Y+R a), s	3.0)	4.0	3.0	4.0	
plits	Full Optimization	Ctrl+Shift+F	And the second second	Conversion Developed 2	1.0	Downstream	0.51	0.70	0.52	Max Allow Headway (MAH), s	3.1		0.0	3.1	0.0	
	Time-Space Disgram	Ctrl+Shift+T	grung. 4 50	Convergence Intreshold, 4	0.010		н 0.05	0.10	0.02	Queue Clearance Time (g x), s	12.	8	_	12.6		
ffsets	nine-space biagram	Cur+ shirt+ 1	ohting, % 50	Random Number Seed	7781		M 0.02	0.02	0.01	Green Extension Time (g •), s	0.3	3	0.0	0.3	0.0	_
	Flow Profile Diagram	Ctrl+Shift+P					0.02	0.02	0.01	Phase Call Probability	1.0	0	_	1.00	-	-
amhanas	and Atomative Internetic		_							Max Out Procability	0.0	0	_	0.00	-	a
ercher ge	to and Atemative Intersector	10								Movement Group Results		EB			WB	1
nterchang	es	Atema	dive.							Approach Movement		T	R	L L	TR	ŝ
nterchang	e Intersection	Atema	tive Intersection							Assigned Movement	5	2	12	1	6 10	ő
nterchang	e Type Diamond	*	-	_						Adjusted Flow Rate (v), veh/h	200	1000	10	194 F	10 884	ő
		Interse	ction Type	~						Adjusted Saturation Flow Rate (a), v	eh/h/in 1810	1900	1610	1810 1	900 161	ŝ
	EDTT Data									Queue Service Time (g+), s	10.8	14.1	0.3	10.6 1	7.4 0.3	3
										Cycle Queue Clearance Time (g +).	10.8	14.1	0.3	10.6 1	7.4 0.1	3
										Green Ratio (g/C)	0.13	0.40	0.49	0.13 0	.49 0.4	40

screen above the toolbar and then selecting "Quick Optimization"

ii. To run Full Optimization, select *View > Full Optimization* from the main menu; this can be found by selecting "View" in the top left-hand corner of the screen above the toolbar and then selecting "Full Optimization"



- c. Using keyboard shortcuts
 - i. Quick Optimization: keyboard shortcut is Ctrl+Shift+O
 - ii. Full Optimization: keyboard shortcut is Ctrl+Shirt+F

Import

- 1. There are five options for import: Streets CSV File, QuickStreets CSV File, Synchro-To-Streets Converter, Streets Data Template, and DAITA File
 - a. Import Streets CSV File; this imports input data from a Streets CSV file to the current Streets dataset

Open					×
÷ → ~ ↑ 🚺 > '	This PC > Desktop > Streets	~	Ō	Ø Search Streets	5
Organize 🔻 New fo	lder				- 🔳 🕐
	Name		C	ate modified	Туре
Quick access	QS1.csv		1	2/5/2021 8:48 PM	Microsoft Exce
🕃 Dropbox (UFL)	B StreetsCSV.csv		1	2/21/2021 9:30 AM	Microsoft Exce
	<				>
File	name: StreetsCSV.csv		~	comma delimited	file (.csv) (*.c ∨
				Open	Cancel

a. Import QuickStreets CSV File; this imports data from a QuickStreets file to the current Streets dataset

Open				×
$\leftarrow \rightarrow \neg \uparrow \Box \rightarrow$	This PC > Desktop > Streets	ٽ ~		ts
Organize 👻 New fo	lder			• 🔳 🔞
10:1	Name	Di	ate modified	Туре
Quick access	QS1.csv	12	2/5/2021 8:48 PM	Microsoft Exce
 OneDrive - Universit This PC Metwork 	by			
File	< name: Q\$1.csv	~	comma delimited	file (.csv) (*.c ∨

b. Import with Synchro-To-Streets Converter; this imports data from a Synchro CSV file to the current Streets dataset

×

SYN	ICHRO	-To-Str	EETS
Plea	ise select	a 'File' or 'Fo	older'
	File	O Folder	
Please	select the	e 'Forward Di	irection'
	~		o
c. Import Streets Data Template; this imports input data from an existing template to the current Streets dataset

Import Streets Data	Template		?	×
General & Global Lanes Phasing & Timing Traffic Detailed Input Multimodal All Templates	Existing templates All templates Export Test - All Export Test - General & Global Export Test - Multimodal Export Test - Traffic Export Test-General Export Test	Export Test - Detailed Input Export Test - Lanes Export Test - Phasing & Timing Export Test Export Test Export Test-Multimodal		
Name Description		ОК	Can	cel

Note: Please see *Templates* under the *Getting Started* section for more details.

d. Import DAITA File; this imports traffic counts from a DAITA file (*.xhd) to the current Streets dataset

) Per approach datasets	
DAITA File	Browse
EB	Browse
WB	Browse
NB	Browse
SB	Browse
mporting data from a file will ov	verwrite existing data in the

2. To import a Streets CSV File, select *File > Import > Streets CSV File* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar, hovering over "Import", and then selecting "Streets CSV File". *Note: Please close the CSV file in other applications, such as Microsoft Excel, before importing.*

New Ctrl-N																				P		ports		williow.	Conc		THE
D Open Ctrl+O B Sample Folder Recent Files - Close - D Save As D Pint Close - D Pint D Direct D Save As D Pint Direct - D Direct Direct -						t 1 - 🕜	Seamer	+ -	7:00	eriod: 1) P	Time: 7:00	Start	+ -	-			1>	ection	Interse	0		m	+N	Ctrl-	New	B
Example Folder Recent Files Chromation Chromation Base Struct The Problem 1 The Problem 1 The Problem 1 The Problem 1 Base Struct Struct CVI+S The Problem 1 The Problem 1 The Problem 1 The Problem 1 Core of the Problem 1 Core of the Problem 1 Core of the Problem 1 Core of the Problem 1 Core of the Problem 1 Core of the Problem 1 The Problem 2 The Problem 2<			_					-						-	-	_	_	_			-		- 0	+0	Ctrl+	Open	P
Base Status Constrained Constrained <thconstrained< th=""> <thconstrained< th=""></thconstrained<></thconstrained<>	esults Si	ection Re	Inter	nalized	HCS Sig																				Folder	Example	-
Close Clo Close Close C					-																			•	iles	Recent Fi	
Cloce Construction	Inters				1	General Information						Phasing		4	44	444	2		_								
Save Ctrl -S Wo Wo Wo Times Field Ti	Durati	up 15 2022	Date	Analysis		Agency				100		Cuelo e			L											Close	
By etc. Cuti-s Per-Treed Signal Impert Analysis terr An	PHF	109 10, 2022	riod	Time Pe		Jurisdiction			_	100		Cycle, s						-						1.0	Chil	C	TTN.
Save As mple Publem 1 File form Description Plane form Plane f	Analy	022	Year	Analysis		Urban Street				al	ed Signa	Pre-Time												1+5	Ctri	Save	B
Print Ctl-P Project Pr	orizedVehicle	Streets1-Motori	ne	File Nar		Intersection	<u> </u>	1		0		Offect e	-	ĸ			*	*			1	roblem	ample P			Save As	
Print CHIP* vec lipe Other Print Desce liferation EB The The Print Print CSV Inport 0.250 0.250 0.050 0.			_	lem 1	Chapter 30: Example Prot	Project Description				50		Di o	- 4-	+			•	-6			0.1	_	1		01	Diat	
Prime Preview Junation 0.200 Prime Preview Junation Care Mode S Import Streets CSV File	WB		EB		0	Demand Information	+	7	•	on EB	2 Directio	Phase 2	- ÷	+			*	-	•		Other	pe	vea Typ	1+P	Ctri	Print	6
Import Streets CSV File CSV Import Wizard Export Streets Carl File CORSIM December Streets Converter Datt A File NBR SBL SBT SBR Boiltones SBL SBT SBR Force Mode Pread Duration CORSIM December Streets Converter NBR SBL SBT SBR Boiltones SBL SBT SBR Force Mode Pread Duration Datt A File Datt Sample Datt S	T	RI	T	1.1		Annroach Movement			-	on SB	4 Directio	Phase 4	*	ĸ			7	*			0.250	1	Duration		eview	Print Pres	6
Import Street SV File Street SV File<	1000 1	10 200	1000	200		Demand (v), veh/h	_			se 2	ce Phas	Reference	£					-			-	<u>.</u>				Incore	-
GSV import Wizard Cuck/Streets CSV File File<							Side				-	Therefore			1	54				ile	S CSV F	Streets				impon	_
Export Synchro-To-Streets Converter NER SET C/RSIM Surphice-To-Streets Converter NER SET SET Exit NER SET	H 5 8	2 . ₽	2.1		O Defenses Direct 2	Signal Information	Unci	lasing	-	t End	tce Point	Reference							ile	CSV Fil	Streets	QuickS		rd	ort Wizan	CSV Imp	
Optimize Optimize Normalize	5	3 3			Deference Priase 2	Officet a 0	Field	rizaru	-	Fixe	lode	Force M		r.	t the ball	4.1.4	- 1	uter	Com	Ctreate	To-To-	Sunch		•		Export	
CORM Street Data Template NBR SBL SET SBR Exit 50 100 50 100 50 10	6.1 1	0.2 48.7	12.9	Green	Simult Gap F/W On	Uncoordinated No	11010										- 1	inter	COllive	Streets	10-10	Syncin					
bit DATA File 56 100 560 800 are WdArh. 120 <	0.0 0	0.0 0.0	0.0	Red	d Simult Gap N/S On	Force Mode Fixed					Duration	Phase D	SBR	SBT	SBL	NBR	- 1		ete	Templat	Data	Streets		•	1	CORSIM	
Lixit Timer Reads EBL EBT VMBL, fill noroge Length fill 120 <t< td=""><td></td><td></td><td></td><td></td><td></td><td>Service of the service of the servic</td><td></td><td>R</td><td></td><td></td><td></td><td></td><td>50</td><td>E00</td><td>100</td><td>E0</td><td>H</td><td></td><td></td><td></td><td>File</td><td>DAITA</td><td></td><td></td><td></td><td></td><td></td></t<>						Service of the servic		R					50	E00	100	E0	H				File	DAITA					
ane Widh fr. 120 120 120 120 120 120 120 120 120 120	L WBT	BT WBL	E	EBL		Timer Results		•	2	· ~	12		50	500	100	50		-			_					Exit	
Consert Lag Seg 200 900 200 900 200 900 1000 200 900 1000 1	6	1		5		Assigned Phase	R ,		3	~ =			12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0		Vidth, ft	ane \
Display Display <t< td=""><td>3.0</td><td>0 2.0</td><td>3</td><td>2.0</td><td></td><td>Case Number</td><td>61</td><td>7</td><td>2 4</td><td>a 1</td><td>12 0</td><td>Green</td><td>1000</td><td>999</td><td>200</td><td>1000</td><td>999</td><td>200</td><td>200</td><td>1800</td><td>200</td><td>200</td><td>999</td><td>200</td><td>A</td><td>e Length fi</td><td>torag</td></t<>	3.0	0 2.0	3	2.0		Case Number	61	7	2 4	a 1	12 0	Green	1000	999	200	1000	999	200	200	1800	200	200	999	200	A	e Length fi	torag
Tendor 3.0 0 <th< td=""><td>02.7</td><td>9 15.9</td><td>- 04</td><td>10.1</td><td>0.)-</td><td>Phase Duration, s</td><td>2.0</td><td></td><td></td><td>· ·</td><td>12.</td><td>V</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>e congut, n</td><td>orug</td></th<>	02.7	9 15.9	- 04	10.1	0.)-	Phase Duration, s	2.0			· ·	12.	V														e congut, n	orug
Line Line <thline< th=""> Line Line <thl< td=""><td>4.0</td><td>0 3.0</td><td>-</td><td>3.0</td><td>(MAH) s</td><td>Max Allow Headway (</td><td>3.0</td><td></td><td>0 4</td><td></td><td>3.0</td><td>Tellow</td><td>1900</td><td>1900</td><td>1900</td><td>1900</td><td>1900</td><td>1900</td><td>1900</td><td>1900</td><td>1900</td><td>1900</td><td>1900</td><td>1900</td><td>pc/h/in</td><td>aturation, p</td><td>ase :</td></thl<></thline<>	4.0	0 3.0	-	3.0	(MAH) s	Max Allow Headway (3.0		0 4		3.0	Tellow	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	pc/h/in	aturation, p	ase :
rade, % 0 </td <td>3</td> <td>12.6</td> <td>+</td> <td>12.8</td> <td>me (ga) s</td> <td>Queue Clearance Tim</td> <td>0.0</td> <td></td> <td>0 0</td> <td></td> <td>0.0</td> <td>Red</td> <td>0</td> <td>%</td> <td>Vehicles, 1</td> <td>eavy</td>	3	12.6	+	12.8	me (ga) s	Queue Clearance Tim	0.0		0 0		0.0	Red	0	0	0	0	0	0	0	0	0	0	0	0	%	Vehicles, 1	eavy
dob., A U </td <td>0.0</td> <td>0 0.3</td> <td>C</td> <td>0.3</td> <td>e(q.).5</td> <td>Green Extension Time</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>0</td> <td></td> <td>1</td> <td>0</td> <td></td> <td>7</td> <td></td> <td></td> <td></td> <td>0</td> <td></td> <td></td> <td></td> <td></td>	0.0	0 0.3	C	0.3	e(q.).5	Green Extension Time								0		1	0		7				0				
Uses, per h 0 <t< td=""><td>5</td><td>1.00</td><td></td><td>1.00</td><td>y</td><td>Phase Call Probability</td><td></td><td></td><td></td><td></td><td></td><td>Timing</td><td></td><td>U</td><td></td><td></td><td>U</td><td></td><td></td><td>Ľ.</td><td></td><td></td><td>0</td><td></td><td></td><td>10</td><td>rade</td></t<>	5	1.00		1.00	y	Phase Call Probability						Timing		U			U			Ľ.			0			10	rade
whing, perh 0 N 0 N 0 N 0 N 0 N 0 N 0 N 0 N 0 N 0 N 0 N 0 N 0 N 0 N 0 N <th< td=""><td>)</td><td>0.00</td><td></td><td>0.00</td><td></td><td>Max Out Probability</td><td>VBT</td><td>BL V</td><td>EBT</td><td>EBL</td><td></td><td></td><td>0</td><td></td><td></td><td>0</td><td></td><td></td><td>0</td><td></td><td></td><td>0</td><td></td><td></td><td></td><td>perh</td><td>ises</td></th<>)	0.00		0.00		Max Out Probability	VBT	BL V	EBT	EBL			0			0			0			0				perh	ises
Light speech 0 <t< td=""><td>140</td><td></td><td>50</td><td></td><td>oculto</td><td>Movement Grown Re</td><td>(6)</td><td>1) (</td><td>(2)</td><td>(5)</td><td>Phase</td><td>Assigned</td><td>0</td><td>N -</td><td>0</td><td>0</td><td>N -</td><td>0</td><td>0</td><td>N -</td><td>0</td><td>0</td><td>N - 1</td><td>0</td><td></td><td>, per h</td><td>arkin</td></t<>	140		50		oculto	Movement Grown Re	(6)	1) ((2)	(5)	Phase	Assigned	0	N -	0	0	N -	0	0	N -	0	0	N - 1	0		, per h	arkin
Op/cels. per h U U U U U U U Hanse Split. 6 200 35.0 20.0 2	TR	R I	T		esuns	Approach Movement		., .	/					0		1	0						0				
Velow Change, s 30 40 30 40 30 40 30 100 100 100 101 161 163 rival Type 3 4 3 <td>6 10</td> <td>12 1</td> <td>2</td> <td>5</td> <td></td> <td>Assigned Movement</td> <td>i.0</td> <td>0 35</td> <td>35.0 2</td> <td>20.0</td> <td>olit, s</td> <td>Phase Spl</td> <td></td> <td>0</td> <td></td> <td></td> <td>0</td> <td></td> <td></td> <td>0</td> <td></td> <td></td> <td>0</td> <td>ļ</td> <td></td> <td>s, per n</td> <td>CYCK</td>	6 10	12 1	2	5		Assigned Movement	i.0	0 35	35.0 2	20.0	olit, s	Phase Spl		0			0			0			0	ļ		s, per n	CYCK
Intro 3 4 3 4 3 3 3 3 3 3 3 Ped Clearance s 0	968 10	10 194	1000	200	v), veh/h	Adjusted Flow Rate (0	4	40 3	3.0	hange, s	Yellow Cha		0			0			0			0		h	rians, per h	edes
Image: Control of the second	1900 161	610 1810	1900	1810	Flow Rate (s), veh/h/ln	Adjusted Saturation FI						Ded Cl	3	3	3	3	3	3	3	4	3	3	4	3		Type	rival
Statem Refring () LEB 1.00 LVB L00 LSB 1.00 LSB 1.00 LSB 1.00 LSB 1.00 LSB L01 L01 1.01	17.4 0.3	0.3 10.6	14.1	10.8	(g.).s	Queue Service Time (0	0.0	0.0	0.0	rance, s	Hed Clean		~	-	~	<u>ا</u>	-	-		-	~	-	Ľ		1300	inval
tal Queue, veh 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	17.4 0.3	0.3 10.6	14.1	10.8	nce Time (g =), s	Cycle Queue Clearant		5	5 5	5	Green, s	Minimum G	1.00	B	1-5	1.00	NB	1-1	0.82	VB	I-M	1.00	B	I-EI	g (I)	am Filtering	ostre
and linit with 25 15 15 15 and 10 and	0.49 0.4	0.49 0.13	0.49	0.13		Green Ratio (g/C)						I an Dhann	0	0	0	0	0	0	0	0	0	0	0	0		ueue veh	Hal (
and limit mith (5) (5) (5) (5)	1849 784	/8/ 233	1857	237		Capacity (c), veh/h	TW	WL	Ef		e .	Lay Phase	-	0.5	-		05	·			-	•	~	<u> </u>		ven, ven	
Add Link, high							n 🗸	0.	00 2	20	Time, s	Passage 1		35			35			35			35		1	Limit, mi/h	beed

3. To import a QuickStreets CSV File, select *File > Import > QuickStreets CSV File* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar, hovering over "Import", and then selecting "QuickStreets CSV File". *Note: Please close the CSV file in other applications, such as Microsoft Excel, before importing.*



4. To import with the Synchro-To-Streets Converter, select *File > Import > Synchro-To-Streets Converter* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar; hovering over "Import", and then selecting "Synchro-To-Streets Converter".

File	View Edit	Window	s Re	orts H	lelp																					. é
ß	New Ctrl-	N	m		Inter	section	: 1>			-	+	- Star	t Time: 7:00	Per	iod: 1	> 7:00	- +	- Se	gment	t: 1 🔹 🕜 •						
Ð	Open Ctrl-	0		-			_	_		_					_				_							-
	Example Folder																		^	HC	Signalized	l Inter	secti	on Res	ults Su	mm
	Recent Files	•						100												Our well before a first						
	0					_			4 사	+++			Phasing							Agency					Duratio	souce
	Close								*	, L			Cycle, s		100					Analyst	Analys	s Date	Aug 15	, 2022	Area T	ype
	Save Ctrl	+5					10					R.				_				Jurisdiction	Time F	eriod			PHF	_
-	Sore con										6.20	A	Pre-Timed	i Signal						Urban Street	Analys	is Year	2022		Analys	is F
	Save As		ample P	blem 1				~					Offset, s		0			1 3		Intersection	File Na	me	Streets	1-Motorize	dVehicle	xus
B	Print Ctrl	+ P	Tur	0#	ar.		-	•				÷	Phase 2.0	Inaction	EB		10000	1 2		Project Description Chapter 30: Exam	e Problem 1					_
			vea iy		NGI .	_	-					-	111036 2 6	hecton	LU					Demand Information		EB	_	1	WB	
20	Print Preview		Duration	0.2	50		*					÷.	Phase 4 D	Direction	SB	-		5		Approach Movement	L	т	R	L	TF	2
-	Import			mante CS	V Eile		-					£	Reference	e Phase	2	-				Demand (v), veh/h	200	1000	10	200 1	000 1	D
-	impore			ueets Ca	v rile				5	1 1					5.4		Director	Side		Signal Information					1 1 1	į.
	CSV Import Wizar	d		uickStre	ets CSV	File					1		Heterence	e Point	End	•	Wizar	9 Unc		Cycle s 100.0 Reference Phase	2	20	-3	L P	2 6	13
	Export			vnchro-	Co-Street	s Conv	erter		41.	r T r			Force Mor	de	Fixed	÷ 1		Field		Offset s 0 Reference Point	Fod		Ň	1	2	Ĩ
					-															Uncoordinated No Simult Gap E/W	On Vellow	12.9	0.2	48.7 0	1 18	.1
	CORSIM	•	1	treets Da	ta lemp	late		ł	NBR	SBL	SBT	SBR	Phase Du	ration						Force Mode Fixed Simult. Gap N/S	On Red	0.0	0.0	0.0 0	0 0.	ó
				AITA File				ł	50	100	500	50														
	Exit				_	1	-		30	100	500			2	~	2	L. '	-		Timer Results	EBL	. E	BT	WBL	WBT	4
ne	Width, ft	12.0	12.0	2.0 12.	0 12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0				3	5	7		Assigned Phase	5	-	2	1	6	_
ra	ae Length ft	200	999	00 200	1800	200	200	999	1000	200	999	1000	Green	12.9	-	12	49.7	61		Case Number	2.0	3	1.0	2.0	3.0	4
-	ge bengan, n												V II	12.0	-	1.2	40.7	2.0	1	Phase Duration, s	10.1	04	2.9	15.9	52.7	-
se	Saturation, pc/h/ln	1900	1900	900 190	1900	1900	1900	1900	1900	1900	1900	1900	Tellow	3.0		1.0	4.0	3.0		Max Allow Headway (MAH) s	3.0		10	3.0	4.0	-
av	v Vehicles, %	0	0 0	0	0	0	0	0	0	0	0	0	Red	0.0	0	0.0	0.0	0.0		Queue Clearance Time (q x) s	12.8			12.6	0.0	-
	-				0	1			1		0	1								Green Extension Time (a.) 5	0.3	0	0	0.3	0.0	-
ade	3, %		0		U			U			U		Timing							Phase Call Probability	1.00	-		1.00		-
ses	s, per h		(0			0			0			EBL	EBT	WBL	WBT		Max Out Probability	0.00			0.00		1
rkir	na perh	0	N - (0	Ν -	0	0	N -	. 0	0	Ν.	0	Assigned Pl	hase	(5)	(2)	(1)	(6)		Manager Carrier Desults		50	_	1		4
						1			1			1	/ borgi rou / i		(0)	(-)	1.7	107		Approach Movement		T		-		-
yc	les, per h		0		0			0			0		Phase Split	.s	20.0	35.0	20.0	35.0		Assigned Movement	5	2	12	1 1	3 16	1
de	strians, per h		0		0	1		0			0		Yellow Char	nge s Í	2.0	4.0	2.0	4.0		Adjusted Flow Rate (v), veh/h	200	1000	10	194 9	38 10	1
	Tune	3	4	3	4	12	3	12	3	3	12	12	n in		5.0	4.0	3.0	4.0		Adjusted Saturation Flow Rate (s), veh/h	1810	1900	1610	1810 19	00 161	5
٧ð	iype	2	ال		*	12	12		12	12		3	Red Clearar	nce, s	0.0	0.0	0.0	0.0		Queue Service Time (g .), s	10.8	14.1	0.3	10.6 17	.4 0.3	ſ
stn	eam Filtering (I)	I-E	B	.00	I-WB	0.82	-	NB	1.00	ŀ	SB	1.00	Minimum Gr	een, s	5	5	5	5		Cycle Queue Clearance Time (g =), s	10.8	14.1	0.3	10.6 17	.4 0.3	
	Course with	0	0	0	0	0	0	10	0	0	0				-		<u> </u>	<u> </u>	3	Green Ratio (g/C)	0.13	0.49	0.49	0.13 0.	49 0.49	÷
d	uueue, veh	v	v (<u> </u>	U	<u> </u>	v	U.	<u> </u>		Lag Phase	[EL	ET	WL	TW		Capacity (c), veh/h	237	1857	787	233 18	49 784	ŧ.
ee	d Limit, mi/h		35		35	1		35	1		35	1	Passage Tir	me,s í	20	0.0	20	0.0	~	<						
																				0	ſ			- AL		

5. To import a Streets Data Template, select *File > Import > Streets Data Template* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar, hovering over "Import", and then selecting "Streets Data Template".



6. To import a DAITA File, select *File > Import > DAITA File* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar, hovering over

"Import"	, and	then	selecting	"DAITA File".	
----------	-------	------	-----------	---------------	--

File View	Edit \	Window	/s R	eports	He	lp																				- 1
New	Ctrl+	N	m		0	Inter	section	: 1>			-	+ -	- Star	Time: 7:00	Period	1> 7:00	- +	- S	egmen	nt: 1 - 🕜 -						
C Open	Ctrl+	0					_	-			_					_			_			_	_		_	-
Example	Folder																		^	HCS	ignalize	ed Inte	rsect	ion Res	ults Si	umr
Recent F	iles	•							1																	
-							_		1	4	5× 4 4×			Phasing						General Information			_		Durati	ion k
Close										- 4 ·	ł L			Cycle, s	1	00				Analyst	Anah	rsis Date	Aug 1	5, 2022	Area	Туре
Save	Ctrle	- 5						10							- · ·		1	-		Jurisdiction	Time	Period	-		PHF	-
- Jave	curs	- 3												Pre-Timed	Signal		ĸ	_		Urban Street	Analy	sis Year	2022		Analy	sis
Save As			ample	Problem	n 1			- H	*			*	-	Offset s	0			1	2	Intersection	File N	lame	Street	s1-Motoriza	dVehicle	e.xu
Print	Ctrla	D	The T		Other			4	•		E		- ÷	Phase 21	limation [P .	1000		2	Project Description Chapter 30: Example	roblem 1					_
	cum		rea i	ype	ouner			-4					+	111050 2 1	account 1				- I	Demand Information		EB			MB	_
Print Pre	view		Duratio	in	0.250			*	*				*	Phase 4 [lirection S	B •		5		Approach Movement	L	T	R	6	T	R
Import				Church	- COV	Cil.		-					- F	Reference	Phase 2	-	-			Demand (v), veh/h	200	1000	10	200 1	000 1	10
import				Street	IS COV	rile				η.	1 1						Director	Side	e	Signal Information					1.1	
CSV Imp	ort Wizard	d		Quick	Street	s CSV F	ile				4. 5.7 4.	1		Hererence	Point	na •	Wiza	Und Und	D I	Ovcle. s 100.0 Reference Phase	2	10	12	_ ≈	2 8	45
Export		•		Synck	nro-To-	Street	s Conv	erter	- 1	N 1 1	PT P			Force Mo	le F	ixed •		Fiel	d	Offset s 0 Reference Point	nd o	100	N.	N	1	1
				~ .																Uncoordinated No Simult. Gap E/W	On Vello	n 12.9	0.2	48.7 0	1 4	8.1
CORSIM		•	_	Street	is Data	Tempi	ate			NBR	SBL	SBT	SBR	Phase Du	ration	-	-	_		Force Mode Fixed Simult. Gap N/S	n Red	0.0	0.0	0.0	0 0	0
Ewit				DAIT	File					50	100	500	50					<u></u>		Name of States o						
LAR		140.0	100	10.0	40.0	100		40.0	100	1 40.0	40.0	100	100		- e	-i≕	-	· .		Timer Results		SL.	2	WBL	WBI	-
ane Width, ft		12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0			-Si	-	`	2	Case Number	20	0	3.0	2.0	3.0	-
orage Length, f	t	200	999	200	200	1800	200	200	999	1000	200	999	1000	Green	12.9	0.2	48.7	6.1		Phase Duration, s	16	1	52.9	15.9	52.7	
an Coturation	no lh ln	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	Yellow	3.0	0.0	4.0	30		Change Period, (Y+R +), s	3.4	0	4.0	3.0	4.0	-
se Saturation,	permin	1500	1300	1300	1300	1300	1300	1300	1300	1300	1500	1300	1500	Red	0.0	0.0	0.0	0.0	-	Max Allow Headway (MAH), s	3.	1	0.0	3.1	0.0	
avy Vehicles,	%	0	0	0	0	0	0	0	0	0	0	0	0	Neu	0.0	0.0	0.0	0.0	-	Queue Clearance Time (g =), s	12	.8		12.6		
de %			0			0	1		0	1		0	1						-111	Green Extension Time (g .), s	0.3	3	0.0	0.3	0.0	
			-		1	-		1	-		1	Ľ		Timing					-	Phase Call Probability	1.0	10		1.00		
ses, per h				0			0			0			0		E	IL EBT	WBL	WBT		Max Out Probability	0.0	0	_	0.00		-
arking, per h		0	Ν •	0	0	Ν -	0	0	N •	0	0	Ν -	0	Assigned Pl	nase (!) (2)	(1)	(6)		Movement Group Results		EB		V	VB	
nuclea per b			0			0	1		0	1		0	1	Disase Cali			00.0	000		Approach Movement	L	Т	R	L	r R	E
sycies, per fr			-			-	1		-	-		-	-	rnase spin	s 20.	35.0	20.0	35.0		Assigned Movement	5	2	12	1	3 16	5
edestrians, per h	1		0			0			0			0		Yellow Cha	nge.s 3.0	4.0	3.0	4.0		Adjusted Flow Rate (v), veh/h	200	1000	10	194 9	38 10	3
ival Type		3	4	3	3	4	3	3	3	3	3	3	3	Red Cleara	ce.s	0.0	0.0	0.0	i	Adjusted Saturation Flow Rate (a), veh/h/ln	1810	1900	1610	1810 19	00 161	10
day of Charles	(1)	1.	D	1.00	1	AID	0.82		ND	1.00		CD	1.00	in a broard	0.0	0.0	0.0	0.0		Queue Service Time (gr), s	10.8	14.1	0.3	10.6 1	4 0.	3
stream Filtenng	100	1-6	0	1.00	1-1	IV D	0.02	-	ND	1.00		op	1.00	Minimum Gr	een, s 5	5	5	5		Green Ratio (g(C)	10.8	14.1	0.40	0.12 0	40 0.4	2
tial Queue, veh		0	0	0	0	0	0	0	0	0	0	0	0	Lag Phase		ET ET	D wi	WT		Capacity (c), yeh/h	237	1857	787	233 18	49 78	4
eed limit mi/h			35			35	1		35	1		35	1	Decese T						<						1
cou anik, more							1			1			1	rassage II	ne,s 20	10.0	120	100		(m)			_			

Export

- 2. There are two options for export: Streets CSV File and Streets Data Template
 - a. Export Streets CSV File; this exports input data from the Streets file to a CSV file

→ * ↑	nis PC > Desktop > Streets	~	G		eets
rganize 🔻 New fold	er				
 Quick access Dropbox (UFL) OneDrive - University This PC Network 	Name	No items mat	Ch you	Date modified Ir search.	Туре
File name: Stree	< tsExport				
Save as type: CSV F	file (*.csv)				

b. Export Streets Data Template; this exports input data from the Streets file to a template file

Export Streets Data	Template		?	×
	Existing templates			
General & Global Lanes Phasing & Timing Traffic Detailed Input Multimodal Select All	General & Global Export Test - All Export Test Export Test	Export Test - General & Global		~
	Export Test - All Export Test Phasing & Timing	Export Test - Lanes		-10
	Export Test - All	Export Test - Phasing & Timing		
< > Name Description		<u> </u>		~
	L	ОК	Cancel	

Note: Please see Templates under the Getting Started section for more details.

3. To export a Streets CSV File, select *File > Export > Streets CSV File* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the tool bar, hovering over "Export", and then selecting "Streets CSV File".



4. To export a Streets Data Template, select *File > Export > Streets Data Template* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the

New	Ctrl+N	1	<u>m</u>		0	Interse	ction:	1>			•	+ -	- Start	Time: 7:00	Perio	od: 1>	7:00	- +	- Segm	ent: 1	- 0						
y Open	Ctrl+C)										_														_	
Exampl	e Folder																		^			HCS Sigr	nalized	Inter	secti	on Res	ults
Recent	lles	•							J	d L d	. 1 1.	L.		Phasing						0	General Information						Inte
Close			-																_	A	Agency						Dur
								_		4+	14		_	Cycle, s		100				A	Analyst		Analysis	s Date	Aug 15	2022	Are
Save	Ctrl+S	5											R.,	Pro Timor	Sign al	Г	7		_	J	Jurisdiction		Time Pe	boing			PH
C			-				=	4					- A	rie-filleu	Jigha		_				Urban Street		Analysis	s Year	2022		Ana
Save As			kample	Problen	n 1			-	~				- B-	Offset, s		0			-	1	Intersection		File Nar	me	Streets	1-Motoriz	edVeh
Drint	Chille	,			0			+	+				÷	Dhave 2.0	Non all an	CD.	-			F	Project Description	Chapter 30: Example Prob	ilem 1			_	
FILL	Cuitre		Area I	pe	Other			-					+-	Fridse 2 L	arection	CD		7			Demand Information			FB			WB
Print Pr	eview		Duratio	n	0.250			*	•				÷ 👘	Phase 4 D	irection	SB	-	_			Approach Movement	A		T	P		TI
					1.00		=	-					5	Petersnow	Phase	2			-		Demand (v), veh/h		200	1000	10	200	1000
import		,	PHF		1.00				1.00	54			_	Therefore	mase	-			Sid								
CSV Im	oort Wizard		Prop. o	CAV	0						l r			Reference	Point	End	•	Phasin	19 Uni	5	Signal Information			2		1	6
Ennet			Trop. o		-				٦.	414	h the second	1		Course Man		Gund		Wiza	rd E.	9	Cycle, s 100.0	Reference Phase 2	. 1		R	R I	5
Export		•		otreets	CSV Fi	le								Force Mor	le.	rixeu			Fiel	0	Offset, s 0	Reference Point End	Green	12.9	0.2	48.7	6.1
CORSIN	1			Streets	Data T	emplat	te		NIDT		0.01	0.07	000	Phase Du	ration -						Uncoordinated No	Simult. Gap E/W On	Yellow	3.0	0.0	4.0	3.0
CONSIN		<u>_</u>	-					IRL	NRI	NRK	SBL	281	SBR		1			1	-		Force Mode Fixed	Simult Gapiles On	Red	0.0	0.0	0.0	0.0
Exit			1000	10	200	1000	10	100	500	50	100	500	50		1 2		Z		2 →	T	Timer Results		EBL	E	BT	WBL	W
a Wishis A		112.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0	12.0		—	e =	÷	→	1		Assigned Phase		5	-	2	1	6
io man, it		12.0	12.0	12.0	12.0		12.0	12.0	12.0	12.0	12.0	12.0	12.0				З	- 24			Case Number		2.0	3	3.0	2.0	3
rage Length	, ft	200	999	200	200	1800	200	200	999	1000	200	999	1000	Green	12.9	0.	2	48.7	6.1	< F	Phase Duration, s		16.1	5	2.9	15.9	52
e Saturation	nc/h/h	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	Yellow	3.0	0.	0	4.0	3.0	- 0	Change Period, (Y+R	e), S	3.0	4	1.0	3.0	4
ie outeration	, porton													Red	0.0	0	0	0.0	0.0	A	Max Allow Headway (MAH), s	3.1	0	0.0	3.1	0.
avy Vehicle:	. %	0	0	0	0	0	0	0	0	0	0	0	0	neu	0.0	10.	0	0.0	10.0	0	Queue Clearance Tim	a (g.).s	12.8			12.6	
de %			0			0			0			0	1							0	Green Extension Time	(g.).s	0.3	0	0.0	0.3	0.
			-	-				1	-	-		<u> </u>		Timing						F	Phase Call Probability		1.00			1.00	
es, per h				0			0			0			0			EBL	EBT	WBL	WBT		Max Out Probability		0.00		_	0.00	
ing, per h		0	Ν -	0	0	Ν -	0	0	N -	0	0	Ν.	0	Assigned Pl	ase	(5)	(2)	(1)	(6)	N	Movement Group Re	sults		EB	_	1	NB
olea norb			0			0			0			0	7	Disease Calls	- 1				1	A	Approach Movement		L	T	R	L	т
rcies, per n			-			<u> </u>			<u> </u>			-	-	Phase Spin	s	20.0	35.0	20.0	35.0	A	Assigned Movement		5	2	12	1	6
destrians, pe	rh		0			0			0			0		Yellow Char	nge,s [3.0	40	3.0	40	A	Adjusted Flow Rate ()), veh/h	200	1000	10	194 9	68
al Tune		3	4	3	3	4	3	3	3	3	3	3	2		-	010	110	0.0		A	Adjusted Saturation FI	ow Rate (s), veh/h/in	1810	1900	1610	1810 19	900 1
vai type		<u> </u>	<u> </u>	-	Ľ	<u> </u>	-	<u> </u>	<u> </u>	<u> </u>	Ľ	<u> </u>		Hed Cleara	ice, s	0.0	0.0	0.0	0.0	0	Queue Service Time (g.).s	10.8	14.1	0.3	10.6 1	7.4
tream Filter	ng (l)	-	EB	1.00	I-V	VB	0.82	ŀ	NB	1.00	ŀ	SB	1.00	Minimum Gr	een.s	5	5	5	5	0	Cycle Queue Clearant	e Time (g ;), s	10.8	14.1	0.3	10.6 1	7.4
	ah	0	0	0	0	0	0	0	0	0	0	0	0	Les Dhese		-	-		-		Green Ratio (g/C)		0.13	0.49	0.49	0.13 0	.49 (
a doctor, v		·	05		Ľ		-		05	<u> </u>	<u> </u>	0.5		Lay Friase	l		ET ET	L] WL	U WT		Capacity (c), veh/h		237	1857	/8/	233 10	849
ed Limit, mi	/h		30			30			30			35		Passage Tir	ne,s	20	0.0	20	00 ~				(-		-	-	
																			>	2			18			-	_

toolbar, hovering over "Export", and then selecting "Streets Data Template".

View Results of the Analysis

- 1. After editing all the necessary inputs, results of the analysis can be found in the form of reports.
- 2. Reports can be found in the Reports menu in the top left-hand corner of the screen; "Reports" is the fifth menu item from the left

	3 # ∿	Signals lext Report Signals Multiple-Period Text Report		+ -	Start	Time: 7:00	Period:	1> 7:00	• + •	Segme	ent: 1 🔹	? -					
assic Mode Visual Mode		Streets Text Report								^		HCS Sig	nalized	Inters	sectio	n Resu	ilts Sur
E PRIMART INPUT DATA		Safety/Emissions Text Report									Guardiate						
General		Streets Multiple-Period Text Report	44 4 40	4		Phasing				12	Anency	on					Duration
Urban Street			+ 4			Curle e	1	00			Analyst		Analysis	Date (Aug 15	2022	Area Ty
1		Interchanges lext Report				-,	Ľ			-	Jurisdiction		Time Pe	eriod			PHF
Intersection		Innut Panast				Pre-Timed	Signal		ĸ	_	Urban Street		Analysis	s Year 2	2022		Analysis
Description Chap	ter 30: Exar	Input Report		×_	-	Offset s	0			1	Intersection		File Nar	ne f	Streets1	Motorize	dVehicle.r
		Results Report	N.	+	- X.		Ľ				Project Descriptio	h Chapter 30: Example Prob	lem 1				
Forward Direction EB	 An 	Intermediate Report	ε	+	+	Phase 2 E	lirection E	в •	7	•	Description						10
Segment Length # 1800	D			*	-	Phase 4 D	irection S	·B	-	-	Cemand Informa	ion		- CO		V	TD
Segment Lengur, it	0.	Graphical Summary			i de la					5	Approach Movem	nt b	200	1000	10	200 4	1 K
All Segment Lengths	PH	Messages Report		-		Reference	Phase 2	•		Sid	Demand (V), Ven		200	1000	10	200 10	100 10
		5 H D	1 1			Reference	Point E	ind •	Phasing	U	Signal Informatio	n				54	UD
	Pri	Full Report	Or THE OF	C					Wizard	Uni	Cycle, s 1	0.0 Reference Phase 2	1 1	100	₹	÷П.	5 5
Terffer and Committee		Safety and Emissions Penort	-			Force Mo	le F	ixed •		Fiel	Offset, s	0 Reference Point End	Green	12.8	0.2	48.7 6	1 18
franciand Geometry	and a	Safety and Emissions Report				Phase Du	milen				Uncoordinated	No Simult. Gap E/W On	Yellow	3.0	0.0	4.0 3	0 4.0
	EBL E	Segment Report	SBL	SBT	SBR	Fildse Du	auon	1		-	Force Mode F	xed Simult. Gap N/S On	Red	0.0	0.0	J.O 0.	.0 0.0
Demand, veh/h	200 1	Access Point Report	100	500	50				- 5	_	Torre Dec. No.				17	10.001	INCOT
1 146 14 6	12.0 1	A	120	12.0	12.0		- 6	- 	-		Accioned Phase		EDL			1 1	VVD1
Lane Width, ft	12.0	Street Heatmap	12.0	12.0	12.0			3	_		Case Number		20		0	20	3.0
Storage Length, ft	200 9	Flow Profile Data	200	999	1000	Green	12.9	0.2	48.7	6.1	Phase Duration		16.1	52	9	15.9	52.7
Page Saturation and Ada	1900 1		1900	1900	1900	Yellow	3.0	0.0	4.0	3.0	Change Period, ((+R :), s	3.0	4.	0	3.0	4.0
base Saturation, portrain	1000	Interchanges Results Report	1500	1000	1000	Red	0.0	0.0	0.0	0.0	Max Allow Headw	ay (MAH), s	3.1	0.1	0	3.1	0.0
Heavy Vehicles, %	0 0	Alternative Intersections Report	0	0	0	neu	0.0	0.0	0.0	0.0	Queue Clearance	Time (g,).s	12.8			12.6	
Grade %	0		-	0							Green Extension	ime (g •), s	0.3	0.1	0	0.3	0.0
	-	Phasing and Timing Summary	h	<u> </u>		Timing					Phase Call Probal	ility	1.00			1.00	
Buses, per h		Internetion Summan			0		E	BL EB	WBL	WBT	Max Out Probabili	У	0.00			0.00	_
Parking, per h	0 N	Intersection summary	0	N 🔻	0	Assigned Pl	nase (S) (2)	(1)	(6)	Movement Group	Results		EB	-	W	18
Bicycles perh	0	None		0		Phase Solt	e [20.4	20.0	20.0	0.70	Approach Movern	ent	L	T	R	LT	R
Dedastrians and	0		-	0		in according	20.1	35.0	20.0	33.0	Assigned Moveme	nt	5	2	12	1 6	16
Pedestrians, per n	U	0		<u> </u>		Yellow Char	1ge.s 3.0	4.0	3.0	4.0	Adjusted Flow Ra	e (v), veh/h	200	1000	10	194 96	8 10
Arrival Type	3 4	3 3 4 3 3 3 3	3	3	3	Red Clearar	nce, s 0.0	0.0	0.0	0.0	Adjusted Saturatio	n Flow Rate (s), ven/nin	1010	1800 1	0.0	310 180	4 0.0
Lipstream Filterion (I)	LEB	1.00 LWB 0.82 LNP 1.0	0 1.0	B	1.00	Marine C.	0.0	0.0	0.0		Ovele Queue Clea	rance Time (σ_{*}) s	10.8	14.1	0.3	0.6 17	4 0.3
opsilearin nitering (i)	PCD	IND DUE HUB IN				Minimum Gr	een.s 5	5	5	5	Green Ratio (of C))	0.13	0.49 (0.49	0.13 0.4	49 0.40
Initial Queue, veh	0 0	0 0 0 0 0 0	0	0	0	Lag Phase			WL	WT	Capacity (c), veh	h	237	1857	787	233 18/	40 784
					the second se								-	and the second se			

r Urban Street -- Maximum length = 1000

- 3. There are multiple options for reports:
 - a. Signals Text Report
 - b. Signals Multiple-Period Text Report
 - c. Streets Text Report
 - d. Streets Multiple-Period Text Report

- e. Safety/Emission Text Report
- f. Interchanges Text Report
- g. Input Report
- h. Results Report
- i. Intermediate Report
- j. Graphical Summary
- k. Messages Report
- I. Full Report
- m. Safety and Emissions Report
- n. Segment Report
- o. Access Point Report
- p. Street Heatmap
- q. Flow Profile Data
- r. Interchanges Results Report
- s. Alternative Intersections Report
- t. Phasing and Timing Summary
- u. Intersection Summary
- v. None
- 4. Report availability is dependent on the analysis of the dataset. For example, if the dataset only has a single intersection instead of two or more intersections, both the Streets Text Report and Streets Multiple-Period Text Report will be disabled.

Print a Report

- 1. There are four options for printing a report:
 - a. Selecting *File > Print* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar and then selecting "Print"



b. Selecting *File > Print Preview* from the main menu; this can be found by selecting "File" in the top left-hand corner of the screen above the toolbar and then selecting "Print Preview"



- c. Using the keyboard shortcut "Ctrl+P" for Print
- d. Selecting the Print icon in the toolbar; this can be found in the top left-hand corner of the screen in the toolbar; it is the fourth icon from the left and has an image of a printer [HcS Streets [Streets MotorizedVehicle.xs]



- 2. Print
 - a. Using Print will bring up a Print dialog box where you can select which printer to print to
- 3. Print Preview
 - a. Using Print Preview will bring up a window where you can view how the report will look on paper before sending it to the printer
 - b. The print icon in the toolbar found in the top left-hand corner can then be selected
 - c. A print dialog box will pop up where you can select which printer to print to

Glossary of Terms

Acceleration Rate

Description: This entry specifies the average constant acceleration rate.

Impact on model results: Accel-decel delays affect the computation of uniform stops and uniform queue. This entry also affects access point operations.

Access Point Critical Gap Time

Description: This entry specifies the critical gap required for left-turners from the major street at an access point.

Impact on model results: This entry affects access point operations. Access point operations are used to modify the proportion of arrivals on green for downstream major-street movements. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

Access Point Deceleration Rate

Description: This entry specifies the average constant deceleration rate in response to turning vehicles.

Impact on model results: This entry affects access point operations. Access point operations are used to modify the proportion of arrivals on green for downstream major-street movements. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

Access Point Dropdown

Description: The access point dropdown control allows the user to switch between active access points, for editing input data.

Impact on model results: None

Access Point Follow Up Time

Description: This entry specifies the follow-up time required for left-turners from the major street at an access point.

Impact on model results: This entry affects access point operations. Access point operations are used to modify the proportion of arrivals on green for downstream major-street movements. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

Access Point Lanes

Description: This entry specifies lane geometry at the active (i.e., more than 10 veh/h) unsignalized access point.

Impact on model results: Access point operations are used to modify the proportion of arrivals on green for downstream major-street movements. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

Access Point Location

Description: This entry specifies the distance from the active (i.e., more than 10 vph) unsignalized access point to the upstream signalized intersection.

Impact on model results: Access point operations are used to modify the proportion of arrivals on green for downstream major-street movements. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

Access Point Maximum Bay Length

Description: This entry specifies the maximum length of a turn bay, at an access point.

Impact on model results: This entry affects access point operations. Access point operations are used to modify the proportion of arrivals on green for downstream major-street movements. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

Access Point Name

Description: This entry is used to document the name of the active (i.e., more than 10 vph) unsignalized access point.

Impact on model results: None

Access Point Peak Hour Factor

Description: This entry specifies the proportion of access point volume occurring in the peak 15 minutes. Peak 15-minute volume is computed as the hourly volume divided by four times the PHF.

Impact on model results: The PHF (when lower than 1.0) simply factors up the associated movement volume, to reflect increased flow rates during the peak 15-minute period. Access point volumes affect the proportion of arrivals on green for downstream major-street movements.

Access Point Right Turn Equivalency

Description: This entry specifies the ratio of through to right-turn saturation flow rate, at an access point.

Impact on model results: This entry affects access point operations. Access point operations are used to modify the proportion of arrivals on green for downstream major-street movements. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

Access Point Right Turn Speed

Description: This entry specifies the average turn speed for a right-turn maneuver at an access point.

Impact on model results: This entry affects access point operations. Access point operations are used to modify the proportion of arrivals on green for downstream major-street movements. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

Access Point Volumes

Description: This entry specifies movement volumes at the active (i.e., more than 10 vph) unsignalized access point. When the analysis contains more than one time period, access point volumes can be entered in units of vehicles per period.

Impact on model results: Access point operations affect the proportion of arrivals on green for downstream major-street movements. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

Additional RCUT Inputs

Description: This button opens a dialog box for the user to input the U-Turn Crossover Median Width and Conventional RCUT Demands.

Impact on model results: This button is only applicable to RCUT alternative intersection and is necessary for the completion of one RCUT alternative intersection.

Agency or Company

Description: This entry documents the agency or company associated with this analysis or project.

Impact on model results: None

All Segment Lengths

Description: This pop-up dialog allows the user to specify all segment lengths on one form. This dialog is only available when intersections can be assumed to be located in a straight line, and when intersection drag-and-drop has not been performed within Visual Mode. Segments are only relevant when there is more than one intersection within the analysis.

Impact on model results: Segment lengths are used in the computation of travel speeds and vehicle delays.

Allow Optimization

Description: This checkbox allows the user to suppress optimization at certain intersections, during an optimization run. Turning off the Allow Optimization checkbox at intersections that are already performing well (level of service A or B) can sometimes make the optimization process more efficient, by allowing it to focus on re-timing the poorly-performing intersections.

Impact on model results: This entry is only applicable to optimization runs.

Alternative Intersection

Description: This checkbox allows the user to convert a conventional intersection into one of the available alternative intersections. Checking this will enable the Intersection Type combo box.

Impact on model results: None

Analysis Time Period

Description: This entry documents the time period covered by the analysis.

Impact on model results: None

Analysis Time Period Duration

Description: This entry specifies the length of time (T) during which flow is assumed to remain constant. If T is equal to one hour, the PHF for each movement should be set to 1.00.

Impact on model results: If the degree of saturation (v/c) exceeds 0.90, control delay is significantly affected by the value of T.

Analysis Year

Description: This entry documents the year for which the analysis is being performed.

Impact on model results: None

Analyst

Description: This entry documents the individual performing the analysis.

Impact on model results: None

Area Type

Description: This entry specifies whether or not the intersection is in a central business district (CBD) type of environment. An intersection is considered to be in a CBD, or a similar type of area, when its characteristics include narrow street rights-of-way, frequent parking maneuvers, vehicle blockages, taxi and bus activity, small-radius turns, limited use of exclusive turn lanes, high pedestrian activity, dense population, and mid-block curb cuts. The average saturation headway of vehicles at intersections in areas with these characteristics will be significantly longer than those found at similar intersections but in more suburban settings.

Impact on model results: The "CBD or similar" selection decreases the saturation flow rate for all movements by 10%, resulting in higher delays, travel times, queues, etc. The "Other" selection has no impact on model results, except to avoid saturation flow rate reductions that would have been caused by "CBD or similar".

Arrival Type

Description: Arrival type is used to describe the quality of signal progression for the corresponding movement group. Values of arrival type range from 1 to 6. An arrival type of 1 represents poor progression, whereas an arrival type of 6 represents excellent progression. An arrival type of 3 represents random vehicle arrivals. Arrival type 1 is characterized by a dense platoon of more than 80 percent of the movement group volume arriving at the start of the red interval. This arrival type is often associated with shorter segments. If the two signals are not coordinated, then poor progression will likely exist for both travel directions. If coordination is provided for only one direction of travel, then poor progression may exist for the other direction. Arrival type 2 is characterized by a moderately dense platoon arriving in the middle of the red interval or a dispersed platoon containing 40 to 80 percent of the movement group volume arriving throughout the red interval. Arrival type 3 describes one of two conditions. If the signals bounding the segment are coordinated, then this arrival type is characterized by a platoon containing less than 40 percent of the movement group volume arriving partially during the red interval and partly during the green interval. If the signals are not coordinated, then this arrival type is characterized by platoons that arrive at the subject intersection at different points in time over the course of the analysis period such

that arrivals are effectively random. Arrival type 4 is characterized by a moderately dense platoon arriving in the middle of the green interval or a dispersed platoon containing 40 to 80 percent of the movement group volume arriving throughout the green interval. Arrival type 5 is characterized by a dense platoon of more than 80 percent of the movement group volume arriving at the start of the green interval. This arrival type may occur on shorter segments with a low-to-moderate number of side street entries and good signal coordination. Arrival type 6 is characterized by a dense platoon of more than 80 percent of the movement group volume arriving during the green interval. This arrival type occurs only on short segments with negligible side street entries and near-ideal signal coordination. It is reserved for exceptional progression quality on routes with near-ideal characteristics.

Impact on model results: Within the computational procedure, arrival type (AT) is first converted to a platoon ratio (Rp = AT / 3) for each movement. Next, platoon ratio is converted to a proportion of arrivals on green (ProportionOnGreen = Rp * g / C) for each movement. If upstream signal information has been entered, PortionOnGreen is automatically recalculated to reflect the expected vehicle arrival pattern from the upstream intersection. PortionOnGreen impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

Average Passenger Trip Length (multimodal)

Description: This entry specifies the average passenger trip length along a particular transit route.

Impact on model results: Average passenger trip length is used to determine the impact of late departures on overall trip speed, and is used to compute the perceived travel time factor.

Base Saturation Flow Rate

Description: The base saturation flow rate represents the expected average flow rate for a through traffic lane having geometric and traffic conditions that correspond to a value of 1.0 for each adjustment factor. Typically, one base rate is selected to represent all signalized intersections in the jurisdiction (or area) within which the subject intersection is located.

Impact on model results: Adjusted saturation flow rates affect capacities and queue service times, which in turn affect many aspects of the overall model; including control delay, time until onset of queue spillback, queue lengths, and travel time.

Base Travel Time Rate (multimodal)

Description: This entry should specify 6.0 min/mi (or 3.73 min/km in metric) for the central business district of a metropolitan area with 5 million persons or more; otherwise use 4.0 min/mi (or 2.49 min/km in metric).

Impact on model results: Base travel time rate is used to compute the transit wait-ride score.

Bicycle Lane Width (multimodal)

Description: This entry specifies the width of the bicycle lane (adjacent to the outside thru vehicle lane) on the subject approach.

Impact on model results: The bicycle lane width affects the cross section width adjustment factor.

Bicycle Running Speed (multimodal)

Description: This entry specifies tan estimate of the average bicycle running speed. The best basis for this estimate is a field measurement of mid-segment bicycle speed on representative streets in the vicinity of the subject street. There are many factors that might affect bicycle speed including adjacent motor

vehicle traffic, adjacent on-street parking activity, commercial and residential driveways, lateral obstructions, and significant grades.

Impact on model results: Bicycle running speed is used to compute bicycle travel speed. Bicycle travel speed is an output measure of effectiveness, and is not used to determine bicycle level of service.

Bicycles per Hour

Description: This entry specifies the number of bicycles whose travel path is crossed by vehicles turning right from the subject approach during the analysis period. These bicycles may travel on the shoulder or in a bike lane. Any bicycle traffic operating in the right lane with automobile traffic should not be included in this count. Rather, they are ignored in the analysis because this interaction is not modeled by the procedure. The count is divided by the analysis period duration to yield an hourly flow rate.

Impact on model results: Non-zero bicycles per hour decrease the saturation flow rate for associated movements, resulting in higher delays, travel times, queues, etc.

Buffer Object Spacing (multimodal)

Description: The buffer is the distance between the outside edge of the paved roadway (or face of curb, if present) and the near edge of the sidewalk. This element of the cross section is not designed for use by pedestrians or motorized vehicles. It may be unpaved or include various vertical objects that are continuous (e.g., barrier) or discontinuous (e.g., trees, bollards) to prevent pedestrian use. If vertical objects are in the buffer, then the average spacing of those objects that are 3 feet (or 0.9 meters in metric) or more in height should be recorded.

Impact on model results: The buffer width coefficient determination is based on the presence of a continuous barrier in the buffer. When making this determination, repetitive vertical objects (e.g., trees, bollards, etc.) are considered to represent a continuous barrier if they are at least 3 feet (or 0.9 meters in metric) high and have an average spacing of 20 feet (or 6.1 meters in metric) or less.

Buffer Width (multimodal)

Description: This entry specifies the distance between the outside edge of the paved roadway (or face of curb, if present) and the near edge of the sidewalk. This element of the cross section is not designed for use by pedestrians or motorized vehicles. It may be unpaved or include various vertical objects that are continuous (e.g., barrier) or discontinuous (e.g., trees, bollards) to prevent pedestrian use. If vertical objects are in the buffer, then the average spacing of those objects that are 3 feet (or 0.9 meters in metric) or more in height should also be recorded.

Impact on model results: Buffer width is used to compute the available sidewalk width.

Bus Blockage Time

Description: The saturation flow rate adjustment factor for bus blockage accounts for the impact of local transit buses that stop to discharge or pick up passengers at a near-side or far-side bus stop within 250 feet (or 76.2 meters in metric) of the stop line (upstream or downstream). This factor should only be used when stopping buses block traffic flow in the subject lane group. The bus blockage adjustment factor assumes an average bus blockage time of 14.4 seconds during the green indication.

Impact on model results: Higher bus blockage times decrease saturation flow rates for their associated movements; resulting in higher delays, travel times, queues, etc.

Bus Stops per Hour

Description: This entry specifies the number of local buses that block traffic flow in a movement group within 250 feet (or 76.2 meters in metric) of the stop line (upstream or downstream), as measured during the analysis period. A local bus is a bus that stops to discharge or pick up passengers at a bus stop. The stop can be on the near side or the far side of the intersection. If more than 250 buses per hour exist, a practical limit of 250 should be used.

Impact on model results: Non-zero bus stops per hour decrease the saturation flow rate for associated movements, resulting in higher delays, travel times, queues, etc.

Calculate Emissions

Description: This button updates the Emissions Output displayed in the Safety and Emission dialog box.

Impact on model results: None

Calculate Safety

Description: This button updates the Safety Output displayed in the Safety and Emission dialog box.

Impact on model results: None

Circulating Pedestrian Volume (multimodal)

Description: This entry specifies the total number of pedestrians traversing the corner but never entering the intersection. For example, on the eastbound approach, circulating pedestrians on the eastbound sidewalk will turn southbound upon reaching the southwest intersection corner. Also on the eastbound approach, circulating pedestrians on the northbound (western-most) sidewalk will turn westbound upon reaching the southwest corner. Eastbound circulating volume is thus the summation of eastbound sidewalk pedestrians who turn southbound (upon reaching the southwest corner) and northbound sidewalk pedestrians who turn westbound (upon reaching the southwest corner).

Impact on model results: Circulating pedestrian volume affects the corner circulation area per pedestrian.

Clear

Description: The Clear button automatically deletes all lanes from the active intersection. In some cases this may allow for faster specification of certain lane configurations.

Impact on model results: Intersection laneage has a fundamental effect on all aspects of the model results.

Conventional RCUT Demands

Description: The Conventional RCUT Demand inputs are enabled only for files specified as type RCUT in the Alternative group box. These input fields represent the movement demands at a standard 4-leg intersection.

Impact on model results: This entry is only applicable to RCUT alternative intersections. Conventional RCUT Demands are used to calculate redistributed demands (found in the greyed out individual RCUT junction demand fields) and to calculate experienced travel times.

Convergence Threshold

Description: This entry specifies the (genetic algorithm) convergence threshold in a signal timing optimization run. During optimization, the optimal function value and average function value are constantly recomputed. The optimal function value represents the best objective function value when considering all candidate timing plans in that particular generation. The average function value is the average performance index value from all candidate solutions in that particular generation. During successive generations, the optimal function value and the average function value tend to improve due to the genetic selection process. The average function value can occasionally become worse due to a "bad mutation", but the optimal function value should always stay the same or improve. Convergence is achieved when the average function value becomes sufficiently close to the optimal function value. Increasing the maximum number of generations (or decreasing the convergence threshold) tends to produce longer program running times, but better timing plans. Of course, once the global optimum solution has been reached, additional generations and tighter convergence thresholds have no additional benefit. Complex traffic networks tend to require substantially more generations of candidate solutions before an optimal solution is obtained.

Impact on model results: This entry is only applicable to optimization runs.

Corner Radius (multimodal)

Description: The corner radius describes radius of curvature at the sidewalk corner.

Impact on model results: Corner radius affects the available corner time-space.

Critical Left Turn Gap Time

Description: This entry specifies the critical gap time required for permissive left-turners at a signalized intersection.

Impact on model results: This entry affects saturation flow rates and actuated phase times for left-turns operating under protected-permissive or permissive-only phasing.

Critical Merge Gap

Description: This entry specifies the minimum gap required for merging into an adjacent lane.

Impact on model results: Critical merge gap affects the distribution of volumes and saturation flow rates among shared lane groups, and also affects access point operations.

Crossover Probability

Description: This entry specifies the (genetic algorithm) crossover probability in a signal timing optimization run. The genetic algorithm initially considers a trial population of signal timing plan candidates. Within this population a competition takes place where the weak candidates are discarded, and the strong candidates are allowed to breed and perform crossover. Following crossover, a new generation of candidate solutions is born. Low crossover probabilities result in younger generations of solutions that are more similar to the older generations, whereas high crossover probabilities result in younger generations that are less similar to the older generations. This entry may affect the number of generations needed to locate the global optimum solution.

Impact on model results: This entry is only applicable to optimization runs.

Crosswalk Closed (multimodal)

Description: If the subject crosswalk is closed in the signalized intersections procedure, then the pedestrian delay is estimated as the value obtained for the subject crosswalk, plus two increments of the delay for the perpendicular crosswalk. This adjustment reflects the additional delay pedestrians incur when crossing the other three legs of the intersection so that they can continue walking in the desired direction. The urban streets procedure must know the "distance to nearest signal-controlled crossing" if there is an identifiable pedestrian path that (*a*) intersects the segment and continues on beyond the segment and (*b*) on which most crossing pedestrians travel. This entry defines the distance pedestrians must travel along the segment should they divert from the path to cross the segment at the nearest signalized crossing. The crossing will typically be at a signalized intersection. However, it may also be at a signalized crosswalk provided at a mid-segment location. If the crossing is at a signalized intersection, it will likely occur in the crosswalk on the side of the intersection that is nearest to the segment. Occasionally, it will be on the far side of the intersection because the near-side crosswalk is closed (or a crossing at this location is otherwise prohibited). This distance is measured along one side of the subject segment; the methodology accounts for the return distance once the pedestrian arrives at the other side of the segment.

Impact on model results: Crosswalk Closed is used to compute the pedestrian diversion delay.

Crosswalk Length (multimodal)

Description: Crosswalk length is measured from outside edge to outside edge of road pavement (or curb to curb, if present) along the marked pedestrian travel path.

Impact on model results: Crosswalk length affects the available crosswalk time-space, and the pedestrian service time.

Crosswalk Width (multimodal)

Description: The crosswalk width represents an effective width. Unless there is a known width constraint, the crosswalk's effective width should be the same as its physical width. A width constraint may be found when vehicles are observed to regularly encroach into the crosswalk area, or when an obstruction in the median (e.g., a signal pole, or reduced-width cut in the median curb) narrows the walking space.

Impact on model results: Crosswalk width affects the available crosswalk time-space, the time-space occupied by turning vehicles, and the pedestrian service time.

Curb-to-Curb Street Width (multimodal)

Description: This entry specifies the width of the cross street as measured along the outside through vehicle lane on the subject approach, between the extended curb line limits of the cross street.

Impact on model results: The street width affects the cross section width adjustment factor.

Cycle Length Increment

Description: This entry specifies the cycle length increments to be considered in a signal timing optimization run. For example, for cycle lengths in the range of 80-100 seconds with a 5-second increment, the optimization process would consider cycle lengths of 80, 85, 90, 95, and 100 seconds.

Impact on model results: This entry is only applicable to optimization runs.

Cycle Length Optimization Flag

Description: This entry specifies whether or not cycle lengths are to be optimized in a signal timing optimization run.

Impact on model results: This entry is only applicable to optimization runs.

Dallas Phasing

Description: This entry potentially allows left-turn movements to operate in the protected-permitted mode without causing a "yellow trap" safety concern. It effectively ties the left-turn's permitted period signal indication to the opposing through signal indication.

Impact on model results: The Dallas phasing mode is considered when computing queue service times and effective green times for permissive-only and protected-permissive left-turn movements. This in turn potentially affects actuated phase times and control delays for all movements.

Dallas Phasing Optimization

Description: This checkbox allows the user to request "Dallas Phasing" optimization during a Full Optimization run. When performing phasing sequence optimization, Dallas Phasing Optimization can be activated to prevent phasing sequences that would result in a "yellow trap" for the permissive left-turners. If the Phasing Sequence Optimization checkbox is selected without Dallas Phasing Optimization, the dashboard will post a warning message, but the optimization process will not modify the user's original values of Dallas Phasing. If Phasing Sequence Optimization is selected with Dallas Phasing Optimization, the optimization process will turn on Dallas Phasing when a lagging left turn is opposed by a permissive left turn, and will turn off Dallas Phasing when both left turns are leading.

Impact on model results: This entry is only applicable to optimization runs.

Date

Description: This entry documents the date on which the analysis was performed.

Impact on model results: None

Deceleration Rate

Description: This entry specifies the average constant deceleration rate in response to a red indication.

Impact on model results: Accel-decel delays affect the computation of uniform stops and uniform queue.

Delete Access Point

Description: This button is used to delete access points from the analysis. Access points can also be deleted graphically within Visual Mode.

Delete Intersection

Description: This button is used to delete intersections from the analysis. Intersections can also be deleted graphically within Visual Mode.

Delete Time Period

Description: This button is used to delete existing time periods from the analysis. When the button is clicked, the final time period will be deleted. When oversaturated conditions exist, a multiple-period analysis can more accurately capture the effects of traffic congestion. The number of time periods should be chosen such that the first and last time periods are undersaturated.

Demand

Description: This entry specifies vehicular demand for each movement. Demand flow rate represents the flow rate of vehicles arriving at the intersection. When measured in the field, this flow rate is based on a traffic count taken upstream of the queue associated with the subject intersection. This distinction is important when counting during congested periods because the count of vehicles departing from a congested approach will produce a demand flow rate that is lower than the true rate. (All uses of the word "volume" or the phrase "volume-to-capacity ratio" refer to demand volume or demand volume-to-capacity ratio.)

Demand must be provided as an hourly flow rate (veh/h) when a single analysis period is considered with HCS. If a multi-period analysis is applied (more than one analysis period), the demand input format will automatically be changed to veh/p (vehicles per analysis period). For example, for a typical 15-min analysis, the user must provide the 15-min turning movement counts.

Impact on model results: The movement demands affect most aspects of the overall model; including control delay, time until onset of queue spillback, queue lengths, and travel time.

Demand Growth

Description: This entry automatically modifies the vehicular demand volume for each movement.

Impact on model results: The movement volumes affect most aspects of the overall model; including control delay, time until onset of queue spillback, queue lengths, and travel time.

Design Speed

Description: This entry specifies the design speed of the loop ramp or diverted movement. The speed used should provide safe passage of the conflict zone for the vast majority of drivers. If a DDI is newly constructed, the design speed of the curve should be utilized to provide an estimate of speed; however, to provide safe crossing for the slowest of vehicles, it should be decreased by 5 mi/h (or 1.6 km/h in metric).

Impact on model results: The design speed is used in the computation of extra distance travel time (EDTT) for each O-D movement, which in turn is used in the computation of experienced travel time (ETT) for each O-D movement.

Design Vehicle Length

Description: This entry specifies the design length of a vehicle in feet (or meters in metric). The design vehicle length is typically 20 feet (or 6.1 meters in metric).

Impact on model results: This entry is only applicable to DDI alternative intersections. Along with freeflow speeds, clear zone widths, and the space between ramp stop bar and conflict zone, vehicle lengths contribute to the calculation of lost times that are applied to DDI off-ramp movements.

Detected Vehicle Length

Description: This entry specifies the detected length of a vehicle.

Impact on model results: Detected vehicle length is used to compute maximum allowable headways (MAH) for each actuated movement. MAH impacts many aspects of the overall model; including actuated phase times, and control delays. Detected vehicle length is also used to compute queue storage ratio.

Detector Length

Description: This entry typically specifies the length of a presence detector at the stop line. If the detector length is set equal to 1 foot, pulse mode detection is assumed. The stop line detector length represents the length of the detection zone used to extend the green indication for queue service. This detection zone is typically located near the stop line and may have a length greater than 40 feet (or 12.2 meters in metric). However, it can be located some distance upstream of the stop line and be as short as 6 feet (or 1.8 meters in metric) in length. This latter configuration typically requires a long minimum green or use of the controller's variable initial setting. If a video-image vehicle detection system is used to provide stop line detection zone plus an additional length of 5 to 10 feet (or 1.5 to 3.1 meters in metric) to account for the projection of the vehicle image into the plane of the pavement (with larger values in this range used for wider intersections).

Impact on model results: Detector lengths affect the calculation of actuated phase times. The HCM Chapter 19/31 procedures do not recognize advance detection, detector setbacks, or volume-density control. In cases such as this, where the HCM procedures may have trouble estimating phase times accurately, the "Field Measured Phase Times" feature can be used.

Diverging Diamond Data

Description: This button opens a dialog box with inputs relevant to a Diverging Diamond Interchange intersection. It will only appear when Diverging Diamond is selected under Interchange Type.

Impact on model results: None

Downstream

Description: This button open a dialog box for the user to select and open the downstream crossover junction file coded in TWSC. Once opened, the TWSC file (.xtw) becomes attached in the Streets module.

Impact on model results: This button is only applicable to MUT with TWSC alternative intersections and is necessary for the completion of one MUT with Stop Signs alternative intersection.

Downstream Intersection Width (multimodal)

Description: This entry specifies the width of the downstream intersection.

Impact on model results: Downstream intersection width affects diversion distance in cases where pedestrians choose to cross at the farthest downstream crosswalk.

Dual Entry

Description: This entry specifies whether or not a phase is to be activated (green) even though it has not received a call for service. A phase operating in dual entry is available to be called by the controller, even if no actuations have been received for this phase. A phase operating in single entry will only be called if actuations have been received. When timing a cycle, a point is reached where the next phase (or phases) to be timed is on the other side of a barrier. At this point, the controller will check the phases in each ring and determine which phase to activate. If a call does not exist in a ring, a phase designated as dual entry in that ring will be activated by the controller. If two phases are designated as dual entry in this ring, then the first phase to occur in the phase sequence is activated.

Impact on model results: Dual entry affects the amount of vehicular and pedestrian calling flow for each actuated phase, potentially affecting actuated phase times and control delays.

Dwell Time (multimodal)

Description: This entry specifies the time that the transit vehicle is stopped at the curb to serve passenger movements, including the time required to open and close the doors. It does not include time spent stopped after passenger movements have ceased (e.g., waiting for a traffic signal or waiting for a gap in traffic to re-enter the travel lane). Dwell times are typically in the range of 10-60 seconds, depending on boarding and alighting demand.

Impact on model results: Dwell time is used to compute the total delay due to the transit stop.

EDTT Data

Description: This button opens a dialog box with inputs relevant to Extra Distance Travel Time (EDTT) Data for a Single-Point Urban Interchange or a Diverging Diamond Interchange intersection. This button will only enable when either SPUI or Diverging Diamond is selected under Interchange Type.

Impact on model results: None

Excess Wait Time (multimodal)

Description: This entry specifies the average number of minutes passengers must wait at a stop past the scheduled departure time. It is measured in the field as the sum of the differences between the scheduled and actual departure times at the preceding timepoint, divided by the number of transit vehicle arrivals.

Impact on model results: Excess wait time is used to compute the perceived travel time factor, which in turn affects the transit LOS score.

Exclusive Pedestrian Phase Time

Description: This entry specifies the amount of cycle time to be used by an exclusive pedestrian phase at each intersection. Currently, this calculation is only supported for uncoordinated intersections.

Impact on model results: For uncoordinated (Chapter 19) operations, exclusive pedestrian phase times affect the cycle length computed by the procedure. The cycle length and vehicular phase times affect most aspects of the overall model; including control delay, queue lengths, and travel time.

Extension of Effective Green Time

Description: This entry specifies the amount of the change and clearance interval at the end of the phase for a lane group, usable by its vehicles.

Impact on model results: Extension of effective green times affect the calculation of actuated phase times and queue service times.

Extra Distance

Description: The entry specifies the distance traveled along the loop ramp or diverted movement in an interchange.

Impact on model results: The extra distance is used in the computation of extra distance travel time (EDTT) for each O-D movement, which in turn is used in the computation of the experienced travel time (ETT) for each O-D movement.

Field Free-Flow Speed

Description: This value can be field measured following the guidance in HCM Chapter 30 Section 5 and coded here to override the parameter computed by the procedure.

Impact on model results: This value is used to compute Percent Free-Flow Speed, which determines Level of Service using HCM Exhibit 18-1.

Field Proportion Arriving on Green

Description: Proportion arriving on green is the proportion of vehicles that arrive during the green signal indication. A procedure is described in Section 3 of Chapter 30 that can be used to estimate the arrival flow profile for an intersection approach when this approach is evaluated as part of an urban street segment. The procedure uses the profile to compute the proportion of arrivals during the green indication.

Impact on results: Control delay and queue size at a signalized intersection are highly dependent on the proportion of vehicles that arrive during the green and red signal indications. Delay and queue size are smaller when a larger proportion of vehicles arrive during the green indication.

Field Travel Speed

Description: This value can be field measured following the guidance in HCM Chapter 30 Section 5 and coded here to override the parameter computed by the procedure.

Impact on model results: This value is used to compute Percent Free-Flow Speed, which determines Level of Service using HCM Exhibit 18-1.

Field-Measured Phase Times

Description: This entry specifies that user-entered phase splits and/or maximum greens will not be modified, as they normally would be, by the computational procedure to estimate signal phase durations.

Impact on model results: When this entry is used, Streets will produce timings that match or closely approximate the Maximum Splits for that intersection, while keeping the overall configuration for a coordinated corridor (constant cycle, actuation effects, etc.).

Follow Up Left Turn Time

Description: This entry specifies the follow-up time required for permissive left-turners at a signalized intersection.

Impact on model results: This entry affects saturation flow rates and actuated phase times for left-turns operating under protected-permissive or permissive-only phasing.

Force Mode

Description: For uncoordinated (Chapter 19) operations, the force mode is not used. For coordinated (Chapter 18) operations, this entry specifies the force-off mode (fixed or floating), which governs reallocation of green time within the cycle. The controller calculates the phase force-off point for each actuated phase based on the force mode and the phase splits. When set to the fixed mode, each actuated phase has its force-off point set at a fixed time in the cycle, relative to time zero on the system master. This operation allows unused split time to revert to the following phase. When set to the floating mode, each actuated phase has its force-off point set at the split time after the phase first becomes active. This operation allows unused split time to revert to the coordinated phase via an early return to green.

Impact on model results: Changing the force mode would potentially reallocation of green time within the cycle, possibly changing the amount of green time available to each movement. The amount of available green time impacts most aspects of the overall model; including queue lengths, stops, and control delays.

Forward Segment Length

Description: This entry specifies distance from the subject intersection to the next downstream intersection, typically in the "phase 2" direction of travel.

Impact on model results: The forward segment length impacts many aspects of the overall model; including the proportion of vehicles arriving on green, time until onset of queue spillback, and travel time.

Forward Weighting

Description: This entry specifies the forward arterial weighting in a signal timing optimization run. For example, if "Travel Time" were chosen as the objective function, and if "Both Major Street Directions" were chosen as the objective function direction, the optimization process would attempt to find a timing plan that would minimize travel times that were multiplied by the forward and reverse weighting factors. This entry has no effect on the approach-specific objective functions (approach stops, approach delay).

Impact on model results: This entry is only applicable to optimization runs.

Free-Flow Speed of Vehicle

Description: This entry specifies the average speed of vehicles on a given segment, measured under low-volume conditions, when drivers are free to drive at their desired speed and are not constrained by the presence of other vehicles or downstream traffic control devices.

Impact on model results: This entry is only applicable to DDI alternative intersections. Along with clearzone widths, vehicle speeds, and the space between ramp stop bar and conflict zone, free-flow speeds contribute to the calculation of lost times that are applied to DDI off-ramp movements.

Heaviest Lane Volume

Description: This entry specifies the single-lane volume with the highest volume of each movement group.

Impact on model results: Heaviest lane volume affects the lane utilization adjustment factor, which in turn affects the adjusted saturation flow rates.

Heavy Vehicle Equivalency

Description: This entry specifies the ratio of passenger car to heavy vehicle saturation flow rate, at signalized intersections. The equivalent number of passenger cars for each heavy vehicle is typically 2.0.

Impact on model results: This entry affects the heavy vehicle adjustment factor and the adjusted saturation flow rate.

Hide Multimodal Results (multimodal)

Description: For "operations only" analyses, this checkbox can be used to hide multimodal outputs on the Results Report and the Intermediate Report.

Impact on model results: None.

Incoming Pedestrian Volume (multimodal)

Description: This entry specifies the number of pedestrians walking in the reverse direction of travel. For example, on the eastbound approach, incoming pedestrians will travel westbound on the southern-most crosswalk.

Impact on model results: Incoming pedestrian volume affects the number of pedestrians arriving at each intersection corner during each cycle, and the total number of circulating pedestrians at each corner.

Initial Queue Length

Description: This entry specifies the initial queue at the beginning of the first analysis period, either observed in the field or carried over from the computations of a previous analysis period. The initial queue for the subject period is the unmet demand from the previous period and represents the number of vehicles present in the movement group at the start of the analysis period. The value entered represents the total number of vehicles observed in the subject traffic lanes at the start of this time period. The initial queue should not include vehicles in queue due to random, cycle-by-cycle fluctuations. Initial queue is estimated as the queue count at the start of the red indication. Whether or not an initial queue value is coded for the first time period, unmet demand will be computed for each period and will be carried forward as the initial queue for the subsequent period.

Impact on model results: Initial queue analyses (in which one or more movements are coded with a non-zero initial queue length) invoke a substantially more extensive computational procedure than analyses with no initial queues. Model results (from initial queue analyses) are more likely to reflect the increased congestion caused by period-to-period unmet demand.

Inside Object Effective Width (multimodal)

Description: This entry specifies the effective width of fixed objects on the inside of the sidewalk. These objects include light poles, traffic signs, planter boxes, etc.

Impact on model results: Inside object effective width is used to compute the effective sidewalk width.

Interchange Intersection

Description: This entry specifies whether or not this intersection can be classified as being part of an interchange ramp terminal facility.

Impact on model results: Interchange intersections are potentially affected by the traffic pressure adjustment factor, additional lost time from queue spillback, additional lost time from demand starvation, and lane utilization adjustments based on the interchange type.

Interchange Type

Description: If this intersection has been flagged as an interchange intersection, this entry specifies the type of an interchange ramp terminal facility (e.g., Parclo, Diamond, SPUI).

Please refer to the following HCM exhibits for O-D and turning movements for conventional interchanges.

- Exhibit 34-162: O-D Flows for Each Interchange Configuration
- **Exhibit 34-163:** Worksheet for Obtaining O-D Movements from Turning Movements for Parclo A-2Q Interchanges
- **Exhibit 34-164:** Worksheet for Obtaining O-D Movements from Turning Movements for Parclo A-4Q Interchanges
- Exhibit 34-165: Worksheet for Obtaining O-D Movements from Turning Movements for Parclo AB-2Q Interchanges

- Exhibit 34-166: Worksheet for Obtaining O-D Movements from Turning Movements for Parclo AB-4Q Interchanges
- Exhibit 34-167: Worksheet for Obtaining O-D Movements from Turning Movements for Parclo B-2Q Interchanges
- **Exhibit 34-168:** Worksheet for Obtaining O-D Movements from Turning Movements for Parclo B-4Q Interchanges
- **Exhibit 34-169:** Worksheet for Obtaining O-D Movements from Turning Movements for Diamond Interchanges
- Exhibit 31-170: Worksheet for Obtaining O-D Movements from Turning Movements for SPUIs

Impact on model results: Lane utilization adjustments are based on the interchange type.

Intersection Depth

Description: This is the distance between the stop bar on the approach and the beginning of the downstream intersection leg.

Impact on model results: This variable defines intersection size, as: (a) Small: depth of 82 ft (or 25.0 m in metric) or less (1 or 2 lanes per approach); (b) Medium: depth between 82 ft (or 25.0 m in metric) and 131 ft (or 39.9 m in metric) (2 lanes per approach); and (c) Large: depth larger than 131 ft (or 39.9 m in metric) (3 or more lanes for at least two approaches).

Intersection Dropdown

Description: The intersection dropdown control allows the user to switch between active intersections for editing input data, and for viewing reports.

Impact on model results: None

Intersection Name

Description: This entry documents the name of the intersection being analyzed. These names can then be viewed within output reports, and within Quick Animation.

Impact on model results: None

Intersection Type

Description: When the Alternative Intersection checkbox is checked, this combo box will enable, allowing the user to convert a coded conventional intersection into an alternative intersection. The choices of Intersection Type include MUT with TWSC, RCUT, and DLT.

Median U-Turn (MUT) intersections with Two-Way Stop-Control (TWSC): At-grade intersections at which major- and minor-street left turns are rerouted. Minor-street through movements are not rerouted. U-Turn crossovers are stop-controlled instead of signalized.

Restricted Crossing U-Turn (RCUT) intersections: At-grade intersections at which minor-street left-turn and through movements are rerouted. Major-street left turns are not rerouted.

Displaced Left-Turn (DLT) intersections: At-grade intersections where left-turning vehicles cross opposing through traffic before reaching the main intersection, thus reducing conflicts at the main intersection.

Impact on model results: This entry is only applicable to Alternative Intersections.

Jurisdiction

Description: This entry documents the jurisdiction for which the analysis is being performed.

Impact on model results: None

K Factor, %

Description: The K factor is the proportion of the annual average daily traffic (AADT) that occurs in the peak hour. It is used by Streets to convert the hourly demand used by the HCM methodologies to AADT, which is used by the crash prediction model.

Impact on model results: Higher values for this variable indicate higher concentration of traffic in the peak hours and, consequently, lower AADT year-round. Since all safety models predict crashes proportionally to AADT, the higher the K factor, the lower the expected number of yearly crashes.

Lag Phase

Description: This entry specifies whether or not the associated left-turn phase occurs immediately after the opposing (through movement) phase terminates. If split phasing is in effect, this entry indicates which through movement phase (4 or 8) occurs first.

Impact on model results: Changing the phasing sequence (via Lag Phase) would potentially shift the window of major street green time to a different part of the cycle, possibly changing the proportion of arrivals on green for one or more movements. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays. The minor street phasing sequence could also affect the times during which cross street vehicles are released on to the major street, again affecting the proportion of arrivals on green.

Lane Width

Description: This entry specifies the average width of lanes represented in a movement group. The minimum average lane width is 8 feet (or 2.4 meters in metric). Standard lane widths are 12 feet (or 3.7 meters in metric). Lane widths greater than 16 feet can be included; however, the analyst should consider whether the wide lane actually operates as two narrow lanes. The analysis should reflect the way in which the lane width is actually used or expected to be used.

Impact on model results: Lane widths below 10 feet (or 3.0 meters in metric) decrease the saturation flow rate for the associated movement, resulting in higher delays, travel times, queues, etc. Lane widths above 12.9 feet (or 3.93 meters in metric) increase the saturation flow rate for the associated movement, resulting in lower delays, travel times, queues, etc.

Left Turn Equivalency

Description: This entry specifies the ratio of through to left-turn saturation flow rate, at signalized intersections.

Impact on model results: Left turn equivalency affects the distribution of saturation flow rates among lanes, which in turn affects many aspects of the overall model. Left turn equivalency also affects the computation of maximum allowable headways (MAH) for each actuated movement, which impacts actuated phase times.

Legal Mid-Segment Crossing (multimodal)

Description: This entry indicates whether a pedestrian can cross the segment at any point along its length, regardless of location. If it is illegal to make this crossing at any point, then the pedestrian is assumed to be required to divert to the nearest signalized intersection to cross the segment.

Impact on model results: If mid-segment crossing is not legal, pedestrian waiting delay should be zero. If mid-segment crossing is legal, pedestrian waiting delay should be estimated by the analyst or computed using Chapter 20 procedures.

Map X/Y Coordinate

Description: These entries specify node coordinate locations for drawing link-node geometry on the map and are only available in Visual Mode. The X coordinate is the horizontal value in a pair of coordinates and describes how far along left or right the point is from the origin (0,0). The Y coordinate is the vertical value in a pair of coordinates and describes how far or up or down the point is from the origin. (0,0).

Impact on model results: Segment lengths will be automatically re-calculated by Visual Mode as a function of node coordinates, and any segment curvature that might exist.

Map X/Y Curve Point 1 and Point 2

Description: These entries specify control point for drawing roadway curvature on the map.

Impact on model results: None

Master Intersection Number

Description: This entry specifies the master intersection number for a signal timing optimization run. Offsets for the master intersection will not be modified during an optimization run. If desired the master intersection number can be set to zero, thus allowing offsets to be modified at all intersections during an optimization run. This entry will be ignored if the master intersection number does not match any of the intersection numbers within the dataset.

Impact on model results: This entry is only applicable to optimization runs.

Maximum Cycle Length

Description: This entry specifies the maximum candidate cycle length to be considered in a signal timing optimization run.

Impact on model results: This entry is only applicable to optimization runs.

Maximum Green

Description: For uncoordinated (Chapter 19) operations, this entry specifies the maximum amount of time that a green signal indication can be displayed in the presence of conflicting demand. For coordinated (Chapter 18) operations, maximum green is not used.

Impact on model results: The amount of available green time impacts most aspects of the overall model; including queue lengths, stops, and control delays. This entry is applicable only when Uncoordinated Intersection is checked.

Maximum Number of Generations

Description: This entry specifies the (genetic algorithm) maximum number of generations in a signal timing optimization run. During optimization, the optimal function value and average function value are constantly recomputed. The optimal function value represents the best objective function value when considering all candidate timing plans in that particular generation. The average function value is the average performance index value from all candidate solutions in that particular generation. During successive generations, the optimal function value and the average function value tend to improve due to

the genetic selection process. The average function value can occasionally become worse due to a "bad mutation", but the optimal function value should always stay the same or improve. Convergence is achieved when the average function value becomes sufficiently close to the optimal function value. Increasing the maximum number of generations (or decreasing the convergence threshold) tends to produce longer program running times, but better timing plans. Of course, once the global optimum solution has been reached, additional generations and tighter convergence thresholds have no additional benefit. Complex traffic networks tend to require substantially more generations of candidate solutions before an optimal solution is obtained.

Impact on model results: This entry is only applicable to optimization runs.

Maximum Platoon Headway

Description: This entry specifies the maximum time headway that defines a platooned vehicle.

Impact on model results: This entry affects access point operations. Access point operations are used to modify the proportion of arrivals on green for downstream major-street movements. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

Median Type (multimodal)

Description: The median type is designated as undivided, non-restrictive (e.g., two-way left-turn lane), or restrictive (e.g., raised curb).

Impact on model results: Median type affects the cross section width adjustment factor.

Mid-Segment 85th-Percentile Speed (multimodal)

Description: The 85th percentile speed represents the speed of the vehicle whose speed is exceeded by only 15% of the population of vehicles. The speed of interest is that of vehicles traveling along the street approaching the subject intersection. It is measured at a location that is sufficiently distant from the intersection that speed is not influenced by intersection operation. This speed is likely to be influenced by traffic conditions, so it should reflect the conditions present during the analysis period.

Impact on model results: The 85th percentile speed affects the motorized vehicle speed adjustment factor.

Minimum Cycle Length

Description: This entry specifies the minimum candidate cycle length to be considered in a signal timing optimization run.

Impact on model results: This entry is only applicable to optimization runs.

Minimum Green

Description: This entry specifies the shortest amount of time that a green signal indication will be displayed for a movement. It is input for each non-coordinated signal phase. Its duration is based on considerations of driver reaction time, queue length, and driver expectancy. Minimum green may be as short as 3 seconds for a left-turn phase, and 5 to 10 seconds for a through movement. For intersections without pedestrian push buttons, the minimum green interval may also need to be sufficiently long to allow a pedestrian to cross during the concurrent vehicular phase.

Impact on model results: Minimum green time affects the amount of available green time, which impacts most aspects of the overall model; including queue lengths, stops, and control delays. Minimum green time may also affect the probability of traffic accidents under certain conditions.

Minimum Platoon Headway

Description: This entry specifies the minimum time headway between vehicles traveling in a platoon.

Impact on model results: This entry affects access point operations. Access point operations are used to modify the proportion of arrivals on green for downstream major-street movements. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

MUT Segment Free-Flow Speed

Description: When the Alternative Intersection checkbox is checked and the Intersection Type selected is MUT with TWSC, fields for Segment Free-Flow Speed will enable.

Impact on model results: This entry affects the Extra Distance Travel Time (EDTT) for the movements that are rerouted as a result of converting to the alternative intersection.

MUT Segment Length

Description: When the Alternative Intersection checkbox is checked and the Intersection Type selected is MUT with TWSC, fields for Segment Length will enable.

Impact on model results: This entry affects the Extra Distance Travel Time (EDTT) for the movements that are rerouted as a result of converting to the alternative intersection.

Mutation Probability

Description: This entry specifies the (genetic algorithm) mutation probability in a signal timing optimization run. Mutation is an arbitrary modification of randomly selected genes. The proportion of mutated genes is affected by the mutation probability. The mutation process prevents the gene pool from becoming stale and failing to recognize new possibilities. In addition, the mutation process allows the genetic algorithm to locate the global optimum solution instead of a local optimum solution. Beware that excessively high mutation probabilities may significantly increase the amount of time required for optimization, or may prevent optimization altogether. If the optimization process is converging too quickly, or if the analyst wishes to examine a wider range of timing plan possibilities, then increasing the mutation probability may be helpful. If the optimization process is not converging quickly enough, or if the analyst wishes to acquire a reasonable and effective local optimum solution, then decreasing the mutation probability may be helpful.

Impact on model results: This entry is only applicable to optimization runs.

Nearest Signal Distance (multimodal)

Description: This input parameter is needed if there is an identifiable pedestrian path that (*a*) intersects the segment and continues on beyond the segment and (*b*) on which most crossing pedestrians travel. This entry defines the distance pedestrians must travel along the segment should they divert from the path to cross the segment at the nearest signalized crossing. The crossing will typically be at a signalized intersection. However, it may also be at a signalized crosswalk provided at a mid-segment location. If the crossing is at a signalized intersection, it will likely occur in the crosswalk on the side of the intersection that is nearest to the segment. Occasionally, it will be on the far side of the intersection because the near-side crosswalk is closed (or a crossing at this location is otherwise prohibited). This distance is measured along one side of the subject segment; the methodology accounts for the return distance once the pedestrian arrives at the other side of the segment.

Impact on model results: Nearest signal distance is used to compute diversion delay.

New Access Point

Description: This button is used to add new access points to the analysis. New access points can also be added graphically within Visual Mode.

New Intersection

Description: This button is used to add new intersections to the analysis. New intersections can also be added graphically within Visual Mode.

New Time Period

Description: This button is used to add new time periods to the analysis. When the button is clicked a new, final time period will be added at the end of all existing time periods. When oversaturated conditions exist, a multiple-period analysis can more accurately capture the effects of traffic congestion. The number of time periods should be chosen such that the first and last time periods are undersaturated.

Number of Active Access Points

Description: This entry specifies the number of active access points on the segment. Unlike the "non-active" access points for which volumes, laneage, and locations are not coded, these access points serving more than 10 vehicles per hour.

Impact on model results: Active access points affect the proportion of vehicles arriving on green at the downstream intersection.

Number of Intersections

Description: This entry specifies the number of intersections in a brand-new dataset. After the new dataset is created, intersections can be added or deleted at any time.

Number of Iterations

Description: This entry specifies a number of model iterations for the computation of actuated phase times. Queue service times are dependent on green interval durations. This dependency introduces a circularity in the calculation process. Thus, the procedure is iterative, where an initial estimate of green interval duration is provided and the green interval duration is re-computed. The computed duration is compared with the initial estimate and, if they are different, then the computed value becomes the new initial estimate and the procedure is repeated. Iterations are repeated until the initial estimate and computed green interval duration are equal.

Impact on model results: If the number of model iterations is too small, this could compromise the accuracy of the model. Higher numbers of model iterations may require longer computation times on the computer. The number of model iterations may have no impact on the model results of intersections under pre-timed operation (indicated by max recall on every phase).

Number of Lanes

Description: This entry specifies the number of intersection lanes available for use by each movement. For through movements, this would include shared L+T, T+R, and L+T+R lanes. For left-turn and right-turn movements, only the number of exclusive (non-shared) turn lanes should be entered. The procedure does not explicitly allow specification of L+R approaches with zero through vehicles; such as a one-lane approach with L+R, or a two-lane approach with LT-only and RT-only. Mechanics of the analysis for a one lane approach with L+R should be the same as for a one-lane approach with L+T+R and a through volume equal to 1 vph. Mechanics of the analysis for a two-lane approach with LT-only and RT-only.

only should be the same as when the approach is coded having one exclusive left-turn lane (LT-only), one shared through-right lane T+R, and a through volume equal to 1 vph. Alternatively, mechanics of the analysis for a two-lane approach with LT-only and RT-only should also be the same as when the approach is coded as having two lanes with L+T+R and a through volume equal to 1 vph.

Impact on model results: Intersection laneage has a fundamental effect on all aspects of the model results.

Number of Periods

Description: This entry specifies the number of time periods in a brand-new dataset. After the new dataset is created, periods can be added or deleted at any time.

Number of Receiving Lanes

Description: This entry specifies the count of lanes departing the intersection. This number should be separately determined for each left-turn and right-turn movement. Experience indicates that proper turning cannot be executed at some intersections because a receiving lane is frequently blocked by double-parked vehicles. For this reason, the number of receiving lanes should be determined from field observation whenever possible.

Impact on model results: The number of receiving lanes affects the ped-bike saturation flow rate adjustment calculations.

Number of Right-Turn Islands (multimodal)

Description: This entry specifies the number of right-turn channelizing islands along the crosswalk.

Impact on model results: The number of right-turn islands affects the motorized vehicle volume adjustment factor.

Number of Transit Stops (multimodal)

Description: This entry specifies the number of transit stops on the segment for the subject route.

Impact on model results: The number of transit stops affects the transit vehicle segment running speed.

O-D Seeds

Description: This entry specifies the average proportion of vehicle volumes that travel from each upstream (origin) movement to each downstream (destination) movement.

The volume of traffic that arrives at a downstream intersection for a given downstream movement represents the combined volume from each upstream point of entry weighted by its percentage contribution to the downstream exit movement. The distribution of these contribution percentages between each upstream and downstream pair is represented as an origin-destination distribution matrix.

The origin-destination matrix is important for estimating the arrival pattern of vehicles at the downstream intersection. Hence, the focus here is on upstream entry movements that are signalized, because (*a*) they are typically the higher-volume movements and (*b*) the signal timing influences their time of arrival downstream. For these reasons, the origin-destination distribution is focused on the three upstream signalized movements. All other movements (i.e., unsignalized movements at the boundary intersections, access point movements, RTOR movements) are combined into one equivalent movement—referred to hereafter as the "access point" movement—that is assumed to arrive uniformly throughout the signal cycle.

The use of seed percentages allows the procedure to adapt the origin-destination volume estimates to factors or geometric situations that induce greater preference for some entry-exit combinations than is suggested by simple volume proportion (e.g., a downstream freeway on-ramp). The default seed proportions are listed in HCM Exhibit 30-2:

	Seed Proportion by	Origin Moveme	ent	Destination
Left	Through	Right	Access Point	Movement
0.02	0.10	0.05	0.02	Left
0.91	0.78	0.92	0.97	Through
0.05	0.10	0.02	0.01	Right
0.02	0.02	0.01	0.00	Access point
1.00	1.00	1.00	1.00	

Movements within the O-D matrix are dependent on the major-street and Forward Direction. The upstream intersection movements refer to the movements heading toward the downstream intersection. The downstream intersection movements refer to the movements in the downstream intersection of the forward direction approach. For example, when the major-street is East-West and the Forward Direction is EB, the Upstream Intersection 1 movements are as follows: L refers to SBL, T refers to EBT, R refers to NBR, and M refers to "access point" movements. The Downstream Intersection 2 are as follows: L refers to EBL, T refers to EBT, R refers to EBR, and M refers to "access point" movements.

Example of corresponding movements in O-D matrix:

Left Origin and Right Destination: if the major-street is East-West and the Forward Direction is EB, then the 0.05 found below in red in the O-D matrix refers to the southbound left-turn movement from Intersection 1 (upstream intersection) and the eastbound right-turn movement from Intersection 2 (downstream intersection).



Impact on model results: This entry is not used unless more than one intersection is being analyzed by the (Chapter 18) procedure. Changing the O-D seeds could affect the proportion of arrivals on green throughout the urban street system. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

Offset

Description: This entry specifies the difference between the start of green time for the reference interval at the subject intersection, and a specified time datum in a system of signalized intersections. The offset is used to coordinate timing plans at adjacent intersection along an urban street, ideally allowing vehicles to pass through multiple intersection without stopping.

Impact on model results: For uncoordinated (Chapter 19) operations, the offset is not used. For coordinated (Chapter 18) operations, offsets affect many aspects of the overall model; including travel speeds, travel times, stops, and control delays.

Offset Optimization Flag

Description: This entry specifies whether or not offsets are to be optimized in a signal timing optimization run.

Impact on model results: This entry is only applicable to optimization runs.

On-Ramp Left Lane Shared

Description: This checkbox indicated if the specified left-turn movement is in a shared left-thru lane.

Impact on results: This entry is only applicable to DDI intersection. For DDI in Streets, a coded majorstreet exclusive left-turn lane is necessary for the lane configuration. However, this checkbox allows the user to specify if that left-turn is in a shared lane. If true, calculation are done internally with consideration of the shared lane.

On-Street Parking

Description: This entry specifies the percent of on-street parking on the link, which is converted to a proportion for calculations. The proportion of the segment with on-street parking represents that portion of the link length that has parking stalls (either marked or unmarked) available along the right side of the segment. This proportion is computed as the length of street with parking stalls divided by the link length. Parking stalls considered include those described as having either a parallel or angle design. This proportion is separately computed for each direction of travel along the segment.

Impact on model results: On-Street Parking is used in the computation of segment free-flow speed; which in turn affects segment running times, and the proportion of vehicle arrivals on green.

Open RCUT File

Description: This button opens a dialog box for the user to select and open the second RCUT file to complete the coded RCUT.

Impact on model results: This button is only applicable to RCUT alternative intersections and is necessary for the completion of one RCUT alternative intersection.

Opposing Right-Turn Lane Influence

Description: This entry specifies whether or not permitted left turners are influenced by exclusive rightturn lanes on the opposing approach. This determination should be based on knowledge of local driver behavior, traffic conditions, and intersection geometry.

Impact on model results: When opposing right-turn lane influence exists, this decreases permitted left-turn capacity. When opposing right-turn lane influence does not exist, this increases permitted left-turn capacity.

Optimization Objective Function

Description: This entry specifies the objective function to be considered in a signal timing optimization run. For example, if "travel time" were chosen as the objective function, the optimization process would attempt to find a timing plan that would minimize travel time.

Impact on model results: This entry is only applicable to optimization runs.

Optimization Objective Function Direction

Description: This entry specifies the objective function direction to be considered in a signal timing optimization run. The available options are "Both Major Street Directions", "Forward Major Street Direction", "Reverse Major Street Direction", and "All Approaches". For example, if "Travel Time" were chosen as the objective function, and if "Reverse Major Street Direction" were chosen as the objective function process would attempt to find a timing plan that would minimize travel times in the urban street reverse direction. The "Forward Major Street Direction" and "Reverse Major Street Direction" and "Reverse Major Street Direction" and "Reverse Major Street Direction" selections are tantamount to applying 100% objective function weighting to the chosen direction, and 0% objective function weighting to the opposite direction. If the "Both Major Street Directions" selection or "All Approaches" selection is chosen in conjunction with arterial objective function. The analyst can specify unequal arterial weightings using the "Forward Direction Weighting" and "Reverse Direction Weighting" entries, if desired.

Impact on model results: This entry is only applicable to optimization runs.

Outgoing Pedestrian Volume (multimodal)

Description: This entry specifies the number of pedestrians walking in the forward direction of travel. For example, on the eastbound approach, outgoing pedestrians will travel eastbound on the southern-most crosswalk.

Impact on model results: Outgoing pedestrian volume affects the number of pedestrians arriving at each intersection corner during each cycle, and the total number of circulating pedestrians at each corner.

Outside Object Effective Width (multimodal)

Description: This entry specifies the effective width of fixed objects on the outside of the sidewalk.

Impact on model results: Outside object effective width is used to compute the effective sidewalk width.

Outside Thru Lane Width (multimodal)

Description: This entry specifies the width of the outside thru vehicle lane on the subject approach.

Impact on model results: The outside thru lane width affects the cross section width adjustment factor.

Parking Exists

Description: This entry indicates that on-street parking spaces exist within 250 feet (76.2 meters in metric) of the intersection (regardless of whether or not parking maneuvers take place). This entry indicates whether on-street parking is allowed along the curb line adjacent to a movement group and within 250 feet (76.2 meters in metric) upstream of the stop line during the analysis period. On a one-way street with no exclusive turn lanes, the presence of on-street parking is separately noted for each side of the street.

Impact on model results: The existence of parking decreases the saturation flow rate for associated movements, resulting in higher delays, travel times, queues, etc. Note that parking conditions with zero maneuvers have a different impact than a no-parking situation.

Parking Lane Width (multimodal)

Description: This entry specifies the width of the parking lane on the subject approach.

Impact on model results: The parking lane width affects the cross section width adjustment factor.

Parking Maneuver Time

Description: This entry specifies the amount of time (default: 18 seconds) needed by a driver to execute a parking maneuver.

Impact on model results: The parking maneuver time affects the parking adjustment factor, which is used to adjust the saturation flow rates.

Parking Maneuvers per Hour

Description: This entry specifies the number of parking maneuvers that occur directly adjacent to a movement group and within 250 feet (76.2 meters in metric) upstream of the stop line, as measured during the analysis period. A maneuver occurs when a vehicle enters or exits a parking stall. If more than 180 maneuvers per hour exist, a practical limit of 180 should be used. On a one-way street with no exclusive turn lanes, maneuvers are separately counted for each side of the street. The count is divided by the analysis period duration to yield an hourly flow rate.

Impact on model results: Non-zero parking maneuvers per hour decrease the saturation flow rate for associated movements, resulting in higher delays, travel times, queues, etc. Note that parking conditions with zero maneuvers have a different impact than a no-parking situation.

Passage Time

Description: This entry specifies the maximum amount of time one vehicle actuation can extend the green interval when green is displayed. It is input for each non-coordinated signal phase. It is also referred to as vehicle interval, extension interval, extension, or unit extension. The passage timer starts to time from the instant the vehicle actuation is removed. A subsequent actuation will reset the passage timer. When the passage timer reaches the passage time setting and there is an actuation on a conflicting phase, the phase will terminate by gap out. Passage time values are typically chosen based on consideration of detection zone length, detection zone location (relative to the stop line), number of lanes served by the phase, and vehicle speed. Longer passage times are often used with shorter detection zones, greater distance between the zone and stop line, fewer lanes, and slower speeds. The objective when determining the passage time value is to make it large enough to ensure that all queued vehicles are served but to not make it so large that it extends for randomly arriving traffic. On high-speed approaches, this objective is broadened to include not making the passage time so large that the phase frequently extends to its maximum setting (i.e., maxes-out) such that safe phase termination is compromised.

Impact on model results: Passage time is used to compute maximum allowable headways (MAH) for each actuated movement. MAH impacts many aspects of the overall model; including actuated phase times, and control delays.

Passenger Load Factor (multimodal)

Description: This entry specifies the number of passengers occupying the transit vehicle divided by the number of seats on the vehicle. If the number of passengers equals the number of seats, then the load factor equals 1.0. This factor should be measured in the field or obtained from the agency serving the transit route. It is an average value for all of the scheduled fixed route transit vehicles that travel along the segment during the analysis period.

Impact on model results: Passenger load factor is used to compute the perceived travel time rate.

Paved Shoulder Width (multimodal)

Description: This entry specifies the width of the paved outside shoulder on the subject approach.

Impact on model results: The paved shoulder width affects the cross section width adjustment factor.

Pavement Condition Rating (multimodal)

Description: This entry, which ranges from 0.0 to 5.0, describes the road surface in terms of ride quality and surface defects. PCR values of 4.0 or higher imply new or nearly new superior pavement; free of cracks and/or patches, and allowing a good ride. PCR values of 1.0 or lower imply distress over at least 75% of the surface; with large potholes and/or deep cracks, and an uncomfortable ride.

Impact on model results: Pavement condition rating affects the bicycle level of service score for the "link".

Peak-Hour Factor

Description: This entry specifies the proportion of peak-hour volume occurring in the peak 15 minutes. Peak 15-minute volume is computed as the hourly volume divided by four times the PHF.

Impact on model results: The PHF (when lower than 1.0) simply factors up the associated movement volume, to reflect increased flow rates during the peak 15-minute period.

Pedestrian Free-Flow Speed (multimodal)

Description: This entry specifies the average desired walking speed of all pedestrians on this particular sidewalk.

Impact on model results: The (average) free-flow walk speed is used to compute the (average) actual walk speed. Increasing two-way pedestrian volumes cause actual walk speeds to become increasingly lower than free-flow walk speeds. Decreasing effective sidewalk widths cause actual walk speeds to become increasingly lower than free-flow walk speeds.

Pedestrian Signal Head (multimodal)

Description: The presence of a pedestrian signal head influences pedestrian crossing behavior. If a pedestrian signal head is provided, then pedestrians are assumed to use the crosswalk during the WALK and flashing DON'T WALK indications. If no pedestrian signal heads are provided, then pedestrians will cross during the green indication provided to vehicular traffic.

Impact on model results: The presence of a pedestrian signal head affects the effective walk time for all phases.

Pedestrian Waiting Delay (multimodal)

Description: This entry specifies the delay incurred when pedestrians wait at an uncontrolled crossing location, if this type of crossing is legal.

Impact on model results: Pedestrian waiting delay affects the roadway crossing difficulty factor.

Pedestrians per Hour

Description: This entry specifies the number of pedestrians traveling in the crosswalk that is crossed by vehicles turning right from the subject approach during the analysis period. For example, the pedestrian flow rate for the westbound approach would describe the pedestrian flow in the crosswalk on the north leg. The count is divided by the analysis period duration to yield an hourly flow rate.

Impact on model results: Non-zero pedestrians per hour decrease the saturation flow rate for associated movements, resulting in higher delays, travel times, queues, etc.
Percent Grade

Description: Approach grade defines the average grade along the approach, as measured along a line parallel to the direction of travel and from the stop line to a point 100 feet (30.5 meters in metric) upstream of the stop line. An uphill condition has a positive grade, and a downhill condition has a negative grade.

Impact on model results: Upgrades (above zero) decrease the saturation flow rate for associated movements, resulting in higher delays, travel times, queues, etc. Downgrades (below zero) increase the saturation flow rate for associated movements, resulting in lower delays, travel times, queues, etc.

Percent Trucks

Description: This entry specifies the percentage of trucks (heavy vehicles) in the traffic stream for each movement. A heavy vehicle is defined as any vehicle with more than four tires touching the pavement. Local buses that stop near the intersection (as defined in a subsequent section) are not included in the count of heavy vehicles. The percentage of heavy vehicles represents the number of heavy vehicles that arrive during the analysis period divided by the total vehicle count for the same period. This percentage is provided for each intersection traffic movement; however, one representative value for all movements may be used for a planning analysis.

Impact on model results: Non-zero truck percentages decrease the saturation flow rate for the associated movement, resulting in higher delays, travel times, queues, etc. For the multimodal (bicycles) procedure, truck percentages are used to compute the motorized vehicle speed adjustment factor.

Percent Turns in Shared Lane

Description: These entries specify the percentage of left-turn or right-turn vehicles using the shared lane instead of the exclusive lane. These entries are only applicable to shared-plus-exclusive lane configurations.

Impact on model results: The vehicular demands affect most aspects of the overall model; including control delay, time until onset of queue spillback, queue lengths, and travel time.

Percent Unopposed Left Turns

Description: Because the HCM procedures do not explicitly support unopposed major-street left turns on a one-way street, these conditions can be approximated by adding left-turn volume into the thru volume. However, when doing this, saturation flow rates must also be adjusted to account for left turns in the traffic stream. This entry allows the user to specify the percentage of major-street left turns within the thru movement, which can then automatically adjust saturation flow rates for the thru movement. This entry is not applicable for minor side streets, and is not applicable for two-way major streets. This entry is also not applicable for one-way major streets on which left turns do not exist.

Impact on model results: The percentage of unopposed left turns is used as a multiplier for the left-turn equivalency, which defaults to 1.05. For example, thru movement saturation flow rate would be reduced by 2.5% if the percent unopposed left turns were coded as 50%. Similarly, thru movement saturation flow rate would be reduced by 0.5% if the percent unopposed left turns were coded as 10%.

Period Dropdown

Description: The time period dropdown control allows the user to switch between active time periods for editing input data, and for viewing reports.

Impact on model results: None

Permitted Left-Turn Flow (multimodal)

Description: This entry specifies the count of vehicles that turn left permissively. A permitted left-turn movement can occur with either the permitted or the protected-permitted left-turn mode. For left-turn movements served by the permitted mode, the permitted left-turn flow rate is equal to the left-turn demand flow rate. For left-turn movements served by the protected-permitted mode, the permitted left-turn flow rate should be measured in the field because its value is influenced by many factors.

Impact on model results: Permitted left-turn flow affects the effective available crosswalk time-space, and the motorized vehicle volume adjustment factor.

Phase 2 Direction

Description: This entry specifies the direction of "phase 2" in the timing plan. The phase 2 direction does not need to be identical to the urban street forward direction. However, if the urban street forward direction is eastbound or westbound, the phase 2 direction must either be eastbound or westbound. If the urban street forward direction is northbound or southbound, the phase 2 direction must either be northbound or southbound.

Impact on model results: Reversing the phase 2 direction would cause input controller settings for phases 1, 2, 5, and 6 to apply to the opposite direction.

Phase 4 Direction

Description: This entry specifies the direction of "phase 4" in the timing plan. The phase 4 direction must be perpendicular to the urban street forward direction.

Impact on model results: Reversing the phase 4 direction would cause input controller settings for phases 3, 4, 7, and 8 to apply to the opposite direction.

Phase Movement

Description: This entry specifies which movements are active during the given signal phase.

Impact on model results: Left-turns are typically active during the odd-numbered signal phases. Rightturns and through movements are typically active during even-numbered signal phases. The main exception to this is protected-permissive or permissive-only left-turn phasing, in which left-turners are activated (allowed to search for gaps in opposing traffic) during even-numbered phases. Protectedpermissive left-turn phasing is known to allow for lower delays experienced by left-turning vehicles (assuming sufficiently low opposing traffic volumes), when compared to protected-only left-turn phasing. However, timing plans allowing permissive left-turners are also known to increase the probability of traffic accidents under certain conditions, when compared to protected-only left-turn phasing.

Phase Split

Description: This entry specifies a "split" time provided for each non-coordinated phase. A phase split represents the sum of the green, yellow change, and red clearance intervals for the phase. The rationale for determining the appropriate green interval duration varies among agencies; however, it is often equated to the optimum fixed green duration that is obtained from a signal timing optimization software program. The phase split for each phase in a concurrent pair (i.e., 1 and 5, 3 and 7, 4 and 8) is not required to be equal in most modern controllers; however, it is typically set at the same value. It is assumed in this procedure that each phase in the pair has the same split value (split values may vary among pairs).

Impact on model results: The amount of available green time impacts most aspects of the overall model; including queue lengths, stops, and control delays.

Phasing Sequence Optimization Flag

Description: This entry specifies whether or not (lead-lag) phasing sequences are to be optimized in a signal timing optimization run.

Impact on model results: This entry is only applicable to optimization runs.

Phasing View

The signal phasing sequence is specified by clicking on the dual-ring phasing diagram (phases 1 through 8), also known as "Quick Phases". Green, yellow, and all-red clearance times may be entered in the group box labeled "Timing". After the signal phasing and timing are entered a sequential phasing diagram (labeled "Phasing View") will display the overall timing plan in an equivalent "single-ring" format.

The HCM procedure to calculate the average duration of an actuated phase generates the green times in the Phasing View. This procedure is used for estimating the average phase duration for an intersection that is operating with actuated control. Where appropriate, the description is extended to include techniques for estimating the duration of non-coordinated and coordinated phases. A series of calculations (Volume Computations; Queue Accumulation Polygon; Maximum Allowable Headway; Equivalent Maximum Green; Average Phase Duration; and Probability of Max Out) is completed in sequence as defined in HCM Chapter 31 to obtain estimates of average phase duration and the probability of phase termination by extension to its maximum green limit.

Note: The Phasing View presents average phase times over the analysis period (typically 15 minutes) that may not necessarily represent what might be displayed for any given cycle. For example, if a given phase has little demand, it may serve the minimum green some cycles and be skipped other cycles, yielding an average below the minimum. Also, if the average is less than the clearance time, only the green may be displayed with zero shown for the clearance time. And, if the average is equal to the clearance time, the green may be displayed as zero. This is necessary to both show the averages and have them sum to the cycle length.

Increasing the "Number of Calculation Iterations" (the default value is 15 iterations) may improve the accuracy of phase time estimation under complex conditions, but may increase the amount of time required for re-calculation. For pre-timed signals ("Recall Mode" set equal to "Max" for each phase), phase durations will usually reflect user-specified maximum green times if the number of iterations is high enough. Alternatively, phase durations may be taken directly from user-entered data, by turning on the checkbox called "Field-Measured Phase Times".

Phasing Wizard

Description: The phasing wizard is available to help determine what is coded in the Quick Phases diagram. The Quick Phases diagram will automatically populate based on the answers provided for the following questions along with the lanes coded in the Quick Lanes diagram:

- Protected Left-Turn Phases?
- Permitted Left-Turn Phases?
- Right-Turn Overlap Phases?
- Lagging Left-Turn Phases?

Indicating "Yes" for any of these questions will cause the additional question of "Which Approaches?" to appear. Checkboxes for all four approaches (i.e., EB, WB, NB, SB) will appear but will only enable if the lanes coded in Quick Lanes allow it.

Platoon Dispersion Factor

Description: This entry specifies the calibration factor for platoon dispersion.

Impact on model results: Platoon dispersion affects the proportion of arrivals on green. This impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

Population Size

Description: This entry specifies the (genetic algorithm) population size in a signal timing optimization run. The population size is the number of individuals within each generation. For example, if 200 generations of optimization were performed with a population size of 10, this would result in a total of 2000 model runs. Lower population sizes sometimes allow for faster program running times on the computer, but higher population sizes may facilitate genetic diversity and faster optimization of certain networks. If the optimization process is converging too quickly, or if the user wishes to examine a wider range of timing plan possibilities, then increasing the population size may be helpful. If the optimization process is not converging quickly enough, or if the user wishes to acquire a reasonable and effective local optimum solution, then decreasing the population size may be helpful.

Impact on model results: This entry is only applicable to optimization runs.

Presence of Bike Facilities

Description: Presence of bicycle facilities, including bike lane only, shared bicycle and vehicle lane or bicycle storage areas at the approaches.

Impact on model results: Overall, bike facilities increase the frequency of left-turn against crashes. For large intersections, it is also related to more rear-end crashes, while for medium or small intersection, less rear-end crashes are expected (see intersection depth definition for intersection size determination).

Presence of Continuous Barrier (multimodal)

Description: This entry specifies presence of any continuous barrier (at least 3 feet, or 0.9 meters in metric, high) located between the sidewalk and the outside edge of roadway.

Impact on model results: Continuous barrier presence affects the buffer area coefficient, which in turn affects the cross section width adjustment factor.

Presence of Curb (multimodal)

Description: This entry specifies whether a curb is present next to the paved outside shoulder on the subject approach.

Impact on model results: Curb presence affects the adjusted width of paved outside shoulder, which in turn affects the cross section width adjustment factor.

Presence of Mast Arm Signal Display

Description: DEFINES the study area as residential. This option is only available when the Area Type option at the (PRIMARY INPUT DATA / General) is not set as CBD.

Impact on model results: Overall, this factor is associated to a reduction on right angle crashes.

Presence of Median Island

Description: Reflects elevated median islands designed for pedestrian safety and traffic separation.

Impact on model results: Decreases the proportion of right angle crashes while slightly increasing left-turn against crashes.

Presence of Merge on Exit Side

Description: This variable reflect the situation where the downstream road width decreases due to lane drops, blockages, incidents or road works. If, at the Main Input screen, the number of lanes decreases from the upstream segment to the next, this variable is automatically checked.

Impact on model results: This factor increases loss-of-control crashes.

Presence of Sidewalk (multimodal)

Description: This entry specifies whether a sidewalk is present along the subject segment. A sidewalk is a paved walkway that is provided at the side of the roadway. It is assumed that pedestrians will walk in the street if a sidewalk is not present.

Impact on model results: Sidewalk presence affects the adjusted available sidewalk width, which in turn affects the pedestrian LOS score.

Presence of upstream bus bay within 330 ft of stop bar

Description: This variable represents the existence of a bus stop with frequent use within 330 ft (or 100.6 m in metric) of the stop bar.

Impact on model results: The presence of bus bays close to the stop bar has been found to increase the frequency of rear-end crashes at small intersections, with little to no effect on larger ones.

Presence of upstream parking within 330 ft of stop bar

Description: This variable represents the existence of continuous curbside parking on either side of the road within 330 ft (or 100.6 m in metric) of the stop bar. This includes parallel and angle parking.

Impact on model results: The presence of parking has not been associated with the increase of any type of crash, though reducing run-offs and thus, loss-of-control crashes.

Pre-Timed Signal Flag

Description: A checkbox is provided to indicate whether a signal is a pretimed control, which is a fixed sequence of phases that are displayed in repetitive order. The duration of each phase is fixed. However, the green interval duration can be changed by time of day or day of week to accommodate traffic variations. The combination of a fixed phase sequence and fixed duration produces a constant cycle length. When a signal is pretimed in Streets, the color of the arrows in the Phase Duration graphic will be blue.

Impact on model results: Indicating pretimed operation for a signal is the equivalent of using maximum recall on all phases, which affects the amount of available green time and in turn, impacts most aspects of the overall model, including queue lengths, stops, and control delay.

Project Description

Description: This entry documents the analysis with information for identification purposes.

Impact on model results: None

Proportion of CAVs

Description: This entry specifies the proportion of CAVs in the traffic stream. CAV is a connected autonomous vehicle, defined here as a vehicle with an operating cooperative adaptive cruise control system. The range of proportion of CAVs in the traffic stream is from 0 to 100.

Impact on model results: The proportion of CAVs affects the saturation flow rates of a signalized intersection. When CAVs are present in the traffic stream, the base saturation flow rates, or s_0 , are adjusted for the through movements. The base saturation flow rate is then applied to Equation 19-8 along with other adjustment factors to determine the adjusted saturation flow rate.

Left-turn movements at signalized intersections may see increases in capacity due to the presence of CAVs in the traffic stream. Unlike through movements, the base saturation flow rates do not change for left-turn movements. Instead, saturation flow rate adjustment factors are considered. For protected left-turn movements, the factor is $f_{CAV,prot}$. For permitted left-turn movements, the factor is $f_{CAV,prot}$. These factors are then applied to Equation 19-8 along with the base saturation flow rate and other adjustment factors to determine the adjusted saturation flow rate.

Proportion of On-Street Parking Occupied (multimodal)

Description: This entry specifies the proportion of the intersection's right-side curb line that has parked vehicles present during the analysis period. It is based on a zone that extends from a point 250 feet (or 76.2 meters in metric) upstream of the intersection to the intersection, and a second zone that extends from the intersection to a point 250 feet (or 76.2 meters in metric) downstream of the intersection. If parking is not allowed in these two zones, then this proportion equals 0.0.

Impact on model results: The proportion of on-street parking affects the cross section width adjustment factor.

Proportion of Pedestrians who Push Button

Description: This entry specifies the proportion of pedestrians who will push the intersection crossing button for service.

Impact on model results: The pedestrian calling rate is used to compute the probability of a phase call. This in turn potentially affects actuated phase times and control delays for all movements.

Queue Length Percentile

Description: This entry specifies the probability that a computed queue length will not be exceeded during any one signal cycle.

Impact on model results: Queue length percentile affects the back-of-queue adjustment factor; which in turn affects queue storage ratio, uniform queue length, and incremental queue length.

Quick Jump

Description: The Quick Jump combo box allows the user to jump to certain sections of the Classic Mode user-interface screen.

Impact on model results: None

Quick Lanes

Description: Quick Lanes provides a graphical data entry mechanism for specifying lane configuration. Lane use combinations can be selected by clicking on the appropriate arrows to place them on the central diagram for each approach. To remove a selected arrow combination, simply click on the white arrow on the approach itself.

Impact on model results: Intersection laneage has a fundamental effect on all aspects of the model results.

Quick Phases

The signal phasing sequence is specified by clicking on the dual-ring phasing diagram (phases 1 through 8), also known as "Quick Phases". Only the left-turn phasing needs to be specified, because thru movements and right-turn movements are automatically added to the phasing sequence as a function of laneage. The dual-ring phasing diagram contains logic to prevent invalid phasing sequences from being entered, given the available laneage. Left-turn movements in odd-numbered phases are used to reflect protected left-turns (i.e., "green arrow"), whereas left-turn movements in even-numbered phases are used to reflect permitted left-turns (i.e., "green ball"). When exclusive right-turn lanes exist, shielded right-turns may be added by clicking twice on the corresponding odd-numbered phase. Green, yellow, and all-red clearance times may be entered in the group box labeled "Timing". After the signal phasing and timing are entered a sequential phasing diagram (labeled "Phasing View") will display the overall timing plan in an equivalent "single-ring" format.

Random Number Seed

Description: This entry specifies the (genetic algorithm) random number seed in a signal timing optimization run. Crossover, mutation, and the competition between individuals involve a certain degree of randomization. If the random number seed value is left unchanged by the analyst, multiple runs with the same input data should always generate the same optimal design. If the random number seed is changed by the analyst, this may change the amount of time required to locate the optimal solution. Given the necessary G.A. parameter values (i.e., a high maximum number of iterations together with a low convergence threshold), the algorithm is designed to converge on the (one and only) global optimum solution. In order to obtain internal processes that are truly "mathematically random", it is recommended that the random number seed value should end in a '1', '3', '7', or '9'.

Impact on model results: This entry is only applicable to optimization runs.

Recall Mode

Description: This entry specifies whether or not the controller will automatically place a call for a specified phase each time the controller is servicing a conflicting phase. When "no recall" is entered, phases are eligible to be skipped in the absence of vehicular demand. Otherwise, there are three types of recalls: minimum recall, maximum recall, and pedestrian recall. Invoking minimum recall causes the controller to place a continuous call for vehicle service on the phase, and then service the phase until its minimum green interval times out. The phase can be extended if actuations are received. Invoking maximum recall causes the controller to place a continuous call for its maximum duration every cycle. Using maximum recall on all phases yields an equivalent pre-timed operation. Invoking pedestrian recall causes the controller to place a continuous call for pedestrian service on the phase and then service the phase for at least an amount of time equal to its walk and pedestrian clear intervals (more if vehicle detections are received). Pedestrian recall is used for phases that have a high probability of pedestrian demand every cycle and no pedestrian detection.

Impact on model results: Recall mode affects the amount of available green time, which impacts most aspects of the overall model; including queue lengths, stops, and control delays. Minimum green time may also affect the probability of traffic accidents under certain conditions.

Red Time

Description: This entry specifies the all-red clearance interval duration displayed by the signal for the given phase.

Impact on model results: Red time affects the amount of available green time, which impacts most aspects of the overall model; including queue lengths, stops, and control delays. Red time may also affect the probability of traffic accidents under certain conditions.

Re-Entry Delay (multimodal)

Description: This entry specifies the time (in seconds) a transit vehicle spends waiting for a gap to reenter the adjacent traffic stream. Re-entry delay is zero at on-line stops.

Impact on model results: Re-entry delay is used to compute the overall delay due to a transit stop.

Reference Phase

Description: For uncoordinated (Chapter 19) operations, the reference phase is not used. For coordinated (Chapter 18) operations, this entry specifies the coordinated phase number (must be either 2 or 6) to which the offset is referenced.

Impact on model results: Changing the reference phase number would potentially shift the window of major street green time to a different part of the cycle, possibly changing the proportion of arrivals on green for one or more movements. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

Reference Point

Description: For uncoordinated (Chapter 19) operations, the reference point is not used. For coordinated (Chapter 18) operations, this entry specifies the location (beginning of green or end of green) to which the offset is referenced.

Impact on model results: Changing the reference point would potentially shift the window of major street green time to a different part of the cycle, possibly changing the proportion of arrivals on green for one or more movements. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays.

Residential Area Use

Description: DEFINES the study area as residential. This option is only available when the Area Type option at the (PRIMARY INPUT DATA / General) is not set as CBD.

Impact on model results: Overall, this factor is associated to a reduction on loss-of-control crashes.

Rest in Walk Enabled (multimodal)

Description: A phase with the rest-in-walk mode enabled will dwell in walk as long as there are no conflicting calls. When a conflicting call is received, the pedestrian clear interval will time to its setting value before ending the phase. This mode can be enabled for any actuated phase. Signals that operate with coordinated-actuated operation may be set to use a coordination mode that enables the rest-in-walk mode. Typically, the rest-in-walk mode is not enabled. In this case, the walk and pedestrian clear intervals each time to their respective setting values, and then the pedestrian signal indication dwells in a steady DON'T WALK indication until a conflicting call is received.

Impact on model results: Rest-in-walk affects the effective walk time for actuated phases.

Reverse Segment Length

Description: This entry specifies distance from the subject intersection to the next downstream intersection, typically in the "phase 6" direction of travel.

Impact on model results: The reverse segment length impacts many aspects of the overall model; including the proportion of vehicles arriving on green, time until onset of queue spillback, and travel time.

Reverse Weighting

Description: This entry specifies the reverse arterial weighting in a signal timing optimization run. For example, if "Travel Time" were chosen as the objective function, and if "Both Major Street Directions" were chosen as the objective function direction, the optimization process would attempt to find a timing plan that would minimize travel times that were multiplied by the forward and reverse weighting factors. This entry has no effect on the approach-specific objective functions (approach stops, approach delay).

Impact on model results: This entry is only applicable to optimization runs.

Right Turn Equivalency

Description: This entry specifies the ratio of through to right-turn saturation flow rate, at signalized intersections.

Impact on model results: Right turn equivalency affects the distribution of saturation flow rates among lanes, which in turn affects many aspects of the overall model. Right turn equivalency also affects the computation of maximum allowable headways (MAH) for each actuated movement, which impacts actuated phase times.

Right Turns on Red

Description: This entry specifies the count of vehicles that turn right at the intersection when the signal indication is red, divided by the analysis period duration. It is expressed as an hourly flow rate, but may represent a time period shorter than one hour. It is difficult to predict the right-turn-on-red (RTOR) flow rate because it is based on many factors that vary widely from intersection to intersection. These factors include approach lane allocation (shared or exclusive right-turn lane), right-turn flow rate, sight distance available to right-turning drivers, volume-to-capacity ratio for conflicting movements, arrival patterns during the signal cycle, left-turn signal phasing on the conflicting street, and conflicts with pedestrians. Given the difficulty of estimating the RTOR flow rate, it is recommended that this flow rate be measured in the field whenever possible. If the analysis is dealing with future conditions or if the RTOR flow rate is not known from field data, then the RTOR flow rate for each right-turn movement can be assumed to equal zero veh/h. This is a conservative assumption because it may indicate a slightly longer delay than may actually be incurred.

Impact on model results: The coded value is subtracted from the right-turn demand before the adjusted flow rate is computed.

Right-Hand Curb

Description: This entry specifies the percentage of the segment length with a right-hand curb present.

Impact on model results: Right-hand curb presence is used in the computation of segment free-flow speeds.

Safety and Emission

Description: This button opens a dialog box for inputs relevant to signal timing optimization with consideration of environment and safety impacts. Outputs are also provided in this dialog box. However, changing inputs will not automatically show the updated outputs. Buttons are provided for separately calculating Safety outputs and Emission outputs.

Impact on model results: None

Saturation Flow Rate

Description: This value specifies the maximum steady flow rate at which previously stopped passenger cars can cross the stop line of a signalized intersection under typical conditions, assuming that the green signal is available and no lost times are experienced.

Segment "Other" Delays

Description: This entry specifies the average extra vehicle delay caused by "other" mid-segment sources, such as parking.

Impact on model results: This entry is used to compute segment running times, and the proportion of vehicle arrivals on green.

Segment Dropdown

Description: The segment dropdown control allows the user to switch between active segments for editing input data, and for viewing reports.

Impact on model results: None

Segment Length

Description: This entry specifies length of the active segment, which is indicated by the segment dropdown. Segments are only relevant when there is more than one intersection within the analysis.

For the purpose of analysis, the roadway is separated into individual elements that are physically adjacent and operate as a single entity in serving travelers. Two elements are commonly found on an urban streets system: points and links. A *point* is the boundary between links and is represented by an intersection or ramp terminal. A *link* is a length of roadway between two points. A link and its boundary points are referred to as a *segment*.

Segment length is the distance between the boundary intersections that define the segment. The point of measurement at each intersection is the stop line, the yield line, or the functional equivalent in the subject directions of travel. This length is measured along the centerline of the street. If it differs in the two travel directions, an average length is used.

The *link length* is used in some calculations. It is computed as the segment length minus the width of the upstream boundary intersection.



Impact on model results: Segment lengths are used in the computation of travel speeds and vehicle delays.

Segment Length with Non-Restrictive Median

Description: This entry specifies the amount of segment length that contains a non-restrictive median.

Impact on model results: Segment median lengths are used in the computation of segment free-flow speeds, which in turn affect the proportion of vehicle arrivals on green.

Segment Length with Restrictive Median

Description: This entry specifies the amount of segment length that contains a restrictive median.

Impact on model results: Segment median lengths are used in the computation of segment free-flow speeds; which in turn affect segment running times, and the proportion of vehicle arrivals on green.

Segment Name

Description: This entry documents the name of the segment being analyzed. These names can then be viewed within output reports, and within Quick Animation.

Impact on model results: None

Segment Number of Access Points on Right

Description: This entry specifies the number of access points on the right-hand side of the segment. Unlike the "active" access points for which volumes, laneage, and locations are coded, this total number of access points may also include "non-active" access points (serving fewer than 10 vehicles per hour).

Impact on model results: The total number of access points is used in the computation of segment free-flow speeds; which in turn affect segment running times, and the proportion of vehicle arrivals on green.

Segment Width of Intersection

Description: This entry specifies the width of the upstream intersection. The intersection width applies to the upstream boundary for a given direction of travel and is the effective width of the cross street. On a two-way street, it is the distance between the stop (or yield) line for the two opposing segment through movements at the boundary intersection, as measured along the centerline of the segment. On a one-way street, it is the distance from the stop line to the far side of the most distant traffic lane on the cross street.



Impact on model results: Intersection width is used in the computation of segment free-flow speed; which in turn affects segment running times, and the proportion of vehicle arrivals on green.

Shared Lanes

Description: This entry specifies the existence of shared left-turn lanes and shared right-turn lanes.

Impact on model results: Approach lane configuration affects the adjusted volumes and saturation flow rates, thus having a fundamental impact on all aspects of the computational procedure. When analyzing "shared-plus-exclusive" configurations, the "Percent Turns in Shared Lane" input parameter is used to specify a percentage of left-turn or right-turn vehicles using the shared lane.

Shortest Distance

Description: This entry specifies the distance measured from the ramp movement stop bar to the conflict point in feet (or meters in metric), measured along the centerline of the off-ramp approach.

Impact on model results: This entry is only applicable to DDI alternative intersections. Along with freeflow speeds, clear-zone widths, and vehicle lengths, the space between ramp stop bar and conflict zone contributes to the calculation of lost times that are applied to DDI off-ramp movements.

Sidewalk Length Adjacent to Building (multimodal)

Description: This entry specifies the proportion of sidewalk length adjacent to a building face.

Impact on model results: This proportion is used to calculate the effective sidewalk width.

Sidewalk Length Adjacent to Fence (multimodal)

Description: This entry specifies the proportion of sidewalk length adjacent to a fence or low wall.

Impact on model results: This proportion is used to calculate the effective sidewalk width.

Sidewalk Length Adjacent to Window (multimodal)

Description: This entry specifies the proportion of sidewalk length adjacent to a window display.

Impact on model results: This proportion is used to calculate the effective sidewalk width.

Simultaneous Gap Out

Description: This entry specifies the manner in which phases are terminated before the barrier can be crossed to serve a conflicting call. Depending on the operating circumstances, this mode can be enabled or disabled. It is a phase-specific setting; however, it is typically set the same for all phases that serve the same street. Simultaneous gap-out dictates controller operation when a barrier must be crossed to serve the next call and one phase is active in each ring. If simultaneous gap-out is enabled, it requires that both phases reach a point of being committed to terminate (via gap out, max out, or force-off) at the same time. If one phase is able to terminate because it has gapped out, but the other phase is not able to terminate, then the gapped-out phase will reset its extension timer and restart the process of timing down to gap-out. If the simultaneous gap-out feature is disabled, then each phase can reach a point of termination independently. In this situation, the first phase to commit to termination maintains its active status while waiting for the other phase to commit to termination. Regardless of which mode is in effect, the barrier is not crossed until both phases are committed to terminate.

Impact on model results: The simultaneous gap-out mode is considered when computing maximum allowable headways (MAH) for each actuated movement. MAH impacts many aspects of the overall model; including actuated phase times, and control delays.

Sneakers

Description: This entry specifies the number of left-turns completed at the end of a permissive period.

Impact on model results: Sneakers affect the capacity of left-turn movements operating under protected-permissive or permissive-only phasing. Left-turn capacity then affects queue length and control delay for the left-turn movement.

Speed Calibration Factor

Description: This entry is specified by the user to adjust base free-flow speed. The default is 0.0 mi/h. However, if desired, a locally representative value can be determined from field-measured estimated of the base-free flow speed for several street segments. The local default value can be established for typical street segments, or for specific street types. This calibration factor is determined as the one value that provides a statistically based best-fit between the prediction from Equation 18-3 and the field measured estimates.

Impact on model results: The Speed Calibration Factor is used in the computation of segment free-flow speed; which in turn affects segment running times, and the proportion of vehicle arrivals on green.

Speed Limit

Description: This entry specifies the posted speed limit applicable to each movement. Speed is used in the methodology to estimate the maximum allowable headway of the arriving traffic stream. Speed limit is highly correlated with the environmental and geometric factors that have a direct influence on driver speed choice. As such, it represents a single input variable that is highly correlated with operating speed

and is used as a convenient way to limit the need for numerous environmental and geometric input data to estimate operating speed. The convenience of using speed limit as an input variable comes with a caution - the analyst must not infer a cause-and-effect relationship between the input speed limit and the estimated performance measures. More specifically, the computed change in performance resulting from a change in the input speed limit is not likely to be indicative of performance changes that will actually be realized. Research indicates that a change in speed limit has a proportionally smaller effect on the actual operating speed. The methodology is based on the assumption that the posted speed limit is: (1) consistent with that found on other streets in the vicinity of the subject intersection and (2) consistent with agency policy regarding specification of speed limits. If it is known that the posted speed limit does not satisfy these assumptions, then the speed limit value that is input to the procedure should be adjusted such that it is consistent with the assumptions.

Impact on model results: Within the computational procedure, speed limits are first converted to freeflow speeds (AverageSpeedtoFFSRatio = 0.90 by default) for each movement. Next, the free-flow speeds are then used to compute maximum allowable headways (MAH) for each actuated movement. MAH impacts many aspects of the overall model; including actuated phase times, and control delays. Speed limits are also used to compute accel-decel delays, which affect the computation of uniform stops and uniform queue.

Split Optimization Flag

Description: This entry specifies whether or not phase splits are to be optimized in a signal timing optimization run.

Impact on model results: This entry is only applicable to optimization runs.

Split Phase

Description: This entry specifies whether or not the split phasing is in effect for phases 4 and 8, meaning that phases 4 and 8 occur sequentially instead of concurrently. Split phasing is generally not used on the major street (phases 2 and 6). Split phasing is commonly used to reduce the probability of accidents at intersections with sight distance problems.

Impact on model results: Changing the minor street phasing sequence (via Split Phase) could affect the times during which cross street vehicles are released on to the major street, affecting the proportion of arrivals on green. The proportion of arrivals on green impacts many aspects of the overall model; including queue service times, actuated phase times, and control delays. To the extent that split phasing is used in lieu of standard phasing, it will typically increase queue lengths and control delays at the subject intersection. However, this is sometimes seen as an acceptable price to pay for reducing the probability of accidents (at intersections with sight distance problems).

Start Time

Description: This entry specifies the clock time (hh:mm) at the beginning of the analysis period. For example, 17:00 could be used to indicate the beginning of the 5:00 PM peak hour. Start times are listed at the top of the formatted reports.

Impact on model results: None

Start-Up Lost Time

Description: This entry specifies the additional time consumed by the first few vehicles in a queue at a signalized intersection, above and beyond the saturation headway, because of the need to react to the initiation of the green phase (and to accelerate).

Impact on model results: Start-up lost times affect the calculation of actuated phase times and queue service times.

Stop Speed

Description: This entry specifies the speed below which a vehicle is said to be stopped.

Impact on model results: Stop speed affects the calculation of accel-decel delays, which in turn affect the computation of uniform stops and uniform queue.

Stops with Benches (multimodal)

Description: This entry specifies the proportion of transit stops that provide benches to sit on. A shelter with a bench is counted twice, once as a shelter and a second time as a bench.

Impact on model results: The proportion of transit stops with benches is used to compute the perceived travel time rate.

Stops with Shelters (multimodal)

Description: This entry specifies the proportion of transit stops that provide a structure with a roof and three enclosed sides that protect occupants from wind, rain, and sun. A shelter with a bench is counted twice, once as a shelter and a second time as a bench.

Impact on model results: The proportion of sheltered transit stops is used to compute the perceived travel time rate.

Stored Heavy Vehicle Length

Description: This entry specifies the lane length occupied by a queued heavy vehicle.

Impact on model results: Stored heavy vehicle length affects the computation of queue storage ratio.

Stored Vehicle Length

Description: This entry specifies the lane length occupied by a queued vehicle.

Impact on model results: Stored vehicle length is considered when estimating the amount of time until onset of queue spillback. Stored vehicle length also affects access point operations.

System Cycle Length

Description: This entry specifies the background cycle length applicable to the urban street system. The cycle length represents the total time for a signal to complete one cycle.

Impact on model results: For uncoordinated (Chapter 19) operations, the cycle length input data entry is not used; instead, the cycle length is automatically recomputed by the procedure. For coordinated (Chapter 18) operations, the cycle length applies to all intersections, and will not be recomputed by the procedure. The cycle length affects most aspects of the overall model; including control delay, queue lengths, and travel time.

Total Number of Access Points (multimodal)

Description: This entry specifies the number of access point approaches on the right side in the subject direction of travel.

Impact on model results: The total number of access points affects the bicycle LOS score for the segment.

Total Walkway Width (multimodal)

Description: The total walkway width is measured from the outside edge of the road pavement (or face of curb, if present) to the far edge of the sidewalk (as sometimes delineated by building face, fence, or landscaping).

Impact on model results: Total walkway width is used to compute the effective sidewalk width.

Transit Frequency (multimodal)

Description: This entry specifies the count of scheduled fixed route transit vehicles that stop on or near the segment during the analysis period. Scheduled transit vehicles can be considered "local" or "nonlocal." Local transit vehicles make regular stops along the street (typically every 0.25 miles, or 0.402 kilometers in metric, or less); although they do not necessarily stop within the analysis segment when segment lengths are short, or when stops alternate between the near and far sides of boundary intersections. They are always counted, regardless of whether they stop within the subject segment. Non-local transit vehicles operate on routes with longer stop spacing than local routes (e.g., limited-stop, bus rapid transit, or express routes). They are only counted when they stop within the subject segment.

Impact on model results: Transit frequency is used to compute the transit wait-ride score.

Transit Stop Near Side (multimodal)

Description: This entry specifies whether a transit stop is located on the near side of a boundary intersection or elsewhere. A portion of the time required to serve a near-side transit stop at a boundary intersection may overlap with the control delay incurred at the intersection.

Impact on model results: Transit stop location is used to compute the transit stop delay due to acceleration and deceleration.

Transit Stop On-Line (multimodal)

Description: This entry specifies whether a transit stop is *on-line*, where the bus stops entirely or mostly in the travel lane and does not have to yield to other vehicles upon exiting the stop, or *off-line*, where the bus pulls out of the travel lane to serve the stop and may have to yield to other vehicles upon exiting.

Impact on model results: Transit stop position is used to compute the delay due to a transit stop.

Turn Bay Length and Segment Length

Description: For left-turns and right-turns this entry specifies turn pocket lengths for each approach. For through movements this entry specifies segment lengths for each approach. Turn bay length represents the length of the bay for which the lanes have full width and in which queued vehicles can be stored. The turn bay length does not include the bay taper. Bay length is measured parallel to the roadway centerline. If a two-way left-turn lane is provided for left-turning vehicle storage and adjacent access points exist, then the bay length entered should represent the "effective" storage length available to the subject left-turn movement. The effective length must consider adjacent access points and their associated left-turn vehicles, which may also store in the two-way left-turn lane.

Impact on model results: Turn bay lengths and segment lengths affect the "queue storage ratio" output, and the time until onset of queue spillback.

Turn Radius

Description: This entry specifies the left-turn radius and right-turn radius.

Traffic movements that discharge along a curved travel path do so at rates lower than those of through movements. The equivalent number of thru cars for a protected turn-movement is calculated with the following equation:

$$E = 1 + (5.61/R)$$

where R is the radius of curvature of the left- or right-turning path (at the center of the path), in feet.

The default value of 112 ft (or 34.1 m in metric) for left-turn movements yields left-turn equivalency factor E_L = 1.05 and the default value of 32 ft (or 9.8 m in metric) for right-turn movements yields right-turn equivalency factor E_R = 1.18.

Impact on model results: Turn radius affects the left-turn equivalency factor (typically 1.05), and the right-turn equivalency factor (typically 1.18). These equivalency factors affect the saturation flow rate of left-turn movements and right-turn movements.

Two-Way Pedestrian Volume (multimodal)

Description: This entry specifies total pedestrian volume traveling along the urban street segment, between boundary intersections.

Impact on model results: Two-way pedestrian volume affects the pedestrian flow per unit width of sidewalk.

Unblocked Lanes

Description: This entry specifies the number of open lanes when blockage is present along the segment.

Impact on model results: The number of unblocked lanes is used in the computation of midsegment capacity, which in turn is used in the computation of the adjustment factor for downstream lane blockage.

Uncoordinated Flag

Description: If an intersection is flagged as uncoordinated, it will be analyzed in accordance with Chapter 19 (signalized intersections) procedures. If an intersection is flagged as coordinated, it will be analyzed in accordance with Chapter 18 (urban streets) procedures.

Impact on model results: For uncoordinated (Chapter 19) operations, each intersection is analyzed independently of all other intersections, and the cycle length is variable. For coordinated (Chapter 18) operations, each intersection is potentially affected by the operation of nearby intersections, and the cycle length is constant.

Unsignalized Delay

Description: When a movement is marked as Unsignalized, this field will enable, allowing the user to manually input control delay for the movement, instead of having the signalized control delay calculated.

Impact on model results: Unsignalized delay will affect the approach and intersection delay.

Unsignalized Movement

Description: This checkbox allows the user to mark a movement as Unsignalized. If the movement is considered as Unsignalized, it is considered as not controlled by traffic signals and all relevant signalized calculations will be hidden for the specified movement.

Impact on model results: Marking a movement as unsignalized will affect the approach and intersection delay.

Upstream

Description: This button opens a dialog box for the user to select and open the upstream crossover junction file coded in TWSC. Once opened, the TWSC file (.xtw) becomes attached in the Streets module.

Impact on model results: This button is only applicable to MUT with TWSC alternative intersections and is necessary for the completion of one MUT with Stop Signs alternative intersection.

Upstream Filtering Adjustment Factor

Description: This entry accounts for the effect of "filtered" arrivals from upstream signals on delay. In other words, the upstream filtering adjustment factor (I) reflects the way that an upstream signal decreases the variance in the number of arrivals per cycle at the subject intersection. The decrease in variance can reduce cycle failure frequency and resulting delay. The filtering adjustment factor varies in value from 0.09 to 1.0. A value of 1.0 is appropriate for an isolated intersection (i.e., one that is at least one mile, or 1.6 kilometers in metric, from the nearest upstream signalized intersection). A value of less than 1.0 is appropriate for non-isolated intersections. The equation I = 1.0 - 0.91Xu^2.68 is used to compute I for non-isolated intersections. The variable Xu is computed as the weighted volume-to-capacity ratio of all upstream movements contributing to volume in the subject movement group. This ratio is computed as a weighted average with the volume-to-capacity ratio of each contributing upstream movement weighted by its discharge volume. The procedure automatically performs this calculation for internal movements with an upstream signal. If desired the user may override the computed value with their own entered value, or restore the computed value by blanking out the input field. For planning and preliminary design analyses, Xu can be approximated as the weighted volume-to-capacity ratio of the movement groups serving through movements at the upstream signalized intersection. Note: The adjacent button will open a file dialog screen to identify the Signals file for the upstream signal. If a file is selected, the appropriate volume-to-capacity ratios will be averaged as described above and the I-factor computed automatically.

Impact on model results: The upstream filtering adjustment factor (also known as the I-factor) is used in the calculation of incremental delay, incremental queue, and incremental stops. **Note:** Since flow rates and signal timing can affect the volume-to-capacity ratio of the upstream signal due to changes in the flow profile, changes to these values in the subject intersection can cause the I-factor to change in the subject intersection.

Urban Street

Description: This entry is used to document the name of the urban street.

Impact on model results: None

Urban Street Forward Direction

Description: This entry typically specifies the direction of "phase 2" in the timing plan.

Impact on model results: Reversing the urban street forward direction could cause forward direction segment-specific MOEs (e.g., running speed, travel time) to be reported for the reverse direction, and vice-versa.

U-Turn Crossover Median Width

Description: This entry specifies the U-turn crossover median width range for RCUT alternative intersections.

Impact on model results: This entry is only applicable to RCUT alternative intersections. U-turn crossover median width affects the saturation flow rate of the u-turn crossover movements.

U-Turn Volume

Description: This entry specifies the U-turn volume for interchange ramp terminals. Please note that this field is for the interchange (not intersection) U-turn demands – the traffic exiting the freeway in one direction, then navigating the arterial to reenter the freeway traveling in the opposite direction. Typically, each intersection would include one value as appropriate for the interchange design.

Impact on model results: U-turn volume affects the lane utilization adjustment factor for interchange ramp terminals.

Walk plus Pedestrian Clear Setting

Description: The walk interval is intended to give pedestrians adequate time to perceive the WALK indication and depart the curb before the pedestrian change interval begins. The walk setting is typically 7 seconds, or more, for an actuated or a non-actuated coordinated phase. Longer walk durations should be considered in school zones and areas with large numbers of elderly pedestrians. It is assumed that the rest-in-Walk mode is not enabled for actuated phases and non-coordinated phases. For a pre-timed phase, the walk interval is often set at a value equal to the green interval duration less the pedestrian clear setting (provided that it exceeds the minimum time need for pedestrian perception and reaction). For a coordinated phase, the controller is sometimes set to use a coordination mode that extends the walk interval for most of the green interval duration. This functionality is not explicitly modeled in the automobile methodology but it can be approximated by setting the walk interval to a value equal to the phase split less the pedestrian clear setting and less the change period (i.e., the yellow change interval plus the red clearance interval). If the walk and pedestrian clear settings are provided for a phase, then it is assumed that a pedestrian signal head is also provided. If these settings are not used, then it is assumed that any pedestrian accommodation needed is provided in the minimum green setting. The pedestrian clear interval (also referred to as the pedestrian change interval) is intended to provide time for pedestrians that depart the curb during the WALK indication to reach the opposite curb (or the median). Some agencies set the pedestrian clear equal to the "crossing time," where crossing time equals the curb-to-curb crossing distance in ft (or m in metric) divided by the pedestrian walking speed of 3.5 ft/s (1.07 m/s in metric). Other agencies set the pedestrian clear equal to the crossing time less the change period. This choice is dependent on agency policy. A flashing DON'T WALK indication is displayed during this interval.

Impact on model results: The Walk + PC interval is used to compute the probability of a phase call. This in turn potentially affects actuated phase times and control delays for all movements.

Walkway Width (multimodal)

Description: The total walkway width is measured from the outside edge of the road pavement (or face of curb, if present) to the far edge of the sidewalk (as sometimes delineated by building face, fence, or landscaping).

Impact on model results: Walkway width affects the available corner time-space.

Weights, %

Description: Defines the weight given to each performance measure to the objective function used by Streets optimization algorithm. Must add up to 100%.

Impact on model results: Changing the weight scheme may lead to slightly different timing results when different feasible results exist.

Width of Clear Zone

Description: This entry specifies the width of the clear zone for the longest vehicle path in feet (or meters in metric), measured along the centerline of the outside lane, which is the closest conflicting vehicle path to the ramp.

Impact on model results: This entry is only applicable to DDI alternative intersections. Along with freeflow speeds, vehicle lengths, and the space between ramp stop bar and conflict zone, clear-zone widths contribute to the calculation of lost times that are applied to DDI off-ramp movements.

Work Zone Approach Width

Description: The approach width during the work zone is coded in feet (or meters in metric) for all open left, thru and right lanes.

Impact on model results: This generates the saturation flow rate adjustment for approach width during work zone presence. This value is used in the computation of the overall saturation flow rate adjustment factor for work zone presence to further reduce the default of 0.858 if applicable.

Work Zone Left Thru Lanes Open

Description: The number of left and thru lanes open during the work zone is used to compare with the number coded for normal operations.

Impact on model results: This generates the saturation flow rate adjustment for reducing lanes during work zone presence. This value is used in the computation of the overall saturation flow rate adjustment factor for work zone presence to further reduce the default of 0.858 if applicable.

Work Zones

Description: Identifying an approach as having a work zone implements a series of equations to compute a saturation flow rate adjustment factor.

Impact on model results: The saturation flow rate adjustment factor is applied to lane groups associated with the approach, to model the work zone presence.

Yellow Time

Description: This entry specifies the yellow (or amber) change interval duration displayed by the signal for the given phase.

Impact on model results: Yellow time affects the amount of available green time, which impacts most aspects of the overall model; including queue lengths, stops, and control delays. Yellow time may also affect the probability of traffic accidents under certain conditions.

Index

Α

Acceleration Rate 77 Access Point Critical Gap Time 77 Access Point Deceleration Rate 77 Access Point Dropdown 77 Access Point Follow Up Time 77 Access Point Lanes 78 Access Point Location 78 Access Point Maximum Bay Length 78 Access Point Name 78 Access Point Peak Hour Factor 78 Access Point Right Turn Equivalency 80 Access Point Right Turn Speed 78 Access Point Volumes 79 Acknowledgements 4 Additional RCUT Inputs 79 Advanced Features 21 Agency or Company 79 All Segment Lengths 79 Allow Optimization 79 Alternative Intersection 79 Alternative Intersections 14,39 Analysis Time Period 80 Analysis Time Period Duration 80 Analysis Year 80 Analyst 80 Area Type 80 Arrival Type 80 Average Passenger Trip Length (multimodal) 81

В

Base Saturation Flow Rate 81 Base Travel Time Rate (multimodal) 81 Bicycle Lane Width (multimodal) 81 Bicycle Running Speed (multimodal) 81 Bicycles per Hour 82 Buffer Object Spacing (multimodal) 82 Buffer Width (multimodal) 82 Bus Blockage Time 82 Bus Stops per Hour 83

С

Calculate Emissions 83 Calculate Safety 83 Change the Mode 55 Circulating Pedestrian Volume (multimodal) 83 Clear 83 Close a File 53 Coding Movements (DDI) 32 **Conventional RCUT Demands 83 Convergence Threshold 84** Corner Radius (multimodal) 84 CORSIM 21 Create a New File 46 Creating New Alternative Intersection Datasets 39 Critical Left Turn Gap Time 84 Critical Merge Gap 84 **Crossover Probability 84** Crosswalk Closed (multimodal) 85 Crosswalk Length (multimodal) 85 Crosswalk Width (multimodal) 85 Curb-to-Curb Street Width (multimodal) 85 Cycle Length Increment 85 Cycle Length Optimization Flag 86

D

Dallas Phasing 86 Dallas Phasing Optimization 86 Date 86 **Deceleration Rate 86** Delete Access Point 86 **Delete Intersection 86 Delete Time Period 87** Demand 87 Demand Growth 87 Design Speed 87 Design Vehicle Length 87 Detailed Input Data 13 Detected Vehicle Length 87 Detector Length 88 Diverging Diamond Data 33,88 Diverging Diamond Interchange (DDI) 31 Downstream 88 Downstream Intersection Width (multimodal) 88 **Dual Entry 88** Dwell Time (multimodal) 89

Е

Edit 9 EDTT Data 35,89 Excess Wait Time (multimodal) 89 Exclusive Pedestrian Phase Time 89 Exit the Program 54 Export 72 Extension of Effective Green Time 89 Extra Distance 89

F

Field Free-Flow Speed 90 Field Proportion Arriving on Green 90 Field Travel Speed 90 Field-Measured Phase Times 90 File 7 Flow Profile Diagram 29 Follow Up Left Turn Time 90 Force Mode 90 Forward Segment Length 91 Forward Weighting 91 Free-Flow Speed of Vehicle 91 Full Optimization 24

G

General (Operational Data) 11 General Controls 7 Getting Started 6,7 Glossary of Terms 77

Н

HCM Chapter 18 5 HCM Chapter 19 5 HCM Chapter 23 6 Heaviest Lane Volume 91 Heavy Vehicle Equivalency 91 Help 10 Hide Multimodal Results (multimodal) 91 How To 46

I

Import 67 Incoming Pedestrian Volume (multimodal) 92 Initial Queue Length 92 Inside Object Effective Width (multimodal) 92 Interchange Intersection 92 Interchange Ramp Terminals 14 Interchange Type 92 Interchanges and Alternative Intersections 31 Intersection Depth 93 Intersection Dropdown 93 Intersection Name 93 Intersection Type 93 Interduction 1

J

Jurisdiction 94

Κ

K Factor, % 94

L

Lag Phase 94 Lane Width 94 Left Turn Equivalency 94 Legal Mid-Segment Crossing (multimodal) 94 License Agreement 1

Μ

Map X/Y Coordinate 95 Map X/Y Curve Point 1 and Point 2 95 Master Intersection Number 95 Maximum Cycle Length 95 Maximum Green 95 Maximum Number of Generations 95 Maximum Platoon Headway 96 Median Type (multimodal) 96 Mid-Segment 85th-Percentile Speed (multimodal) 96 Minimum Cycle Length 96 Minimum Green 96 Minimum Platoon Headway 97 Modeling Capability in HCS (Alternative Intersections) 39 Multimodal Input Data 14 MUT Segment Free-Flow Speed 97 MUT Segment Length 97 Mutation Probability 97

Ν

Nearest Signal Distance (multimodal) 97 New Access Point 98 New Intersection 98 New Time Period 98 Number of Active Access Points 98 Number of Intersections 98 Number of Iterations 98 Number of Lanes 98 Number of Periods 99 Number of Receiving Lanes 99 Number of Right-Turn Islands (multimodal) 99 Number of Transit Stops (multimodal) 99

0

O-D Seeds 99 Offset 100 Offset Optimization Flag 101 On-Ramp Left Lane Shared 101 **On-Street Parking 101** Open an Existing File 49 Open RCUT File 101 **Operational Data 11 Opposing Right-Turn Lane Influence 101 Optimization Objective Function 101 Optimization Objective Function Direction 102** Outgoing Pedestrian Volume (multimodal) 102 Output Reports 36 Outside Object Effective Width (multimodal) 102 Outside Thru Lane Width (multimodal) 102 Overview of Diverging Diamond Interchange (DDI) 31 **Overview of Visual Mode 15**

Ρ

Parking Exists 102 Parking Lane Width (multimodal) 102 Parking Maneuver Time 103 Parking Maneuvers per Hour 103 Passage Time 103 Passenger Load Factor (multimodal) 103 Paved Shoulder Width (multimodal) 103 Pavement Condition Rating (multimodal) 104 Peak-Hour Factor 104 Pedestrian Free-Flow Speed (multimodal) 104 Pedestrian Signal Head (multimodal) 104 Pedestrian Waiting Delay (multimodal) 104 Pedestrians per Hour 104 Percent Grade 105 Percent Trucks 105 Percent Turns in Shared Lane 105 Percent Unopposed Left Turns 105 Period Dropdown 105 Permitted Left-Turn Flow (multimodal) 106 Phase 2 Direction 106 Phase 4 Direction 106 Phase Movement 106 Phase Split 106 Phasing and Timing 13 Phasing Sequence Optimization Flag 107 Phasing View 107 Phasing Wizard 107 Platoon Dispersion Factor 107 Population Size 108 Presence of Bike Facilities 108 Presence of Continuous Barrier (multimodal) 108 Presence of Curb (multimodal) 108 Presence of Mast Arm Display 108 Presence of Median Island 108 Presence of Merge on Exit Side 109 Presence of Sidewalk (multimodal) 109

Presence of upstream bus bay within 330 ft of stop bar 109
Presence of upstream parking within 330 ft of stop bar 109
Pre-Timed Signal Flag 109
Print a Report 75
Project Description 109
Proportion of CAVs 109
Proportion of On-Street Parking Occupied (multimodal) 110

Proportion of Pedestrians who Push Button 110

Q

Queue Length Percentile 110 Quick Animation 21 Quick Jump 110 Quick Lanes 110 Quick Optimization 22 Quick Phases 111

R

Random Number Seed 111 Recall Mode 111 Red Time 111 Re-Entry Delay (multimodal) 112 Reference Phase 112 Reference Point 112 Reports 9 Residential Area Use 112 Rest in Walk Enabled (multimodal) 112 **Reverse Segment Length 112 Reverse Weighting 113 Right Turn Equivalency 113** Right Turns on Red 113 Right-Hand Curb 113 Run Animation 58 **Run Optimization 60**

S

Safety and Emission 113 Saturation Flow Rate 114 Save a File 51 Segment "Other" Delays 114 Segment Dropdown 114 Segment Length 114 Segment Length with Non-Restrictive Median 115 Segment Length with Restrictive Median 115 Segment Length with Restrictive Median 115 Segment Name 115 Segment Number of Access Points on Right 115 Segment Width of Intersection 115 Shared Lanes 116 Shortcuts 10 Shortest Distance 116 Sidewalk Length Adjacent to Building (multimodal) 116 Sidewalk Length Adjacent to Fence (multimodal) 117 Sidewalk Length Adjacent to Window (multimodal) 117 Signal Timing Inputs (DDI) 35 Signals/Streets Reports 14 Simultaneous Gap Out 117 Sneakers 117 Speed Calibration Factor 117 Speed Limit 117 Split Optimization Flag 118 Split Phase 118 Start Time 118 Start-Up Lost Time 118 Steps to Build a Partial DLT 45 Steps to Build an MUT with Stop Signs 43 Steps to Build an RCUT with Signals 29 Stop Speed 119 Stops with Benches (multimodal) 119 Stops with Shelters (multimodal) 119 Stored Heavy Vehicle Length 119 Stored Vehicle Length 119 System Cycle Length 119 System Requirements 6

Т

Templates 7 Time-Space Diagram 26 Toolbar Icons 10 Toolbar Icons in Visual Mode 17 Total Number of Access Points (multimodal) 119 Total Walkway Width (multimodal) 120 Trademarks and Copyrights 4 Traffic (Operational Data) 12 Transit Frequency (multimodal) 120 Transit Stop Near Side (multimodal) 120 Transit Stop On-Line (multimodal) 120 Turn Bay Length and Segment Length 120 Turn Radius 120 Two-Way Pedestrian Volume (multimodal) 121

U

Unblocked Lanes 121 Uncoordinated Flag 121 Unsignalized Delay 121 Unsignalized Movement 121 Upstream 122 Upstream Filtering Adjustment Factor 122 Urban Street 122 Urban Street Forward Direction 122 U-Turn Crossover Median Width 122 U-Turn Volume 123

V

View 8 View Results of the Analysis 74 Visual Mode 15

W

Walk plus Pedestrian Clear Setting 123 Walkway Width (multimodal) 123 Weights, % 123 Width of Clear Zone 124 Windows 9 Work Zone Approach Width 124 Work Zone Left Thru Lanes Open 124 Work Zones 124

Y

Yellow Time 124