

# **Contents**

Introduction	1
License Agreement	1
Acknowledgements	
Trademarks and Copyrights	
Catting Ctartad	-
Getting Started	7
System Requirements	
Getting Started	7
General Controls	8
Menu Items	8
Multilane Highway Segments	10
	_
HCM Chapter 12 Operational Data	
Safety Results	
Multilane Highway Report	
manane mg.may repertiment	
Two-lane Highways	13
HCM Chapter 15	13
Operational Data	
Safety Results	
Two-Lane Highway Report	16
How To	17
Create a New File	17
Open an Existing File	20
Save a File	24
Close a File	25
Exit the Program	
Edit the Default Settings	
Change the View	
Create a Horizontal Curve	
View Results of the Analysis	
Print a Report	42
Glossary of Terms	45
Index	62

# Introduction

## **License Agreement**

HIGHWAY CAPACITY SOFTWARE™ (HCS™) END-USER LICENSE AGREEMENT (EULA)

Effective Date: 9/1/2025

Copyright © 2025 University of Florida. All rights reserved.

This End User License Agreement ("Agreement") is a legal agreement between you ("End User", "you") and the University of Florida Board of Trustees for the benefit of the McTrans Center ("McTrans", "we") regarding the use of the Highway Capacity Software ("Software"). By accessing or using the Software programs within the electronically transmitted package or direct download, you agree to be bound by the terms and conditions of this Agreement.

#### 1. INTEGRATION:

This License Agreement is the complete and exclusive statement of the agreement between End User and McTrans and supersedes any previous End User License Agreements distributed by older versions of the software proposal or prior agreement, oral or written, and any other communications between End User and McTrans relating to the subject matter of this License Agreement. This EULA will supersede the End User License Agreement contained in the HCS Version 5, 6, and 7 modules disseminated as part of the Software. This License Agreement may only be modified by a written agreement made subsequent to the date hereof and signed by both parties.

#### 2. LICENSE GRANT:

#### 2.1 Subscription-Based License:

McTrans grants you a non-exclusive, non-transferable license to access and use the Software, subject to the terms of your active subscription. The license is valid only for the duration of your subscription and is contingent upon full payment of all applicable fees.

#### 2.2 Access to Software Versions:

Your subscription grants access to versions 5 (selected modules), 6 (selected modules), 7 and 8 series and beyond (2022 onward) of the Software. When a new version of the Software is released, the End User with an active subscription can download and access the latest version at no additional cost for the remainder of their subscription term.

#### 3. TYPES OF SUBSCRIPTIONS:

The type of subscription determines the permitted use of the Software. Once a subscription type is selected, it cannot be changed or exchanged for a different type.

Highways User Guide Introduction · 1

#### 3.1 Office-Based Subscription:

This subscription grants access to the Software for a predetermined number of computers within a physical office. An "office" refers exclusively to a fixed geographical location, typically a single physical address, where an organization conducts its business or operational activities. This location must consist of one or more contiguous rooms or spaces within a single building. Virtual offices or any non-physical locations are excluded from this definition.

The Software may be installed on multiple devices within the office, and access is restricted to end users officially assigned to that licensed office. End Users may also use the Software on portable computers, such as laptops, while on official travel, provided that all (100%) such use is exclusively on behalf of the office for which this Software license was purchased. Additional offices must obtain proper licensing prior to accessing the Software. The Software may only be installed on devices owned or controlled by the licensed office.

This subscription is intended exclusively for commercial use.

#### Virtualization Restriction:

The Software under an office-based subscription is prohibited from being used in a virtualized environment. All installations of the Software must be conducted on a physical computer, such as a desktop or laptop. Remote access technologies, such as remote desktop, are strictly prohibited under this subscription type.

#### 3.2 Computer-Based Subscription:

This subscription permits the installation and use of the Software on a specified number of individual devices. An "individual device" refers to a single, standalone computing unit, such as a desktop or laptop, intended for use by a single user at a time. Concurrent or simultaneous access by multiple users on the same computer or through any means of remote connection is strictly prohibited. The Software may only be accessed directly from the device(s) on which it is installed, regardless of whether the device is located in a physical office or used in a virtual office. End users working remotely or in virtual offices must ensure that the device remains dedicated to their use and fully complies with the terms of this subscription.

#### Virtualization Restriction:

The Software under a computer-based subscription is prohibited from being used in a virtualized environment. All installations must be conducted on a physical computer, such as a desktop, PC, or laptop. Remote access to the Software via any technology, including but not limited to remote desktop, is strictly prohibited under this subscription type.

#### 3.3 Volume-Based Subscription:

This subscription permits the installation and use of the Software on a specified number of individual devices. An "individual device" refers to a single, standalone computing unit, such as a desktop or laptop, intended for use by a single user at a time. Concurrent or simultaneous access by multiple users on the same computer or through any means of remote connection is strictly prohibited. The Software may only be accessed directly from the device(s) on which it is installed, regardless of whether the device is located in a physical office or used in a virtual office. End users working remotely or in virtual offices must ensure that the device remains dedicated to their use and fully complies with the terms of this subscription.

#### Virtualization Restriction:

The Software under a Volume-based subscription is prohibited from being used in a virtualized environment. All installations must be conducted on a physical computer, such as a desktop, PC, or laptop. Remote access to the Software via any technology, including but not limited to remote desktop, is strictly prohibited under this subscription type.

#### 3.4 Academic Subscription:

The academic subscription is available exclusively to academic institutions and grants access to a specified number of seats (copies) across the entire academic institution. This subscription is intended solely for use in a classroom

2 · Introduction Highways User Guide

setting for teaching or a lab for research purposes under the direct supervision of faculty or other authorized personnel. The Software may only be installed on devices owned or controlled by the academic institution.

The End User is required to implement appropriate protection measures to prevent students or any other individuals from copying the Software and removing it from the lab or classroom environment. The responsibility for safeguarding the Software and preventing unauthorized copying or distribution rests entirely with the End User.

#### Virtualization for Virtual Classrooms:

Under the academic license, the End User may request permission to utilize a virtual environment for the installation and use of the Software. Such virtualization is only permitted with prior written consent from McTrans. If such permission is granted, the virtual environment must adhere to all protections and restrictions outlined in this Agreement, ensuring that the Software is used exclusively for its intended educational purposes and its access is limited to the institution's faculty and actively enrolled students only. Additionally, the number of seats purchased must be sufficient to cover the number of students and faculty accessing the virtual classroom.

#### 4. SUBSCRIPTION TERM:

#### 4.1 Duration:

The subscription term begins on the date of purchase and continues for the period specified at the time of purchase ("Subscription Term"). The license granted under this Agreement is valid only for the duration of the Subscription Term.

#### 4.2 Renewal:

Subscriptions may be renewed upon payment of applicable fees before the end of the Subscription Term. If the subscription is not renewed, access to the Software and all related services, including technical support, will be terminated.

#### 5. TECHNICAL SUPPORT:

#### 5.1 Support Services:

During the active Subscription Term, the End User is entitled to reasonable telephone or email support provided during the normal business hours of McTrans. McTrans reserves the right to determine the extent of the support provided.

#### 5.2 Revisions and Enhancements:

McTrans reserves the right to make substantial revisions and enhancements to the Software and to market such substantially revised versions as separate products. The End User shall not be entitled to receive such separate products without additional charge. Upon the release of any such revised version of the Software, the obligation to provide the above-described technical support services to the End User shall cease unless the End User chooses to pay to license the enhanced version of the Software, regardless of whether the End User has previously requested or received support on the prior version.

#### 6. NETWORK USE:

The End User is strictly prohibited from using the Software on any network. This prohibition includes but is not limited to the use of the Software either directly or indirectly through commands, data, or instructions transmitted to or from a computer that is not licensed or is not part of the licensed internal network. This also includes any use for Internet or web hosting services or by any user who does not hold a valid license for the Software from McTrans.

The Software is not designed for network use, and such use is unsupported. McTrans will not provide technical support for any issues resulting from network incompatibilities or unauthorized network use.

Highways User Guide Introduction · 3

#### 7. RESTRICTIONS ON USE:

The End User agrees that they shall not, nor shall they permit any third party to:

- Software Modification: Modify, adapt, translate, or create derivative works based on the Software, in whole
  or in part, without the express prior written consent of McTrans.
- Reverse Engineering: Reverse engineer, decompile, disassemble, or otherwise attempt to derive the source code of the Software, except to the extent expressly permitted by applicable law.
- Unauthorized Use: Use the Software for any purpose other than as expressly permitted under this Agreement, including unauthorized copying, distribution, or dissemination of the Software.
- Intellectual Property Infringement: Engage in any activity that infringes on the intellectual property rights of McTrans, including any unauthorized copying or distribution of the Software or associated documentation.
- Copying and Distribution: Copy, reproduce, or distribute the Software or associated printed documentation
  for sale, distribution, or dissemination, except as expressly provided under the terms of this Agreement or
  with the express prior written consent of McTrans.
- Documentation Use: Reproduce the associated documentation only as necessary for use within the permitted scope of the subscription type as outlined in this Agreement.
- Al Training and LLMS Restriction: The End User agrees not to use the Software to train or develop any artificial intelligence (AI) model or large language model system (LLMS) without the express prior written consent of McTrans. This includes, but is not limited to, using the Software to generate or fine-tune AI models, create or modify LLMS, or use the Software as a data source for AI or LLMS training. Any attempts to do so will be considered a material breach of this Agreement and may result in termination of the license.

#### Ownership of Software Modifications:

Any modifications, adaptations, translations, derivative works, or any other products or materials resulting from any prohibited actions shall become the exclusive property of McTrans, regardless of whether such actions were performed with or without McTrans' consent.

#### 8. INTELLECTUAL PROPERTY RIGHTS:

The Software and all associated intellectual property rights are owned by McTrans. No rights are granted to the End User other than the limited license expressly set forth in this Agreement.

#### 9. USE OF RESULTS IN RESEARCH AND COMMERCIAL PUBLICATIONS:

McTrans grants the End User legal permission to use the results generated by the Software in academic, research, or commercial publications, provided that such use complies with the terms of this agreement. The End User may publish or present findings derived from the Software as part of their research or commercial work as long as the Software is properly cited and all applicable license terms and restrictions are adhered to. Unauthorized reproduction or distribution of the Software itself remains strictly prohibited.

#### 10. TRANSFER OF LICENSE AND DEACTIVATION RESTRICTIONS:

The Software is licensed only to the End User, and this License Agreement may not be assigned or transferred to anyone without McTrans' prior written consent. Any authorized transferee of this License Agreement shall be bound by the terms of this License Agreement. The End User may not transfer, assign, rent, lease, sell, or otherwise dispose of the Software except as expressly provided in this License Agreement.

Deactivation requests are granted on a limited basis, such as hardware failure, device replacement or upgrade, reassignment of equipment, etc. To request deactivation, please email mctrans@ce.ufl.edu with a brief reason for your request and include the name of the computer or the machine you wish to deactivate. McTrans will then provide you with instructions on how to deactivate a license so you can use it on a different machine.

4 · Introduction Highways User Guide

#### 11. LIMITED WARRANTY AND LIMITATIONS OF REMEDIES:

End User acknowledges and agrees that it is the sole responsibility of End User to fully understand the limitations and assumptions underlying the Software and to refrain from using the Software without the assistance of personnel with appropriate expertise. The End User accepts full responsibility for reviewing, interpreting, applying, and utilizing the output of the Software and for ensuring that such output complies with any applicable design codes, standards, or project specifications.

Except as expressly provided herein, the Software is provided "AS IS" without warranty of any kind, whether expressed or implied, including, but not limited to, implied warranties of merchantability and fitness for a particular purpose. McTrans does not warrant that the functions contained in the Software will meet the End User's requirements or that the operation of the Software will be uninterrupted or error-free. The entire risk as to the quality and performance of the product is with the End User.

In no event will McTrans be liable to the End User for any damages, including any lost profits, lost savings, or other incidental or consequential damages arising out of the use of or inability to use the Software, even if McTrans has been advised of the possibility of such damages, or for any claim by any other party. The above warranty gives the End User specific legal rights, and the End User may also have other rights in the United States, which vary from state to state.

Use of the Software where the End User believes or has reason to believe that damage may occur constitutes a violation of any and all warranties. McTrans has no knowledge of the hardware or Software configurations of the End User and assumes no liability for their damage.

#### 12. TERMINATION:

#### 12.1 Termination by McTrans:

McTrans may terminate this Agreement immediately upon notice if you fail to comply with any term or condition of this Agreement. Upon termination, you must cease all use of the Software and destroy all copies of the Software in your possession.

#### 12.2 Termination by End User:

You may terminate this Agreement at any time by discontinuing the use of the Software and notifying McTrans. No refunds will be provided for any remaining portion of the Subscription Term.

#### 13. GOVERNING LAW:

This License Agreement shall be governed by the laws of the State of Florida, U.S.A. Venue for all disputes related to this License Agreement shall be in the United States District Court of the Northern District of Florida, Gainesville Division, or in the Circuit Court of the Eighth Judicial Circuit for Alachua County, Florida.

#### 14. U.S. GOVERNMENT RESTRICTED RIGHTS:

The Software and associated documentation are provided with RESTRICTED RIGHTS. Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subdivision (c)(1)(ii) of The Rights in Technical Data and Computer Software clause at 52.227-7013 or subparagraphs (c)(1) and (2) of the Commercial Computer Software - Restricted Rights at 48CFR52.227-19. The contractor is McTrans, University of Florida, PO Box 116585, Gainesville, FL 32611-6585.

#### 15. EXPORT REGULATION:

The Software may be subject to U.S. export control laws and regulations, including the U.S. Export Control Reform Act and its associated regulations. End User will not directly or indirectly export, re-export, transfer, or release the Software to, or make the Software accessible from, any country, jurisdiction, or person to which export, re-export, transfer, or release is prohibited by applicable U.S. laws and regulations. End User will comply with all applicable

Highways User Guide Introduction · 5

laws and regulations and complete all required undertakings (including obtaining any necessary export license or other governmental approval) prior to exporting, re-exporting, transferring, or releasing, or otherwise making the Software available, outside the U.S. End User shall not export, re-export, transfer, or release the software or software source code to any country which is comprehensively sanctioned by the U.S. Department of the Treasury, Office of Foreign Assets Control (OFAC).

#### 16. SEVERABILITY:

If any portion of this License Agreement shall be declared void or a nullity by a court of competent jurisdiction, then the remainder shall survive and remain in full force. Should you have any questions concerning this license, you may contact the McTrans Center, University of Florida, PO Box 116585, Gainesville, FL 32611-6585, U.S.A., [1] (800) 226-1013.

# **Acknowledgements**

McTrans Center, University of Florida Transportation Institute PO Box 116585, Gainesville FL 32611-6585 Telephone: 1-800-226-1013 Fax: 352-392-6629 Web: mctrans.ce.ufl.edu Email: mctrans@ce.ufl.edu

We acknowledge the Transportation Research Board (TRB), the USDOT's Federal Highway Administration (FHWA), the American Traffic Safety Services Association (ATSSA), the Institute of Transportation Engineers (ITE), and the American Association of State Highway and Transportation Officials (AASHTO) for all text, figures, and references included in HCS and express our sincere appreciation for permission to include this information.

### **Trademarks and Copyrights**

- Microsoft(R), MS-DOS(R), and Windows(TM) are registered trademarks of Microsoft Corporation.
- McTrans(TM), HCS(TM), HSS(TM), TSIS-CORSIM(TM), and TRANSYT-7F(TM) are trademarks of the University of Florida.
- HCS, HCS2026, HCS2025, HCS2024, HCS2023, HCS2022, HCS7, HCS 2010, HCS+, HSS, HSS2026, HSS2025, HSS2024, TRANSYT-7F, and T7F are copyright University of Florida.
- TSIS-CORSIM, TSIS-CORSIM2026, TSIS-CORSIM2025, TSIS-CORSIM2024, TSIS-CORSIM2023, TSIS-CORSIM2022, TSIS, CORSIM, NETSIM, FRESIM, TRAFED, TRAFVU, and TShell are copyright University of Florida, with portions copyright ITT Industries, Inc., Systems Division.

6 · Introduction Highways User Guide

# **Getting Started**

## **System Requirements**

HCS is designed for standard Windows installations. For optimal performance, the system should be Windows 10 or newer. While HCS may be compatible with older versions of Windows, any installation and operational issues arising from using these older versions will be the sole responsibility of the end user.

### **Getting Started**

To begin, click on File then New (or the "New File..." button on the Start page).

Normal Windows keyboard and mouse functions are available. Tabbing, clicking to a new field, or pressing the Enter key will trigger a recalculation and update the report.

#### **Multilane Highway Analysis**

Multilane Highway analyses will estimate Capacity and Level of Service (LOS) for a given set of traffic and geometric conditions. This type of analysis is oriented toward the evaluation of an existing or planned segment or facility. The methodology and procedures of application use the HCM Chapter 12 procedures.

#### **Two-Lane Highway Analysis**

Two-lane Highway analyses will estimate Capacity and Level of Service (LOS) for a given set of traffic and geometric conditions. This type of analysis is oriented toward the evaluation of an existing or planned segment or facility. The methodology and procedure of application use the HCM Chapter 15 procedures.

Highways User Guide Getting Started · 7

# **General Controls**

### Menu Items

New - Creates a new Multilane or TwoLane file (\*.xuf) and starts a new analysis project; shortcut is Ctrl+N

**Multilane Segment** – Creates a new Multilane file (\*.xuf) and starts a new Multilane Segment analysis project

**Two-Lane Segment** – Creates a new TwoLane file (\*.xuf) and starts a new TwoLane Segment analysis project

Two-Lane Facility - Creates a new TwoLane file (\*.xuf) and starts a new TwoLane Facility analysis project

Open – Opens an existing Multilane or TwoLane file (\*xuf, \*.xhm, or \*.xh2); shortcut is Ctrl+O

**Example Folder** – Opens folder with all HCS examples in File Explorer

Save - Saves an open Multilane or TwoLane file (\*.xuf) using the current file name; shortcut is Ctrl+S

Save As... - Saves an open Multilane or TwoLane file (\*.xuf) using a specified file name; shortcut is F12

Close - Closes an existing Multilane or TwoLane file (\*.xuf); shortcut is Ctrl+W

#### Units

**USC Units** – Changes the units of the current file to U.S. Customary

**Metric Units** – Changes the units of the current file to Metric

**Print** – Brings up printer selection and prints a Multilane or TwoLane report to the printer or specified file type; shortcut is Ctrl+P

Print Preview – Displays preview of current report before printing; shortcut is Ctrl+F2

#### View

Page View – Changes the view to display inputs and report by pages; shortcut is F9

#### **Full View**

**Report -> Right** – Changes the view to display both the input screen and report simultaneously; the report is displayed on the right portion of the screen; shortcut is F10

**Report -> Bottom** – Changes the view to display both the input screen report simultaneously; the report is displayed on the bottom portion of the screen; shortcut is F11

#### Report

Formatted Report - Displays formatted report including the most important values; shortcut is F4

Text Report - Displays text report with input, intermediary, and final results; shortcut is F6

8 · General Controls Highways User Guide

**Import From CSV** – Imports the analysis inputs of both directions from a CSV file into the \*.xuf file for a Multilane file; imports the analysis inputs of the segment(s) from a CSV file into the \*.xuf file for a TwoLane file

**Export To CSV** – Exports the analysis inputs of both directions from the \*.xuf file into a CSV file for a Multilane file; exports the analysis inputs of the segment(s) from the \*.xuf file into a CSV file for a TwoLane file

**Default Settings** – Opens a dialog box for the user to input defaults for Analyst, Agency, and Jurisdiction, which will be applied to all new files; also allows selection of USC or SI units, which will be applied to all new files; also provides option to include Safety Analysis results, which will be applied to all newly opened files; shortcut is Alt+F

#### Help

**Contents** – Provides access to glossary, acknowledgements, copyrights, and information on the HCM procedures; shortcut is Ctrl+F1

Index - Allows user to search keywords within the glossary

**Search** – Allows user to search for any word within the glossary

User Guide - Opens a comprehensive user guide in PDF format; shortcut is Ctrl+G

**HCM Reference Guide** – Opens the McTrans website in the default web browser to request access to a reference guide for the HCM in PDF format

**HCM Volume 4 Website** – Opens the Highway Capacity Manual Volume 4 website in the default web browser to access the free online resource

**HCS Updates** – Sends the HCS version number anonymously without any personally identifiable information to McTrans to check for a newer version

**HCM/HCS Training** – Opens the McTrans Training Page in the default web browser to view the latest training opportunities

**HCQS Website** – Opens the TRB Highway Capacity and Quality of Service Committee website in the default web browser

#### Support

**Frequently Asked Questions** – Opens the McTrans support page for HCS in the default web browser

HCS Overview - Opens the McTrans HCS Overview page in the default web browser

McTrans Website - Opens the McTrans home page in the default web browser

**E-mail McTrans** – Composes a new e-mail addressed to McTrans in the default e-mail client with registration number, serial key, module, and version number already populated in the Subject field

**About HCS** – Opens an about window with software version information, EULA, general acknowledgements, contact information, and other relevant links

#### **CORSIM**

**View Animation** – Sends data to the TSIS-CORSIM program for simulation and/or animation purposes, TRAFVU can be opened within TSIS-CORSIM case to allow user to view animation; shortcut is Ctrl+Shift+A

**Generate TRF File** – Saves an open Highways file (\*.xuf) as a CORSIM file (\*.trf), which is a file that contains the input data used to define a CORSIM network and to drive the CORSIM simulation for a single simulation case; shortcut is Ctrl+Shift+T

Exit – Exits the HCS Highways module; shortcut is Alt+F4

Highways User Guide General Controls · 9

# **Multilane Highway Segments**

## **HCM Chapter 12**

The Highway Capacity Software (*HCS*) faithfully implements the methodology prescribed in the Highway Capacity Manual (HCM) for analyzing Basic Freeway and Multilane Highway Segments. These segments are outside the influence of merging, diverging, and weaving maneuvers. In the case of multilane highways, they are also outside the influence of signalized intersections. Because of the similar operational characteristics of basic freeway and multilane highway segments, they are analyzed with the same methodology.

Chapter 12 focuses on *uninterrupted flow*, which refers to access-controlled facilities, with access and egress being controlled through grade-separated cross streets and ramp movements to access the facility. For multilane highways, uninterrupted flow also exists when there are no traffic control devices that interrupt traffic and where no platoons are formed by upstream traffic signals.

The methodologies in this chapter are limited to *uncongested flow* conditions. Uncongested flow conditions require that the demand-to-capacity ratio for the segment is less than or equal to 1.0. Uncongested flow on freeways and multilane highways further means that there are no queuing impacts on the segment from downstream bottlenecks. The HCM does not currently provide a method for evaluating oversaturated multilane highways, other than to identify them as LOS F.

The bicycle methodology is identical for two-lane highways and multilane highways. Details are provided in Chapter 15, Two-Lane Highways. Bicycle levels of service for multilane highway segments are based on a bicycle LOS score, which is in turn based on a traveler perception model.

## **Operational Data**

#### **Geometric Data**

For multilane highway segments, there are inputs for each direction. The number of lanes for both directions is entered. The user chooses the type of Terrain (Level, Rolling, or Specific Grade). If Specific Grade is chosen, fields for Percent Grade and Grade Length will enable for the user to change. Lane Width, Base Free Flow Speed, and Right Side Clearance are also available as inputs. Access-Point Density, Median (left) Side Clearance, and Median Type are also included for each direction. However, if a Median Type is selected for one direction, the other direction will automatically update to reflect the same Median Type.

Checkboxes are provided for Measured FFS to indicate if it is necessary for the current analysis. When Measured FFS is checked, the following fields are disabled: Lane Width, Right Side Clearance, Median (Left) Side Clearance, and Access-Point Density. The input for Base Free Flow Speed is then taken as the measured Free Flow Speed.

#### **Demand Data**

Demand, Peak Hour Factor, Percent Total Trucks, Percent Single-Unit Trucks, and Percent Tractor-Trailers are included as inputs for multilane highway segments.

If 'Mixed Flow Model' is checked, the mixed-flow model will be used to assess capacity, speed, and density in addition to the traditional passenger-car-equivalent (PCE) method. Results of both methods will be provided in the

reports.

#### **Adjustment Factors**

Driver Population is taken into account. This affects the Speed and Capacity Adjustment Factors. However, if the user chooses to override the default values based on driver population, they can change the adjustment factors.

#### **Bicycle LOS**

Outside Lane Width, Shoulder Width, Speed Limit, Pavement Condition Rating, and Percent Occupied Parking are included as inputs for the evaluation of bicycle level of service.

#### Results

A multilane highway segment can be characterized by three performance measures: density in passenger cars per mile per lane (pc/mi/ln), space mean speed in miles per hour (mi/h), and the ratio of demand flow rate to capacity (v/c). Since speed is constant through a broad range of flows and the v/c ratio is not directly discernible to road users (except at capacity), the service measure for multilane segments is density.

Level of Service (LOS) Criteria for Basic Freeway and Multilane Highway Segments:

	Density (pc/mi/ln) [USC]	Density (pc/km/ln) [SI]
LOS A	≤11	≤7
LOS B	>11 - 18	>7 – 11
LOS C	>18 - 26	>11 – 16
LOS D	>26 - 35	>16 – 22
LOS E	>35 - 45	>22 - 28
LOS F	>45 or v/c>1.0	>28 or v/c>1.0

Bicycle levels of service for multilane highway segments are based on a bicycle LOS score, which is in turn based on a traveler perception model.

Bicycle Level of Service (LOS) Criteria for Multilane Highway Segments:

	Bicycle LOS Score
LOS A	≤1.5
LOS B	>1.5 - 2.5
LOS C	>2.5 - 3.5
LOS D	>3.5 - 4.5
LOS E	>4.5 - 5.5
LOS F	>5.5

### **Safety Results**

When 'Show Safety Analysis Results in Reports' is checked in the *Default Settings*, predicted crashes will be computed based on the Highway Safety Manual (HSM) methods for the corresponding road type.

Due to the structural differences between the HCM and HSM methods, certain transformations are required to convert HCM inputs into HSM inputs. Additionally, not all HSM-required data is available from HCM. Therefore, certain assumptions are included in the calculations.

The next section lists the conversion process of internal parameters, default values, and assumptions used to compute safety results in the *Highways* module for Multilane.

The following HCS Multilane inputs are internally converted to HSS as shown:

- Directional Volume (veh/h): The sum of demand volumes from both directions in *Multilane* are added together, then the bidirectional peak hour volume is converted to 'AADT (veh/day)' by applying the 'K-Factor'. This factor can be defined by the user in the *Default Settings*.
- Lane Width: If 'Lane Width' is entered in *Multilane*, no conversion is needed. Otherwise, a base condition
  value of 12 ft is applied.

- Model Type: If the 'Median Type' in *Multilane* is entered as 'TWLTL' or 'Undivided', the 'Model Type' in HSS will be 'Undivided'. Otherwise, the 'Model Type' used will be 'Divided'.
- Paved Right Shoulder Width (Divided): If 'Right-Side Clearance' is entered in Multilane, the average of both directions is used in HSS. Otherwise, a default value of 6 ft is applied.
- Shoulder Width (Undivided): If 'Right-Side Clearance' is entered in *Multilane*, the average of both directions is used in HSS. Otherwise, a default value of 6 ft is applied.

The following inputs required in *HSS* are not used in *HCS Multilane*. Therefore, the base conditions are assumed in the calculation of safety results, represented by the following values:

Segment Length: 1 mile

Driveway Density (DD): 5 driveways per mile

Horizontal Curvature: None

Roadside Hazard Rating: 3

Median Barriers (Divided): None

• Shoulder Type (Undivided): Paved

• Sideslope (Undivided): 1:7

Centerline Rumble Strips: None

Two-Way Left Turn Lanes: None

Lighting: None

Automated Speed Enforcement: None

### **Multilane Highway Report**

The report page shows a formatted version of the analysis in a dynamic form, reacting to changes in the Multilane page. All or a portion can be copied to the Windows clipboard for insertion into other files by right-clicking into the report and selecting Copy.

Both formatted and text reports are available for viewing and printing. The formatted report provides data and results that are most important to the user, and are displayed in a clean and more presentable fashion. The text report provides more details to the user, rather than a summary.

The user can switch between reports by clicking on the button found at the bottom of the Report page.

# **Two-Lane Highways**

### **HCM Chapter 15**

This Highway Capacity Software (*HCS*) faithfully implements the methodology prescribed in the Highway Capacity Manual (HCM) for analyzing Two-Lane Highways. Two-lane highways have one lane for use of traffic in each direction. The principal characteristic that distinguishes two-lane highway operation from that of other uninterrupted-flow facilities is that passing maneuvers take place in the opposing lane of traffic. Passing maneuvers are limited by the availability of gaps in the opposing traffic stream and by the availability of sufficient sight distance for a driver to discern the approach of an opposing vehicle safely. As demand flows and geometric restrictions increase, opportunities to pass decrease. This creates platoons within the traffic stream, with trailing vehicles subject to additional delay because of the inability to pass the lead vehicles.

Chapter 15 presents methodologies for analyzing two-lane highway operations under uninterrupted-flow conditions. Uninterrupted flow exists when there are no traffic control devices that interrupt traffic and where no platoons are formed by upstream signals or roundabouts. In general, any segment that is more than 2.0 mi from the nearest signalized intersection fits into this category. When traffic signals are less than 2.0 mi apart, the facility should be classified as an urban street and analyzed with the methodologies of Chapter 16, Urban Street Facilities, and Chapter 18, Urban Street Segments.

The methodology is most directly used to determine the LOS on a uniform directional segment of two-lane highway by estimating the service measure of Follower Density that defines LOS. Such an analysis can also be used to determine the capacity of the directional segment or the service flow rate that can be accommodated at any given LOS.

### **Operational Data**

#### **Geometric Data**

On the Input page for a Segment analysis or the Details page for a Facility analysis, the user can choose the Coded Type, which includes the following options: Passing Constrained, Passing Zone, and Passing Lanes. Other inputs include, Measured FFS, Analyze Bicycle Results, Free-Flow Speed, Speed Limit, Lane Width, Shoulder Width, Percent Grade, Access Point Density, Pavement Condition Rating, and Percent Occupied Parking.

Checkboxes are provided for Measured FFS and Analyze Bicycle Result to indicate if they are necessary for the current analysis. When Measured FFS is checked, the Access-Point Density field is disabled, and the Free-Flow Speed field is enabled. The input for Free Flow Speed is then taken as the measured Free Flow Speed. When Analyze Bicycle Results is checked, the Pavement Condition Rating and Percent Occupied Parking fields are enabled for the user to edit. Bicycle results will also be added to both the formatted and text reports.

#### **Demand Data**

On the input page for a Segment analysis, Directional Demand, Opposing Demand, Peak Hour Factor, and Total Trucks are included as inputs for two-lane highway segments. Opposing Demand is only enabled when the Segment Coded Type selected is Passing Zone.

Highways User Guide Two-Lane Highways · 13

#### **Segments Input**

On the Segments page for a Facility analysis, the geometric and demand data can be found under the Segments Input section. In this section, the user can add, insert, or delete segments within the facility using the buttons Add Segment, Insert Segment, and Delete Segment, respectively. The Type of segment can be specified as Passing Constrained, Passing Zone, or Passing Lanes. For each segment, the corresponding segment Name, Length, Speed Limit, Directional Volume, Opposing Volume, Peak Hour Factor, and Heavy Vehicle Percentage can be entered. Opposing Volume is only enabled when the segment type selected is Passing Zone. For each segment, a Details link is also provided. Clicking the Details link for a segment will bring the user to the Details page for that specific segment.

On the Segments page for a Facility analysis, there is also a 'Map-Based Segmentation' button that will bring up a separate 'Segmentation' window for editing. Please see *Map-Based Segmentation* for details.

#### **Subsegments**

On the Input page for a Segment analysis or the Details page for a Facility analysis, the user can add, insert, or delete subsegments within the current segment using the buttons Add Subsegment, Insert Subsegment, and Delete Subsegment, respectively. The Type of each subsegment can be specified as Tangent or Horizontal Curve and the corresponding Length can also be entered. If the subsegment type selected is Horizontal Curve, the user can specify the corresponding Radius and Superelevation.

#### **Bicycle LOS**

On the Input page for a Segment analysis or the Details page for a Facility analysis, Lane Width, Shoulder Width, Speed Limit, Pavement Condition Rating, and Percent Occupied Parking are included as inputs for the evaluation of bicycle level of service.

#### **Facility Graphic**

On the Segments page for a Facility analysis, a facility graphic is provided under the Segment Input section to help better visualize the facility being analyzed. It provides information on the Segment Type, Segment Length in feet, and Segment ID. This same graphic can be found on the Details page for a Facility analysis, with the currently viewed segment being highlighted. The user can switch between segment inputs by selecting the desired segment in the graphic itself. The user also has the option of changing the color of the graphic based on difference performance measures, which include Speed and Follower Density. Selecting 'None' will leave the graphic the color of a road. A legend for different colors appears to the side of the graphic when any of the other options are selected.

#### Results

If the volume-to-capacity ratio is less than or equal to 1.0, follower density is used as the service measure for all two-lane highways. However, two sets of LOS thresholds are used to account for differences in driver perception between driving on higher-speed versus lower-speed highways.

On higher-speed two-lane highways (≥50 mi/h, ≥80 km/h in metric), absolute speed and delay due to passing restrictions are generally both important to motorists. Higher-speed two-lane highways are most commonly encountered as inter-city connecting routes. Lower-speed two-lane highways (<50 mi/h, or <80 km/h in metric) are typically encountered as intra-city routes and in scenic and rural-developed areas. These highways generally have posted speed limits of 35-45 mi/h (or 56.3-72.4 km/h in metric) and have limited passing opportunities. Thus, for two-lane highways in these areas, high speeds are usually not expected and higher percentages of followers are generally tolerated. Consequently, the follower density thresholds for a given LOS are higher for lower-speed highways than higher-speed highways.

Please note that when converting between units (USC to Metric, or Metric to USC), the follower density table speed limits are not exact. When converting from USC to Metric, the speed limit of 50 mi/h converts to 80.5 km/h. When converting from Metric to USC, the speed limit of 80 km/h converts to 49.7 mi/h.

14 · Two-Lane Highways Highways User Guide

Level of Service (LOS) Criteria for Two-Lane Highways:

	Follower Density (followers/mi)	Follower Density (followers/mi)
	Higher-Speed Highways	Lower-Speed Highways
	Posted Speed Limit ≥ 50 mi/h	Posted Speed Limit < 50 mi/h
LOS A	≤2.0	≤2.5
LOS B	>2.0 - 4.0	>2.5 - 5.0
LOS C	>4.0 - 8.0	>5.0 - 10.0
LOS D	>8.0 - 12.0	>10.0 - 15.0
LOS E	>12.0	>15.0

Note: LOS F exists when demand exceeds capacity.

Level of Service (LOS) Criteria for Two-Lane Highways in Metric units:

	Follower Density (followers/km)	Follower Density (followers/km)
	Higher-Speed Highways	Lower-Speed Highways
	Posted Speed Limit ≥ 80 km/h	Posted Speed Limit < 80 km/h
LOS A	≤1.2	≤1.6
LOS B	>1.2 - 2.5	>1.6 - 3.1
LOS C	>2.5 - 5.0	>3.1 - 6.2
LOS D	>5.0 - 7.5	>6.2 - 9.3
LOS E	>7.5	>9.3

Note: LOS F exists when demand exceeds capacity.

Bicycle levels of service for two-lane highway segments are based on a bicycle LOS score, which is in turn based on a traveler perception model.

Bicycle Level of Service (LOS) Criteria for Two-Lane Highway Segments:

	Bicycle LOS Score
LOS A	≤1.5
LOS B	>1.5 - 2.5
LOS C	>2.5 - 3.5
LOS D	>3.5 - 4.5
LOS E	>4.5 - 5.5
LOS F	>5.5

### **Safety Results**

When 'Show Safety Analysis Results in Reports' is checked in the *Default Settings*, predicted crashes will be computed based on the Highway Safety Manual (HSM) methods for the corresponding road type.

Due to the structural differences between the HCM and HSM methods, certain transformations are required to convert HCM inputs into HSM inputs. Additionally, not all HSM-required data is available from HCM. Therefore, certain assumptions are included in the calculations.

The next section lists the conversion process of internal parameters, default values, and assumptions used to compute safety results in the *Highways* module for Two-Lane.

The following HCS Two-Lane inputs are internally converted to HSS as shown:

- Demand Volume (veh/h): The 'Demand Volume' is converted to 'AADT (veh/day)' by applying 'K-Factor'
  and 'D-Factor'. These factors can be defined by the user in the *Default Settings*. The 'Opposing Demand',
  applicable for Passing Zone segments, is not used internally in the safety calculations.
- Lane Width: If 'Lane Width' is entered in *Two-Lane*, no conversion is needed. An average lane width considering both directions is used. Otherwise, a base condition value of 12 ft is applied.
- Segment Length (ft): Lengths in feet are internally converted to miles.
- Grade: No conversion is needed.

Highways User Guide Two-Lane Highways · 15

• Shoulder Width: No conversion is needed.

The following inputs required in *HSS* are not used in *HCS Two-Lane*. Therefore, the base conditions are assumed in the calculation of safety results, represented by the following values:

Horizontal Curvature: None

Roadside Hazard Rating: 3

• Shoulder Configuration: Paved Shoulder

Lighting: None

Automated Speed Enforcement: None

## **Two-Lane Highway Report**

The report page shows a formatted version of the analysis in a dynamic form, reacting to changes in the Input page for a Segment analysis or the Segments and Details pages for a Facility analysis. All or a portion can be copied to the Windows clipboard for insertion into other files by right-clicking into the report and selecting Copy.

Both formatted and text reports are available for viewing and printing. The formatted report provides data and results that are most important to the user, and are displayed in a clean and more presentable fashion. The text report provides more details to the user, rather than a summary.

The user can switch between reports by clicking on the button found at the bottom of the Report page.

16 · Two-Lane Highways Highways User Guide

# **How To**

### **Create a New File**

1. From the Start screen, there are three options for creating a new file:



Note: A new file can be created if an existing file is already open; you do not need to start from the Start screen.

a. Selecting *File > New* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen, hovering over "New", and then selecting one of the analysis types.




Selecting "New File..." from the Start screen; this can be found below in the red box. A Select New File Type dialog box will pop up after selecting "New File..." which allows you to choose the desired analysis type.



c. Using the keyboard shortcut "Ctrl+N", selecting one of the analysis types from the Select New File Type dialog box, and clicking "OK"




- 2. Once a new file is created, you will be brought to the input page of the selected analysis type if in Page View or the input screen split with the report either on the right or the bottom of the screen if in Full View.
  - a. Page View



- i. If Multilane Segment or Two-Lane Segment was selected, you will be brought to the Input page.
- ii. If Two-Lane Facility was selected, you will be brought to the Segments page.

#### b. Full View



# **Open an Existing File**

1. From the Start screen, there are six options for opening an existing file:



Note: A file can be opened even if another file is currently open; you do not need to start from the Start screen.

a. Selecting *File* > *Open* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Open"



Selecting "Open File..." from the Start screen; this can be found below in the red box



c. Using the keyboard shortcut "Ctrl+O"

 Selecting a file under the Recent files list from the Start screen; this can be found below in the red box




e. Selecting File > Example Folder from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Example Folder". Opening the example folder will open the path of the HCS example files in File Explorer. The desired example file can be double-clicked or right-clicked and selecting 'Open', which will open the example file in the Highways program.




f. Selecting "Example Folder..." from the Start screen; this can be found below in the red box. Opening the example folder will open the path of the HCS example files in File Explorer. The desired example file can be double-clicked or right-clicked and selecting 'Open', which will open the example file in the Highways program.



- 2. Once an existing file is opened, you will be brought to the corresponding input page if in Page View or the input screen split with the report either on the right or the bottom of the screen if in Full View
  - a. Page View




#### b. Full View




### Save a File


- 1. There are five options for saving an open file:
  - a. Selecting *File > Save* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Save"



b. Selecting *File > Save As...* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Save As..."



- c. Using the keyboard shortcut "Ctrl+S" for Save
- d. Using the keyboard shortcut "F12" for Save As
- e. Exiting the program or closing the file without saving changes beforehand; this will prompt you to save changes to the file before anything is closed




- Selecting "Yes" will save the file if it is an existing file. If the file has not been previously saved, the Save As dialog box will pop up allowing you to change the file name and save it.
- ii. Selecting "No" will exit the program or close the file without saving the file
- iii. Selecting "Cancel" will prevent the file from closing

Note: Using Save with an existing file will save a file without prompting you to specify a file name. Using Save with a new file will bring up the Save As dialog box for you to specify a file name for saving. Using Save As will always bring up the Save As dialog box for you to specify a file name for saving.

### Close a File

1. There are three options for closing an open file:

a. Selecting *File > Close* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Close"



- b. Using the keyboard shortcut "Ctrl+W"
- c. Exiting the program itself; please see How To: Exit the Program

### **Exit the Program**

1. From the Start screen, there are three options for exiting the program:



Note: The program can be exited even if a file is still open; you do not need to start from the Start screen.

a. Selecting *File > Exit* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Exit"



- b. Using the keyboard shortcut "Alt+F4"
- c. Selecting "X" in the top right-hand corner of the screen; this can be found below in the red box




### **Edit the Default Settings**

1. From the Start screen, there are two options for editing the Default Settings:




Note: The Default Settings can be changed even if an existing file is already open; you do not need to start from the Start screen.

a. Selecting *File > Default Settings* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Default Settings"



b. Using the keyboard shortcut "Alt+F"

2. Opening the Default Settings will cause a Default Settings window to pop up:




#### 3. Settings


- a. You can specify Analyst, Agency, and Jurisdiction by clicking in the corresponding text boxes and typing the desired text.
- b. Under 'Units', you are given the option of running the analysis in either *U.S. Customary (USC)* or *SI (Metric)* units.
- c. Under 'Safety Analysis', you are given the option of displaying safety analysis results in reports.
  - i. Show Safety Analysis Results in Reports: If this is checked, a section for safety analysis results will be displayed in the text report.
  - ii. K-Factor: The value indicated in this textbox will apply to the safety calculations if results are shown
  - iii. D-Factor: The value indicated in this textbox will apply to the safety calculations if results are shown
- 4. Clicking "OK" will save the changes made and close the Default Settings window; clicking "Cancel" will close the Default Settings window without saving any changes.
  - a. When a new file is created, the Analyst, Agency, and Jurisdiction fields will automatically be populated with the text specified in the Default Settings.
  - b. When starting a new file, the inputs and results will display according to the units specified in the Default Settings.
  - c. When viewing the text report, safety results will be displayed or hidden depending on what is checked in the Default Settings.
    - i. If the desired selection indicates to show safety results, it is important to note that they will only update after saving the file.
      - 1. If a new file is created, the safety results section will at first be hidden.
      - 2. If inputs are changed in an existing file, it will be necessary to save the file first before the safety results will update.

## **Change the View**


- 1. When a file is open, there are three main options for the view of the program:
  - a. Page View: the input and results reports are separated into pages as seen below. You can navigate between pages using the "Back" and "Next" buttons or by clicking the page names found at the top of the screen.




b. Full View with the report on the right of the screen: the screen is split with all inputs on the left side and the results reports on the right side. You can access all inputs and view all of the current report by using the corresponding scroll bars. There is also a screen splitter that can be moved to adjust the views of the input screen and results report.




c. Full View with the report on the bottom of the screen: the screen is split with all inputs on the top of the screen and the results reports on the bottom of the screen. You can access all inputs and view all of the current report by using the corresponding scroll bars. There is also a screen splitter that can be moved to adjust the views of the input screen and results report.




- 2. Views can be changed by using the main menu items or the keyboard shortcuts.
  - a. Main Menu Items
    - i. To switch to Page View, select File > View > Page View from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen, hovering over "View", and then selecting "Page View".



ii. To switch to Full View with the report on the right of the screen, select *File > View > Full View > Report -> Right* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen, hovering over "View", hovering over "Full View", and then selecting "Report -> Right".




iii. To switch to Full View with the report on the bottom of the screen, select File > View > Full View > Report -> Bottom from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen, hovering over "View", hovering over "Full View", and then selecting "Report -> Bottom".




- b. Keyboard Shortcuts
  - i. Page View: keyboard shortcut is "F9"
  - ii. Full View with report on the right of the screen: keyboard shortcut is "F10"
  - iii. Full View with report on the bottom of the screen: keyboard shortcut is "F11"

### **Create a Horizontal Curve**


- 1. There are two options for creating a horizontal curve in a Two-Lane Facility analysis.
  - a. Add a curve through the segment input table
    - i. In the current Two-Lane Facility analysis, there is a Segments Input section on the Segments page.



ii. In the data grid, select the "Details" link of the desired segment. This will cause the Details page of the selected segment to open.




- 1. The Details page can also be accessed by selecting the Details page at the top bar. The desired segment can then be selected by clicking on the segment in the facility graphic at the top of the page.
- iii. Under the Subsegments section, add a subsegment to the segment by clicking the "Add Subsegment" button.




iv. In the data grid, select "Horizontal Curve" for the Type. Edit the Length, Radius, and Superelevation as necessary.

#### b. Map-Based Segmentation



- i. Create the entire facility using the Map-Based Segmentation functionality. This function can be accessed in the Two-Lane Facility analysis by selecting the 'Map-Based Segmentation' button found under the Segments Input section on the Segments page.
- ii. After creating the facility using the map, access the Subsegment Editor by clicking on the "Details" link of the desired segment.
- iii. In the Subsegment Editor, right-click on the beginning boundary node of the segment and select "Insert Horizontal Curve Subnode After Current Node".



- iv. Drag the subnode to the correct location and edit Radius and Superelevation in the data grid.
- v. Please see Map-Based Segmentation in the glossary for more details.

# View Results of the Analysis

1. After editing all the necessary inputs, results of the analysis can be found in the form of reports. Reports can be found on the Report page if using Page View or on the results portion of the split screen if using Full View.

## START SCANIS CRIACE

\*\*\*Project Information\*\*\*

\*\*\*Project Information\*\*


\*\*\*Project Information\*\*\*

\*\*\*Project Information\*\*


a. Page View with Report page displayed

b. Full View with the report on the right of the screen

Highways User Guide How To · 35




c. Full View with the report on the bottom of the screen




36 · How To Highways User Guide

2. There are two options for reports: Formatted and Text





Text reports show a more detailed analysis in plain text




3. The type of report displayed can be changed by using the main menu items, keyboard shortcuts, or toggle buttons found under the report


Highways User Guide How To · 37

#### a. Main Menu Items

i. To switch to the Formatted Report, select *File > Report > Formatted Report* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen, hovering over "Report", and then selecting "Formatted Report".




ii. To switch to the Text Report, select *File > Report > Text Report* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen, hovering over "Report", and then selecting "Text Report".




- b. Keyboard Shortcuts
  - i. Formatted Report: keyboard shortcut is "F4"
  - ii. Text Report: keyboard shortcut is "F6"

38 · How To Highways User Guide

- c. Report Toggle Buttons
  - i. Toggle buttons are available at the bottom of the screen underneath the report.
  - ii. If the formatted report is currently being displayed, the toggle button will say "Switch to Text Report" which will allow you to display the text report if clicked.




iii. If the text report is currently being displayed, the first toggle button will say "Switch to Formatted Report" which will allow you to display the formatted report if clicked.



Highways User Guide How To · 39

iv. For a two-lane facility analysis, there are two options for displaying the reports: single segment report or facility report. A dropdown menu along with a checkbox is provided to indicate which type of report to display.




- 1. The dropdown menu allows the selection of which single segment report to display. This is only enabled if the 'All Segments' checkbox is unchecked.
  - a. Below is an example of a single segment formatted report for Segment 1 in a facility being displayed.




- 2. The 'All Segments' checkbox indicates whether or not to display the single segment report or facility report.
  - a. Formatted Report
    - i. Checking 'All Segments' will display the facility formatted report.
    - ii. Unchecking 'All Segments' will display the results for a single selected segment.
  - b. Text Report
    - i. Checking 'All Segments' will include the results for all segments and display them one after the other.
    - ii. Unchecking 'All Segments' for the text report will display the results for a single selected segment.

40 · How To Highways User Guide

c. Below is an example of a facility formatted report being displayed.



4. The magnification of the report currently being displayed can be changed using the zoom slider found at the bottom right-hand corner of the screen.




- a. To zoom in, drag the slider to the right; to zoom out, drag the slider to the left
- b. Clicking the plus (+) button will zoom in; clicking the minus (-) button will zoom out
- c. Holding down "ctrl" on the keyboard and scrolling up on the mouse wheel will zoom in; holding down "ctrl" on the keyboard and scrolling down on the mouse wheel will zoom out


Highways User Guide How To · 41

# **Print a Report**

- 1. There are four options for printing a report:
  - a. Selecting *File > Print* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Print"



b. Selecting *File > Print Preview* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Print Preview"




- c. Using keyboard shortcut "Ctrl+P" for Print
- d. Using keyboard shortcut "Ctrl+F2" for Print Preview

42 · How To Highways User Guide


#### 2. Print

a. Using Print will bring up a Print dialog box where you can select which printer to print to



#### 3. Print Preview

a. Using Print Preview will bring up a window where you can view how the report will look on paper before sending it to the printer



b. The print icon in the toolbar found in the top left-hand corner can then be selected



Highways User Guide How To · 43

c. A print dialog box will pop up where you can select which printer to print to



44 · How To Highways User Guide

# Glossary of Terms

### **Access Point Density**

Access Point Density, or APD, is the measure of access points per mile (or access points per kilometer in metric).

In Multilane, the number of access points per mile is determined by dividing the total number of access points (i.e., driveways and unsignalized intersections) on the right side of the highway in the direction of travel by the length of the segment in miles (or kilometers in metric). An intersection or driveway should only be included in the count if it influences traffic flow. Access points that go unnoticed by drivers, or with little activity, should not be used to determine access-point density.

In TwoLane, access points are major driveways and side roads where significant traffic enters and/or leaves the two-lane highway within the analysis segment. Access points lower the free-flow speed for the segment. By lowering the free-flow speed, access points will also indirectly affect the average speed and the follower density.

The total number of access points on an analysis segment is the sum of the number of active major driveways and road or street approaches (on both sides of the highway) where traffic enters and/or leaves the two-lane highway within the segment. Residential driveways and other low-volume driveways and side roads (generally with ADT below 20 vehicles per day) should not be counted as access points. If the two-lane highway has a physical median barrier, or barrier striping, that prevents access to driveways on the opposite side of the barrier, then the access points on the opposite side of the median should not be included in the total for the segment.

Note that the methodology for estimating segment speeds does not provide for the computation of the effects of intersection delays *within* a two-lane highway analysis segment. Therefore, segments cannot include all-way stop, roundabout, or signal-controlled intersections between their endpoints. The segment must be split into smaller segments so that these intersections fall at the segments' start- or endpoints. Intersections at the beginning or end point of a segment do not count as access points.

# **Access-Point Density Adjustment**

The exhibit below presents the adjustment to FFS for various levels of access-point density. Studies indicate that for each access point per mile, the estimated FFS decreases by approximately 0.25 mi/h, regardless of the type of median.

Access-Point Density (access points/mi)	Reduction in FFS, $f_4$ (mi/h)
0	0.0
10	2.5
20	5.0
30	7.5
≥40	10.0

Note: Interpolation to the nearest 0.1 is recommended.

Access Point Density is measured in access points per mile (or access points per kilometer in metric), and the corresponding Access Point Density Adjustment is measured in miles per hour (or kilometers per hour in metric).

# **Add Segment**

Clicking on the button 'Add Segment' will add a row of inputs with the default Segment Type of 'Passing Constrained' along with the default values for the Passing Constrained segment type. The user can add an unlimited number of segments and can manually change the inputs to the desired values.

## Add Subsegment

Clicking on the button 'Add Subsegment' will add a row of inputs with the default Subsegment Type of 'Tangent' along with the default values for the Tangent subsegment type. The user can add an unlimited number of subsegments and can manually change the inputs to the desired values.

# **Agency**

This field is provided to document the agency or company associated with the analysis or project.

# **Analysis Year**

This field is provided to document the year for which the analysis is being performed. For example, a current or past operational year or a future design or planning year might be coded here.

## **Analyst**

This field is provided to document the name of the analyst.

## **Analyze Bicycle Results**

A checkbox is provided for the user to indicate whether or not to analyze bicycle results. Checking this box will enable inputs relevant to the bicycle LOS procedure and display bicycle results on the formatted and text reports. Likewise, leaving this box unchecked will disable inputs relevant to the bicycle LOS procedure and will remove the bicycle results from the formatted and text reports.

# **Back to Segment Editor**

A 'Back to Segment Editor' is provided when viewing subsegment details in the map-based segmentation window. Clicking this button will bring back the segment editor to edit details with the segments in the map-based segmentation window.

# **Base Free-Flow Speed**

The methodology covers multilane highway segments with a FFS in the range of 45 to 70 mi/h. There is not a great deal of information available to help establish a base value. In one sense, it is like the design speed—it represents the potential FFS based only on the highway's horizontal and vertical alignment, not including impacts of lane widths, lateral clearances, median type, and access points. The design speed may be used for BFFS if it is available.

Although speed limits are not always uniformly set, BFFS for multilane highways may be estimated, if necessary, as the posted or statutory speed limit plus 5 mi/h for speed limits 50 mi/h and higher and as the speed limit plus 7 mi/h for speed limits less than 50 mi/h.

For metric units, Base Free-Flow Speed is measured in kilometers per hour, with a range of 72.4 to 112.7 km/h.

# **Bicycle LOS**

Bicycle levels of service for multilane highway segments are based on a bicycle LOS score, which is in turn based on a traveler perception model. The bicycle LOS score is based, in order of importance, on give variables:

- Average effective width of the outside through lane,
- · Motorized vehicle volumes and speeds,
- · Heavy vehicle (truck) volumes, and
- Pavement condition.

The LOS ranges for bicycles on multilane highways are given in the following table:

LOS	Bicycle LOS Score	
Α	≤1.5	
В	>1.5-2.5	
C	>2.5-3.5	
D	>3.5-4.5	
E	>4.5-5.5	
F	>5.5	

The data required for evaluating bicycle LOS on a multilane highway and used in the development of the LOS model are as follows:

- Width of the outside through lane: 10 to 16 ft (or 3.0 to 4.9 m in metric),
- Shoulder width: 0 to 6 ft (or 0 to 1.8 m in metric),
- Motorized vehicle volumes: up to 36,000 annual daily traffic (AADT),
- Number of directional through lanes,
- Posted speed,
- Heavy vehicle percentage, and
- Pavement condition: 2 to 5 on the FHWA 5-point pavement rating scale.

# **Bicycle LOS Score**

LOS score is a numerical output from a traveler perception model that typically indicates the average rating that travelers would give a transportation facility or service under a given set of condition.

The bicycle LOS model for multilane highways uses a traveler perception index calibrated by using a linear regression model. The model fits independent variables associated with roadway characteristics to the results of a user survey that rates the comfort of various bicycle facilities. The resulting bicycle LOS index computes a numerical LOS score, generally ranging from 0.5 to 6.5, which is stratified to produce a LOS A to F result.

The bicycle LOS score can be calculated from the following equation:

 $BLOS = 0.507 \ln(v_{OL}) + 0.1999 S_t (1 + 10.38 HV)^2 + 7.066 (1/P)^2 - 0.005 (W_e)^2 + 0.760$ 

where

BLOS = bicycle level of service score;

 $v_{OL}$  = directional demand flow rate in the outside lane (veh/h);

 $S_t$  = effective speed factor;

HV = percentage of heavy vehicles (decimal); if V <200 veh/h, then HV should be limited to a maximum of 50%:</p>

P = FHWA's 5-point pavement surface condition rating; and

 $W_e$  = average effective width of the outside through lane (ft).

For metric units, the width listed in the calculations above are measured in meters. However, it is converted to feet for calculations and then converted to meters for end results.

## **Capacity Adjustment Factor**

The Capacity Adjustment Factor (CAF) is the factor used to allow the user to adjust the capacity for reduced-capacity situations or to match field measurements. The capacity in any cell of the time-space domain can be reduced to represent incident situations such as construction and maintenance activities, adverse weather, traffic accidents, and vehicle breakdowns. Similarly, capacity can be increased to match field measurements.

## **Central Angle**

Central Angle is a horizontal curve specific input. The central angle, along with the radius, of the curve will automatically adjust the segment length and control points accordingly.

# **Coded Type**

There are three coded types: Passing Constrained, Passing Zone, and Passing Lane.

In the analysis methodology, these segment types are defined as follows:

- Passing Constrained: Length of two-lane highway in which passing in the oncoming lane is either
  prohibited or effectively negligible due to lack of utilization of passing zone(s). The latter might be due to
  insufficient sight distance and indicates an area where passing should be formally prohibited.
- <u>Passing Zone</u>: Length of two-lane highway for which passing in the oncoming lane is permitted, and the length and location of such passing zone provides reasonable accommodation of passing maneuvers under certain traffic conditions.
- <u>Passing Lane</u>: This segment type consists of an added lane in the same direction as the analysis direction, with the intent to break up platoons that have formed upstream by allowing faster vehicles to pass slower vehicles.

#### **D**-factor

*D* is the proportion of traffic moving in the peak direction of travel on a given roadway during the peak hour. It is used, along with AADT (annual average daily traffic) and the *K*-factor (proportion of AADT occurring during the peak hour), in the following equation to determine the demand volume (*V*) or directional peak-hour volume (*DDHV*) in a planning and preliminary engineering analysis:

$$V = DDHV = AADT \times K \times D$$

While the consideration of directional distribution is not mandated in the analysis of multilane facilities, the distribution has a dramatic effect on both design and LOS.

#### **Date**

This field is provided to document the date when the analysis is performed.

# **Delete Segment**

After the user selects a segment to delete, clicking on the button 'Delete Segment' will delete the row of inputs corresponding to the selected segment. Multiple segments can be selected and deleted at the same time.

# **Delete Subsegment**

After the user selects a subsegment to delete, clicking on the button 'Delete Subsegment' will delete the row of inputs corresponding to the selected subsegment. Multiple subsegments can be selected and deleted at the same time.

#### **Demand**

The number of vehicles or other roadway users desiring to use a given system element during a specific analysis period, typically 1 h or 15 min.

Demand volume is the number of vehicles that arrive to use the facility. Under noncongested conditions, demand volume is equal to the observed volume.

### **Direction Description**

This field is provided to document the description of the direction being analyzed (e.g., EB, WB, NB, SB).

#### **Directional Demand**

The demand volume for the analysis direction (V<sub>d</sub>), in vehicles per hour, at the entrance of the segment being analyzed. This is then adjusted to account for the peak 15-min volume within the analysis hour.

#### Directional Flow Rate in the Outside Lane

The directional demand flow rate of motorized traffic in the outside lane is calculated on the basis of the hourly directional volume, the peak hour factor, and the number of directional lanes (two or more for passing lanes or multilane highways):

$$v_{OL} = \frac{V}{PHF \times N}$$

where

 $v_{OL}$  = directional demand flow rate in the outside lane (veh/h),

V = hourly directional volume (veh/h),

PHF = peak hour factor, and

N = number of directional lanes.

# **Driver Population**

Driver population describes the level of driver familiarity in the traffic stream and is used in adjustments for speed and capacity. The base traffic stream characteristics for basic freeway and multilane highway segments are representative of traffic streams composed primarily of commuters or drivers who are familiar with the facility.

The driver population adjustment factor  $f_p$  had previously been used in the HCM to reflect the effects of unfamiliar drivers in the traffic stream and was applied as an increase in demand volume. With the addition of a unified speed flow equation in Chapter 12 of the HCM and the ability to adjust both the base FFS and capacity in all freeway segment chapters (12-14) to account for incidents and weather events, the driver population factor is no longer used. Instead, FFS and capacity adjustment factors  $SAF_{pop}$  and  $CAF_{pop}$  are applied in combination with other applicable SAFs and CAFs.

Analyst judgment is still required when applying recommended adjustments. However, should there be expectations of significant presence of unfamiliar drivers, the values shown in the exhibit below can serve as a guide for the analysis.

Level of Driver Familiarity	CAFpop	SAFpop
All familiar drivers, regular commuters	1.000	1.000
Mostly familiar drivers	0.968	0.975
Balanced mix of familiar and unfamiliar drivers	0.939	0.950
Mostly unfamiliar drivers	0.898	0.913
All or overwhelmingly unfamiliar drivers	0.852	0.863

## **Effective Speed Factor**

The effect of motor vehicle speed on bicycle quality of service is primarily related to the differential between motor vehicle and bicycle travel speeds. For example, a typical cyclist may travel in the range of 15 mi/h. An increase in motor vehicle speeds from 20 to 25 mi/h is more readily perceived than a speed increase from 60 to 65 mi/h, since the speed differential increased by 100% in the first instance compared with only 11% in the latter.

The following equation shows the calculation of the effective speed factor that accounts for this diminishing effect.

$$S_t = 1.1199 \ln(S_p - 20) + 0.8103$$

where

 $S_t$  = effective speed factor, and

 $S_p$  = posted speed limit (mi/h).

For metric units, the posted speed limit is measured in kilometers per hour. However, this is converted to miles per hour for the calculation of the effective speed factor.

#### **Effective Width**

The effective width of the outside through lane depends on both the actual width of the outside through lane and the shoulder width, since cyclists will be able to travel in the shoulder where one is provided. Moreover, striped shoulders of 4 ft or greater provide more security to cyclists by giving cyclists a dedicated place to ride outside of the motorized vehicle travelway. Thus, an 11-ft lane and adjacent 5-ft paved shoulder results in a larger effective width for cyclists than a 16-ft lane with no adjacent shoulder.

Parking occasionally exists. On-highway parking reduces the effective width because parked vehicles take up shoulder space and bicyclists leave some shy distance between themselves and parked cars.

The following equations are used to calculate the effective width  $W_e$  on the basis of the paved shoulder width  $W_s$  and the hourly directional volume V:

If  $W_s$  is greater than or equal to 8 ft:

$$W_e = W_v + W_s - (\%OHP \times 10 \text{ ft})$$

If W<sub>s</sub> is greater than or equal to 4 ft and less than 8 ft:

$$W_e = W_v + W_s - 2 \times [\%OHP(2 \text{ ft} + W_s)]$$

If  $W_s$  is less than 4 ft:

$$W_e = W_v + [\%OHP(2 \text{ ft} + W_s)]$$

with, if V is greater than 160 veh/h:

$$W_v = W_{OL} + W_s$$

Otherwise,

$$W_{v} = (W_{OL} + W_{s}) \times (2 - 0.005V)$$

where

 $W_{v}$  = effective width as a function of traffic volume (ft),

 $W_{OL}$  = outside lane width (ft),

 $W_s$  = paved shoulder width (ft),

V = hourly directional volume per lane (veh/h),

 $W_{\rm e}$  = average effective width of the outside through lane (ft), and

%OHP = percentage of segment with occupied on-highway parking (decimal).

For metric units, Effective Width is measured in meters. All widths listed in the calculations above are measured in meters. However, they are converted to feet for calculations and then converted to meters for end results.

# **Free Flow Speed**

- The average speed of vehicles on a given segment, measured under low-volume conditions, when drivers
  are free to drive at their desired speed and are not constrained by the presence of other vehicles or
  downstream traffic devices.
- 2. The theoretical speed when both density and flow rate are zero.

The free-flow speed (FFS) can be determined either through direct field measurement (preferred) or by estimation.

For multilane highway segments, the adjusted free-flow speed is determined by subtracting each speed adjustment from the base free-flow speed according to HCM Equation 12-3 for Multilane Highway Segments, which can be found below.

```
FFS = BFFS – f_{LW} – f_{TLC} – f_M – f_A where

FFS = free-flow speed of the multilane highway segment (mi/h);

BFFS = base FFS for the multilane highway segment (mi/h);

f_{LW} = adjustment for lane width (mi/h);

f_{TLC} = adjustment for total lateral clearance (mi/h);

f_M = adjustment for median type (mi/h); and

f_A = adjustment for access-point density (mi/h).
```

If a field measured free-flow speed is entered, no subsequent adjustments are made, and the adjusted free-flow speed will simply be the field-measured free-flow speed.

For metric units, free-flow speed, along with all the corresponding adjustments, are measured in kilometers per hour.

For two-lane highways, the operating conditions of the facility in terms of a base free-flow speed (BFFS) that reflects the facility's geometric characteristics must be characterized to estimate the FFS. As part of this estimation process, it is recognized that the posted speed limit is intended to inform motorist of appropriate operating speed for the given geometric conditions. The FFS is calculated with HCM Equations 15-3 through 15-6, which can be found below:

```
FFS = BFFS - a(HV\%) - f_{LS} - f_A
with
a = \max[0.0333, a_0 + a_1 \times BFFS + a_2 \times L + \max(0, a_3 + a_4 \times BFFS + a_5 \times L) \times v_0/1000]
where
   FFS = free-flow speed in the analysis direction (mi/h);
  BFFS = base free-flow speed (mi/h);
  HV%
         = percentage of heavy vehicles in the analysis direction (%) (e.g., 5% is expressed as 5);
          = adjustment for lane and shoulder width (mi/h), from Equation 15-5;
     fis
      f_A
         = adjustment for access-point density (mi/h), from Equation 15-6;
   a_0-a_5 = coefficient values from Exhibit 15-12
      L = segment length (mi), subject to minima and maxima given in Step 1; and
         = demand flow rate in opposing direction (veh/h); v_0 = 1,500 in Passing Constrained segments
      Vο
              and v_o = 0 in Passing Lane segments.
```

For metric units, free-flow speed, along with all the corresponding adjustments, are measured in kilometers per hour. Segment length is measured in kilometers.

### **Grade Length**

The length of the segment, in miles (or kilometers in metric), representing the percent grade

## **Heavy Vehicles**

The percentage of heavy vehicles in the traffic stream. Heavy vehicles are engaged primarily in the transportation of goods and materials or in the delivery of services other than public transportation. Heavy vehicles generally consist of large trucks, buses, and recreational vehicles (RVs).

#### **Horizontal Curve**

This is a geometric design that provides a transition between two tangent sections of roadway, allowing a vehicle to complete a turn at a gradual rate than a sharp cut.

## **Insert Segment**

Clicking on the button 'Insert Segment' will add a row of inputs with the default Segment Type 'Passing Constrained' along with the default values for the Passing Constrained segment type above the selected segment. The user can insert an unlimited number of segments and can manually change the inputs to the desired values.

### **Insert Subsegment**

Clicking on the button 'Insert Subsegment' will add a row of inputs with the default Subsegment Type 'Tangent' along with the default values for the Tangent subsegment type above the selected subsegment. The user can insert an unlimited number of subsegments and can manually change the inputs to the desired values.

#### **Jurisdiction**

This field is provided to document any jurisdiction convention or project related information.

#### K-factor

K is the proportion of AADT (annual average daily traffic) that occurs during the peak hour. It is used, along with AADT and the D-factor (the proportion of peak-hour volume traveling in the peak direction), in the following equation to determine the demand volume (V) or directional peak-hour demand volume (DDHV) in a planning and preliminary engineering analysis:

 $V = DDHV = AADT \times K \times D$ 

For many rural and urban highways, this factor falls between 0.09 and 0.10. For highway sections with high peak periods and relatively low off-peak flows, the *K*-factor may exceed 0.10. Conversely, for highways that demonstrate consistent and heavy flows for many hours of the day, the *K*-factor is likely to be lower than 0.09. In general,

- The K-factor decreases as the AADT on a highway increases;
- The K-factor decreases as development density increases; and
- The highest *K*-factors occur on recreational facilities, followed by rural, suburban, and urban facilities, in descending order.

The K-factor should be determined, if possible, from local data for similar facilities with similar demand characteristics.

#### **Lane Width**

The lateral distance between stripes for a given lane; measured in feet (or meters in metric)

For the two-lane highways bicycle methodology, the lane width input also specifies the outside lane width, or Wol.

## **Lane Width Adjustment**

This is an adjustment to Base Free-Flow Speed based on the average lane width. The base condition for lane width is 12 ft or greater. When the average lane width across all lanes is less than 12 ft, the FFS is negatively affected. Adjustments to reflect the effect of narrower average lane width are shown below:

Reduction in FFS, $f_{LW}$ (mi/h)	
0.0	
1.9	
6.6	

For metric units, Average Lane Width is measured in meters, and the corresponding Lane Width Adjustment is measured in kilometers per hour.

#### Level of Service

Level of Service (LOS) is a quantitative stratification of a performance measure or measures that represent quality of service, measured on an A-F scale, with LOS A representing the best operating conditions from the traveler's perspective and LOS F the worst.

LOS on multilane highway segments is defined by density, which is measured in passenger cars per mile per lane. Although speed is a major concern of drivers related to service quality, it would be difficult to describe LOS by using speed, as it remains constant up to high flow rates (i.e., 1,400 pc/h/ln for multilane highway segments). Density describes a motorist's proximity to other vehicles and is related to a motorist's freedom to maneuver within the traffic stream. Unlike speed, however, density is sensitive to flow rates throughout the range of flows.

The criteria for LOS is shown in the exhibit below:

	LOS	Density (pc/mi/ln)
	Α	≤11
	В	>11-18
	C	>18-26
	D	>26-35
	E	>35-45
	É	Demand exceeds capacity OR density >45

For metric, density is measured in passenger cars per kilometer per lane. The criteria for LOS is shown in metric below:

LOS	Density (pc/km/ln)
Α	≤7
В	>7–11
С	>11–16
D	>16–22
E	>22–28
F	Demand exceeds capacity OR density >28

If the demand-to-capacity ratio is less than or equal to 1.0, follower density is used as the service measure for all two-lane highways. However, two sets of LOS thresholds are used to account for differences in driver perception between driving on higher-speed versus lower-speed highways.

The criteria for LOS is shown in the exhibit below:

	Follower Density (followers/mi/ln)		
LOS	Higher-Speed Highways Posted Speed Limit ≥ 50 mi/h	Lower-Speed Highways Posted Speed Limit < 50 mi/h	
Α	≤ 2.0	≤ 2.5	
В	> 2.0 - 4.0	> 2.5 - 5.0	
C	> 4.0 - 8.0	> 5.0 - 10.0	
D	> 8.0 - 12.0	> 10.0 - 15.0	
E	> 12.0	> 15.0	
F	Demand exceeds capacity		

In the case of facilities with mixed speed limits (e.g., some above 50 mi/h and others below 50 mi/h), an average speed limit is computed for the facility, and that is used to determine the facility LOS.

For metric, follower density is measured in followers per kilometer per lane. The criteria for LOS is shown in metric below:

#### Follower Density (followers/km/ln)

LOS	Higher-Speed Highways Posted Speed Limit ≥ 80 km/h	Lower-Speed Highways Posted Speed Limit < 80 km/h
Α	≤ 1.2	≤ 1.6
В	> 1.2 – 2.5	> 1.6 – 3.1
С	> 2.5 – 5.0	> 3.1 – 6.2
D	> 5.0 – 7.5	> 6.2 – 9.3
E	> 7.5	> 9.3
F	Demand ex	ceeds capacity

Please note that when converting between units (USC to Metric, or Metric to USC), the follower density table speed limits are not exact. When converting from USC to Metric, the speed limit of 50 mi/h converts to 80.5 km/h. When converting from Metric to USC, the speed limit of 80 km/h converts to 49.7 mi/h.

#### **Level Terrain**

Any combination of grades and horizontal or vertical alignment that permits heavy vehicles to maintain the same speed as passenger cars. This type of terrain typically contains short grades of no more than 2%.

# **Map-Based Segmentation**

Clicking on the 'Map-Based Segmentation' button will bring up the Segmentation window, where the user can create sections through a map. Clicking 'OK' after finalizing sections will bring the user back to the Segments page in Highways and will automatically generate the appropriate segments and subsegments for the facility. Clicking 'Cancel' will close the Segmentation window without applying any of the changes made.

Specific locations can be searched using the 'City / Zip Code' textbox. When a city or zip code is entered, the map will adjust to find that location. The user may also zoom in/out or drag the map to find a location. At the top right corner of the map, there are '+' and '-' buttons that allow zooming in and out, respectively. Above that is a drop-down menu that allows changing of the map view. Options include the following: Road and Aerial With Labels.

#### Segment Editor:

When ready to add a node, the user can right-click on the map which will bring up a menu with the following: Add Passing Constrained Node, Add Passing Zone Node, and Add Passing Lanes Node. Adding a node will place a pin on the map with a number. As more nodes are added, the pins will be connected by lines representing segments of the roadway. Nodes can be dragged on the map to change their location and the length of the segments. If there is already a node on the map, the user can right-click that node which will bring up a menu with the following: Delete Current Node, Insert Passing Constrained Node After Current Node, Insert Passing Zone Node After Current Node, and Insert Passing Lanes Node After Current Node.

At the bottom of the map, there are also buttons provided to make editing the facility easier. They include the following: Zoom to Selection, Zoom to Facility, Remove Last Node, and Clear Map Content. For 'Zoom to Selection', the user can highlight rows within the data grid or select nodes/segments on the map. Once selected, clicking on 'Zoom to Selection' will zoom in to the selected nodes/segments on the map. Clicking on 'Zoom to Facility' will zoom in/out to show the entire facility on the map. Clicking on 'Undo Last Node' will remove the last node added to the map. Clicking on 'Clear Map Content' will remove everything that was added to the map.

#### Subsegment Editor:

To access the subsegment editor, the 'Details' link of the desired segment must be clicked. This will cause the map to show just the segment selected, along with its boundary nodes. The data grid will also only show the nodes/sections pertaining to this selected segment. The segment and its boundary nodes cannot be adjusted while in the subsegment editor. Only subnodes/subsegments can be edited in the subsegment editor.

When ready to add a subnode, the user can right-click the beginning segment boundary node on the map. This will bring up a menu with the following: Insert Tangent Subnode After Current Node and Insert Horizontal Curve Subnode After Current Node. Inserting a subnode will place a pin on the map with a number. Numbering is based on the beginning boundary node. For example, if the beginning boundary node is 3, the first subnode inserted will be 3.1. As more subnodes are added, the pins will be connected by lines representing subsegments of the segment. If there is already a subnode on the map, the user can right-click that subnode which will bring up a menu with the following: Insert Tangent Subnode After Current Node, Insert Horizontal Curve Subnode After Current Node, and Delete Current Node.

At the bottom of the map, there are also buttons provided to make editing the facility easier. They include the following: Zoom to Selection, Zoom to Segment, Remove Last Subnode, and Clear Map Content. For 'Zoom to Selection', the user can highlight rows within the data grid or select subnodes/subsegments on the map. Once selected, clicking on 'Zoom to Selection' will zoom in to the selected subnodes/subsegments on the map. Clicking on 'Zoom to Segment' will zoom in/out to show the entire segment on the map. Clicking on 'Undo Last Subnode' will remove the last subnode added to the map. Clicking on 'Clear Map Content' will remove all subnodes/subsegments that were added to the map.

Clicking on the 'Back to Segment Editor' button will bring back the segment editor and change the map back to view the entire facility with just the nodes and segments.

# **Measured Free-Flow Speed**

The measured free-flow speed is the FFS measured in the field and provided by the user. If the FFS is measured directly, no adjustments are applied to the measured value.

# Median (Left) Side Clearance

Left-side lateral clearance is measured from the edge of the travel lanes to the nearest periodic or continuous obstruction in the median. If such obstructions are farther than 6 ft (or 1.8 m in metric) from the edge of the pavement, a value of 6 ft (or 1.8 m in metric) is used.

Left-side lateral clearances are subject to some judgement. Many types of common median barriers do not affect driver behavior if they are no closer than 2 ft (or 0.6 m in metric) from the edge of the travel lane, including concrete and W-beam barriers. A value of 6 ft (or 1.8 m in metric) would be used in such cases. Also, when the multilane highway segment is undivided or has a TWLTL, no left-side lateral clearance restriction is assumed, and a value of 6 ft (or 1.8 m in metric) is applied.

# **Median Type**

Multilane highways have three median types:

- Undivided (with only a centerline separating the directions of flow)
- Divided (with a physical median separating the directions of flow)
- TWLTL (two-way left-turn lane)

Median type is used in determining the adjustment for median type  $f_M$ , which is used in the calculation of free-flow speed.

## Median Type Adjustment

The adjustment for type of median is given in the following exhibit:

Median Type	Reduction in FFS, f <sub>M</sub> (mi/h)
Undivided	1.6
TWLTL	0.0
Divided	0.0

For metric units, Median Type Adjustment is measured in kilometers per hour.

#### **Mixed-Flow Model**

The mixed-flow model is one of two distinct methodologies offered to assess the effect of heavy vehicles on capacity and LOS. The model directly assesses the capacity, speed, and density of traffic streams that include a significant percentage of heavy vehicles operating on a single or composite grade. When using the mixed-flow models, no PCEs are needed, as the passenger car, SUT, and TT volumes are used directly in the estimation of mixed-flow speed and density.

#### **Number of Lanes**

This specifies the number of lanes on the roadway in the specified direction.

# **Opposing Demand**

The demand volume for the opposing direction (V<sub>o</sub>), in vehicles per hour, at the entrance of the segment being analyzed. This is then adjusted to account for the peak 15-min volume within the analysis hour.

#### Outside Lane Width

The width of the outside through lane is measured in feet. This is denoted as  $W_{OL}$  and is used in the calculation of effective width.

If *V* is greater than 160 veh/h:

$$W_v = W_{Ol} + W_s$$

Otherwise,

$$W_{\rm V} = (W_{\rm OL} + W_{\rm S}) \times (2 - 0.005 V)$$

where

 $W_{\nu}$  = effective width as a function of traffic volume (ft);

 $W_{OL}$  = outside lane width (ft);

 $W_s$  = paved shoulder width; and

V = hourly directional volume per lane (veh/h).

For metric units, the width of the outside through lane is measured in meters. All widths listed in the calculations above are measured in meters. However, they are converted to feet for calculations and then converted to meters for end results.

# **Pavement Condition Rating**

A description of the road surface in terms of ride quality and surface defects. The pavement condition is rated from 2 to 5 based on the Federal Highway Administration (FHWA) 5-point rating scale.

#### **Peak Hour Factor**

Peak Hour Factor (PHF) is the hourly volume during the analysis hour divided by the peak 15-min flow rate within the analysis hour. It is a measure of traffic demand fluctuation within the analysis hour.

#### **Percent Grade**

The longitudinal slope of a roadway; provided by the user as a percentage.

## **Percent Occupied Parking**

This refers to the percent of the segment with occupied on-highway parking. On-highway parking reduces effective width because parked vehicles take up shoulder space and bicycles leave some shy distance between themselves and the parked cars.

### **Project Description**

This field is provided for the user to document the analysis with any information for identification purposes.

#### **Radius**

Curve radius is a horizontal curve specific input. The curve radius, along with the central angle, of the curve will automatically adjust the segment length and control points accordingly.

# **Right Side Clearance**

Right-side lateral clearance is measured from the right edge of the travel lanes to the nearest periodic or continuous roadside obstruction. If such obstructions are farther than 6 ft (or 1.8 m in metric) from the edge of the pavement, a value of 6 ft (or 1.8 m in metric) is used.

Fixed obstructions with lateral clearance effects include light standards, signs, trees, abutments, bridge rails, traffic barriers, and retaining walls. Standard raised curbs are not considered to be obstructions.

# **Rolling Terrain**

Any combination of grades and horizontal or vertical alignment that causes heavy vehicles to reduce their speed below those of passenger cars, but that does not cause heavy vehicles to operate at crawl speeds for any significant length of time or at frequent intervals.

# Segment Length

This field is provided to document the length of the segment being analyzed; measured in feet (or meters in metric)

# **Segment Name**

This field is provided for each segment to identify the segment or specify the start point and end point of the segment under analysis.

#### Select All

A 'Select All' checkbox is provided under the 'Segments Global Inputs' section of a Two-Lane Facility analysis to easily select and apply all inputs provided under that section to the entire facility.

#### **Shoulder Width**

This is the width of the shoulder, measured in feet (or meters in metric)

### Single-Unit Trucks (SUT)

Single-Unit Trucks (SUT) are defined as one of two categories of heavy vehicles. Buses and RVs are treated as SUTs in the HCM. SUTs include the following:

- Other Two-Axle, Four-Tire Single-Unit Vehicles: Two-axle, four-tire vehicles, other than passenger cars. Generally pickup trucks, sports utility vehicles, and vans.
- Buses: All vehicles manufactured as traditional passenger-carrying buses with two axles and six tires or three or more axles. Excludes modified buses no longer capable of mass passenger transport.
- Two-Axle, Six-Tire, Single-Unit Trucks: All vehicles on a single frame with two axles and dual rear wheels. Includes some trucks, camping and recreational vehicles, and motor homes.
- Three-Axle Single-Unit Trucks: All vehicles on a single frame with three axles. Includes some trucks, camping and recreational vehicles, and motor homes.
- Four or More Axle Single-Unit Trucks. All trucks on a single frame with four or more axles.

## **Specific Grade**

A single grade of roadway segment or extended roadway segment expressed as a percentage.

# **Speed Adjustment Factor**

The Speed Adjustment Factor (SAF) is the factor used to allow the user to adjust speed based on a combination of different sources, including weather and work zone effect. The SAF may also be used to calibrate the estimated FFS for local conditions or other effects that contribute to a reduction in FFS. For example, poor pavement conditions or sun glare may result in drivers reducing their speed even under low-volume conditions.

# **Speed Limit**

The speed limit, in miles per hour (or kilometers per hour in metric), posted on the highway segment in the analysis direction.

In Two-Lane Highways, the posted speed limit is also used to determine the LOS criteria applicable to the analysis—Higher Speed Highways (posted speed  $\geq 50$  mi/h) or Lower Speed Highways (posted speed < 50 mi/h). Please note that when converting between units (USC to Metric, or Metric to USC), the follower density table speed limits are not exact. When converting from USC to Metric, the speed limit of 50 mi/h converts to 80.5 km/h. When converting from Metric to USC, the speed limit of 80 km/h converts to 49.7 mi/h. For the cases when the user enters a posted speed limit of 80 km/h, the Higher Speed criteria (posted speed  $\geq 50$  mi/h) will be internally used in HCS.

For both Two-Lane Highways and Multilane Highways, the posted speed limit is used to calculate the effective speed factor.

### **Subsegment Length**

This field is provided to document the length of the subsegment being analyzed. For tangent subsegments, the link length is entered. For curves, the link length will be based on the curve radius and central angle.

### **Subsegment Type**

There are two subsegment types: Tangent and Horizontal Curve. Tangent sections are either straight or have horizontal curves with radii greater than 2,550 ft (or 777.24 m in metric).

### Super 2

The 2+1, sometimes referred to as "Super 2", design typically extends for many miles, with several changes of direction for the passing lane provided within this distance.

### **Superelevation**

Superelevation is a horizontal curve specific input. It is the banking of a roadway in a curve to counteract lateral acceleration.

### **Target LOS**

Target LOS is used in a planning and preliminary engineering analysis. This is the Level of Service (LOS) the analyst wishes to achieve based on other parameters, such as Number of Lanes and FFS.

See also Level of Service.

## **Terrain Type**

An extended length of highway containing a number of upgrades and downgrades where no single grade is long enough or steep enough to have a significant impact on the operation of the overall segment. There are three types of terrain: Level, Rolling, and Specific Grade.

See also Level Terrain, Rolling Terrain, and Specific Grade.

# Time Analyzed

This field is provided to document the time frame of the analysis as morning peak, afternoon peak, existing conditions, future projections, etc.

# **Total Lateral Clearance Adjustment**

The adjustment for total lateral clearance (TLC) on multilane highway segments is based on TLC at the roadside (right side) and at the median (left side). Fixed obstructions with lateral clearance effects include light standards, signs, trees, abutments, bridge rails, traffic barriers, and retaining walls. Standard raised curbs are not considered to be obstructions.

The following equation is used to determine TLC:

 $TLC = LC_R + LC_L$ 

where

TLC = total lateral clearance (ft) (maximum value 12 ft);

 $LC_R$  = right-side lateral clearance (ft) (maximum value 6 ft); and

 $LC_L$  = left-side lateral clearance (ft) (maximum value 6 ft).

The following exhibit shows the reduction of FFS due to lateral obstructions on the multilane highway:

Four-Lane Highways		Six-Lane Highways	
TLC (ft)	Reduction in FFS (mi/h)	TLC (ft)	Reduction in FFS (mi/h)
12	0.0	12	0.0
10	0.4	10	0.4
8	0.9	8	0.9
6	1.3	6	1.3
4	1.8	4	1.7
2	3.6	2	2.8
0	5.4	.0	3.9

Note: Interpolation to the nearest 0.1 is recommended.

For metric units, Total Lateral Clearance, along with Right-Side Lateral Clearance and Left-Side Lateral Clearance, are measured in meters. The corresponding Total Lateral Clearance Adjustment is measured in kilometers per hour.

#### **Total Trucks**

The percentage of trucks in the traffic stream. Trucks are heavy vehicles engaged primarily in the transport of goods and materials or in the delivery of services other than public transportation. All heavy vehicles are classified as single-unit trucks (SUTs) or tractor-trailers (TTs).

## **Tractor-Trailers (TT)**

Tractor-Trailers (TT) are defined as one of two categories of heavy vehicles. TTs include the following:

- Four or Fewer Axle Single-Trailer Trucks: All vehicles with four or fewer axles consisting of two units, one of which is a tractor or straight truck power unit.
- Five-Axle Single-Trailer Trucks: All five-axle vehicles consisting of two units, one of which is a tractor or straight truck power unit.
- Six or More Axle Single-Trailer Trucks: All vehicles with six or more axles consisting of two units, one of which is a tractor or straight truck power unit.
- Five or Fewer Axle Multi-Trailer Trucks: All vehicles with five or fewer axles consisting of three or more units, one of which is a tractor or straight truck power unit.
- Six-Axle Multi-Trailer Trucks: All six-axle vehicles consisting of three or more units, one of which is a tractor or straight truck power unit.
- Seven or More Axle Multi-Trailer Trucks: All vehicles with seven or more axles consisting of three or more units, one of which is a tractor or straight truck power unit. Includes triple-trailer combinations.

#### **Units**

This specifies the units of the analysis file (i.e., U.S. Customary or Metric).

## **Vehicle Hours of Delay (VHD)**

VHD is the vehicle hours of delay during time period t. In TwoLane, the facility VHD is the sum of each segment VHD, which is calculated using the equation below:

$$VHD = \sum_{t} \left[ \left( \left( V_{i} \times \frac{L_{i}}{S_{i}} \right) - \left( V_{i} \times \frac{L_{i}}{S_{i}} \right) \right) \times T \right]$$

where

VHD = Vehicle Hours of Delay (hours/time period)

 $V_i$  = Segment Volume (veh/h)

 $L_i$  = Segment Length (mi)

 $S_i$  = Segment Average Speed (mi/h)

FFS = Free-Flow Speed (mi/h)

T = Length of time period (h)

For metric units, Segment Length is measured in km, while Segment Average Speed and Free-Flow Speed are measured in km/h.

### **Vehicle Miles Traveled (VMT)**

VMT is the vehicle miles traveled during time period *t*. In TwoLane, the facility VMT is the sum of each segment VMT, which is calculated using the equation below:

$$VMT = \sum_{t} [V_i \times L_i \times T]$$

where

*VMT* = Vehicle Miles Traveled (veh-miles/time period)

 $V_i$  = Segment Volume (veh/h)

 $L_i$  = Segment Length (mi)

T = Length of time period (h)

For metric units, Vehicle Miles Traveled (VMT) is converted to vehicle-kilometers per time period and is then denoted as VkmT, which stands for Vehicle Kilometers Traveled.

# Index

#### Α

Access Point Density 45
Access-Point Density Adjustment 45
Acknowledgements 6
Add Segment 46
Add Subsegment 46
Agency 46
Analysis Year 46
Analyst 46
Analyze Bicycle Results 46

#### В

Back to Segment Editor 46 Base Free-Flow Speed 46 Bicycle LOS 46 Bicycle LOS Score 47

#### C

Capacity Adjustment Factor 48
Central Angle 48
Change the View 30
Close a File 25
Coded Type 48
CORSIM 9
Create a Horizontal Curve 33
Create a New File 17

#### D

D-factor 48
Date 48
Default Settings 9
Delete Segment 48
Delete Subsegment 48
Demand 49
Direction Description 49
Directional Demand 49

#### Ε

Edit the Default Settings 28 Effective Speed Factor 50 Effective Width 50 Exit 9 Exit the Program 26 Export 9

#### F

Free-Flow Speed 51

#### G

General Controls 8 Getting Started 7 Glossary of Terms 45 Grade Length 52

#### Н

HCM Chapter 12 10 HCM Chapter 15 13 Heavy Vehicles 52 Help 9 Horizontal Curve 52 How To 17

#### I

Import 9 Insert Segment 52 Insert Subsegment 52 Introduction 1

#### J

Jurisdiction 52

#### Κ

K-factor 52

62 · Index Highways User Guide

#### L

Lane Width 52 Lane Width Adjustment 53 Level of Service (LOS) 53 Level Terrain 54 License Agreement 1

#### M

Map-Based Segmentation 54
Measured Free-Flow Speed 55
Median (Left) Side Clearance 55
Median Type 55
Median Type Adjustment 56
Menu Items 8
Mixed-Flow Model 56
Multilane Highway Report 12
Multilane Highway Segments 10

#### Ν

New 8 Number of Lanes 56

#### 0

Open 8
Open an Existing File 20
Operational Data 10,13
Opposing Demand 56
Outside Lane Width 56

#### Ρ

Pavement Condition Rating 57
Peak Hour Factor (PHF) 57
Percent Grade 57
Percent Occupied Parking 57
Project Description 57
Print 8
Print a Report 42
Print Preview 8

#### R

Radius 57 Report 8 Right Side Clearance 57 Rolling Terrain 57

#### S

Safety Results 11,15 Save 8 Save a File 24 Save As... 8 Segment Length 57 Segment Name 57 Select All 58 Shoulder Width 58 Single-Unit Trucks (SUT) 58 Specific Grade 58 Speed Adjustment Factor (SAF) 58 Speed Limit 58 Subsegment Length 59 Subsegment Type 59 Super 259 Superelevation 59 System Requirements 7

#### Т

Target LOS 59
Terrain Type 59
Time Analyzed 59
Total Lateral Clearance Adjustment 59
Total Trucks 60
Tractor-Trailers (TT) 60
Trademarks and Copyrights 6
Two-Lane Highway Report 16
Two-Lane Highways 13

#### U

Units 60

#### V

Vehicle Hours of Delay (VHD) 61 Vehicle Miles Traveled (VMT) 61 View 8 View Results of the Analysis 35

Highways User Guide Index · 63