



Contents

Introduction	1
License Agreement	1
Acknowledgements	
Trademarks and Copyrights	
Getting Started	7
Getting Started	7
General Controls	8
Menu Items	8
Highway Safety	10
Highway Safety ManualInitial Steps	
Segment Analysis	
Intersection Analysis	
Roundabout Analysis	
Method Type	
Rural Facility Analysis	
Urban Facility Analysis	
Freeway and Ramp Facility Analysis	
Report	23
How To	24
Create a New File	24
Open an Existing File	26
Save a File	30
Close a File	
Exit the Program	
Edit the Default Settings	
Change Parameters	
Export to CSV	
Run an Empirical Bayes Analysis	
Run an Economic Analysis Apply User-Defined CMFs	
View Results of the Analysis	
Print a Report	
Glossary of Terms	61
Index	118

Introduction

License Agreement

HIGHWAY SAFETY SOFTWARE™ (HSS™) END-USER LICENSE AGREEMENT (EULA)

Effective Date: 10/15/2024

Copyright © 2024 University of Florida. All rights reserved.

This End User License Agreement ("Agreement") is a legal agreement between you ("End User", "you") and the University of Florida Board of Trustees for the benefit of the McTrans Center ("McTrans", "we") regarding the use of the Highway Safety Software ("Software"). By accessing or using the Software programs within the electronically transmitted package or direct download, you agree to be bound by the terms and conditions of this Agreement.

1. INTEGRATION:

This License Agreement is the complete and exclusive statement of the agreement between End User and McTrans and supersedes any previous End User License Agreements distributed by older versions of the software proposal or prior agreement, oral or written, and any other communications between End User and McTrans relating to the subject matter of this License Agreement. This License Agreement may only be modified by a written agreement made subsequent to the date hereof and signed by both parties.

2. LICENSE GRANT:

2.1 Subscription-Based License:

McTrans grants you a non-exclusive, non-transferable license to access and use the Software, subject to the terms of your active subscription. The license is valid only for the duration of your subscription and is contingent upon full payment of all applicable fees.

2.2 Access to Software Versions:

Your subscription grants access to versions 8 series and beyond (2022 onward) of the Software. When a new version of the Software is released, the End User with an active subscription can download and access the latest version at no additional cost for the remainder of their subscription term.

3. TYPES OF SUBSCRIPTIONS:

The type of subscription determines the permitted use of the Software. Once a subscription type is selected, it cannot be changed or exchanged for a different type.

3.1 Office-Based Subscription:

This subscription grants access to the Software for a predetermined number of computers within a physical office. An "office" refers exclusively to a fixed geographical location, typically a single physical address, where an organization conducts its business or operational activities. This location must consist of one or more contiguous

rooms or spaces within a single building. Virtual offices or any non-physical locations are excluded from this definition.

The Software may be installed on multiple devices within the office, and access is restricted to end users officially assigned to that licensed office. End Users may also use the Software on portable computers, such as laptops, while on official travel, provided that all (100%) such use is exclusively on behalf of the office for which this Software license was purchased. Additional offices must obtain proper licensing prior to accessing the Software. The Software may only be installed on devices owned or controlled by the licensed office.

This subscription is intended exclusively for commercial use.

Virtualization Restriction:

The Software under an office-based subscription is prohibited from being used in a virtualized environment. All installations of the Software must be conducted on a physical computer, such as a desktop or laptop. Remote access technologies, such as remote desktop, are strictly prohibited under this subscription type.

3.2 Computer-Based Subscription:

This subscription permits the installation and use of the Software on a specified number of individual devices. An "individual device" refers to a single, standalone computing unit, such as a desktop or laptop, intended for use by a single user at a time. It is not shared concurrently with other users and is intended for use by a single user only The Software may only be accessed directly from the device(s) on which it is installed, regardless of whether the device is located in a physical office or used in a virtual office. End users working remotely or in virtual offices must ensure that the device remains dedicated to their use and fully complies with the terms of this subscription.

Virtualization Restriction:

The Software under a computer-based subscription is prohibited from being used in a virtualized environment. All installations must be conducted on a physical computer, such as a desktop, PC, or laptop. Remote access to the Software via any technology, including but not limited to remote desktop, is strictly prohibited under this subscription type.

3.3 Academic Subscription:

The academic subscription is available exclusively to academic institutions and grants access to a specified number of seats (copies) across the entire academic institution. This subscription is intended solely for use in a classroom setting for teaching or a lab for research purposes under the direct supervision of faculty or other authorized personnel. The Software may only be installed on devices owned or controlled by the academic institution.

The End User is required to implement appropriate protection measures to prevent students or any other individuals from copying the Software and removing it from the lab or classroom environment. The responsibility for safeguarding the Software and preventing unauthorized copying or distribution rests entirely with the End User.

Virtualization for Virtual Classrooms:

Under the academic license, the End User may request permission to utilize a virtual environment for the installation and use of the Software. Such virtualization is only permitted with prior written consent from McTrans. If such permission is granted, the virtual environment must adhere to all protections and restrictions outlined in this Agreement, ensuring that the Software is used exclusively for its intended educational purposes and its access is limited to the institution's faculty and actively enrolled students only. Additionally, the number of seats purchased must be sufficient to cover the number of students and faculty accessing the virtual classroom.

4. SUBSCRIPTION TERM:

4.1 Duration:

The subscription term begins on the date of purchase and continues for the period specified at the time of purchase ("Subscription Term"). The license granted under this Agreement is valid only for the duration of the Subscription Term.

4.2 Renewal:

Subscriptions may be renewed upon payment of applicable fees before the end of the Subscription Term. If the subscription is not renewed, access to the Software and all related services, including technical support, will be terminated.

5. TECHNICAL SUPPORT:

5.1 Support Services:

During the active Subscription Term, the End User is entitled to reasonable telephone or email support provided during the normal business hours of McTrans. McTrans reserves the right to determine the extent of the support provided.

5.2 Revisions and Enhancements:

McTrans reserves the right to make substantial revisions and enhancements to the Software and to market such substantially revised versions as separate products. The End User shall not be entitled to receive such separate products without additional charge. Upon the release of any such revised version of the Software, the obligation to provide the above-described technical support services to the End User shall cease unless the End User chooses to pay to license the enhanced version of the Software, regardless of whether the End User has previously requested or received support on the prior version.

6. NETWORK USE:

The End User is strictly prohibited from using the Software on any network. This prohibition includes but is not limited to the use of the Software either directly or indirectly through commands, data, or instructions transmitted to or from a computer that is not licensed or is not part of the licensed internal network. This also includes any use for Internet or web hosting services or by any user who does not hold a valid license for the Software from McTrans.

The Software is not designed for network use, and such use is unsupported. McTrans will not provide technical support for any issues resulting from network incompatibilities or unauthorized network use.

7. RESTRICTIONS ON USE:

The End User agrees that they shall not, nor shall they permit any third party to:

- Software Modification: Modify, adapt, translate, or create derivative works based on the Software, in whole or in part, without the express prior written consent of McTrans.
- Reverse Engineering: Reverse engineer, decompile, disassemble, or otherwise attempt to derive the source code of the Software, except to the extent expressly permitted by applicable law.
- Unauthorized Use: Use the Software for any purpose other than as expressly permitted under this Agreement, including unauthorized copying, distribution, or dissemination of the Software.
- Intellectual Property Infringement: Engage in any activity that infringes on the intellectual property rights of McTrans, including any unauthorized copying or distribution of the Software or associated documentation.
- Copying and Distribution: Copy, reproduce, or distribute the Software or associated printed documentation
 for sale, distribution, or dissemination, except as expressly provided under the terms of this Agreement or
 with the express prior written consent of McTrans.
- Documentation Use: Reproduce the associated documentation only as necessary for use within the permitted scope of the subscription type as outlined in this Agreement.

Ownership of Software Modifications:

Any modifications, adaptations, translations, derivative works, or any other products or materials resulting from any prohibited actions shall become the exclusive property of McTrans, regardless of whether such actions were performed with or without McTrans' consent.

8. INTELLECTUAL PROPERTY RIGHTS:

The Software and all associated intellectual property rights are owned by McTrans. No rights are granted to the End User other than the limited license expressly set forth in this Agreement.

9. USE OF RESULTS IN RESEARCH AND COMMERCIAL PUBLICATIONS:

McTrans grants the End User legal permission to use the results generated by the Software in academic, research, or commercial publications, provided that such use complies with the terms of this agreement. The End User may publish or present findings derived from the Software as part of their research or commercial work as long as the Software is properly cited and all applicable license terms and restrictions are adhered to. Unauthorized reproduction or distribution of the Software itself remains strictly prohibited.

10. TRANSFER RESTRICTIONS:

The Software is licensed only to the End User, and this License Agreement may not be assigned or transferred to anyone without McTrans' prior written consent. Any authorized transferee of this License Agreement shall be bound by the terms of this License Agreement. The End User may not transfer, assign, rent, lease, sell, or otherwise dispose of the Software except as expressly provided in this License Agreement.

11. LIMITED WARRANTY AND LIMITATIONS OF REMEDIES:

End User acknowledges and agrees that it is the sole responsibility of End User to fully understand the limitations and assumptions underlying the Software and to refrain from using the Software without the assistance of personnel with appropriate expertise. The End User accepts full responsibility for reviewing, interpreting, applying, and utilizing the output of the Software and for ensuring that such output complies with any applicable design codes, standards, or project specifications.

Except as expressly provided herein, the Software is provided "AS IS" without warranty of any kind, whether expressed or implied, including, but not limited to, implied warranties of merchantability and fitness for a particular purpose. McTrans does not warrant that the functions contained in the Software will meet the End User's requirements or that the operation of the Software will be uninterrupted or error-free. The entire risk as to the quality and performance of the product is with the End User.

In no event will McTrans be liable to the End User for any damages, including any lost profits, lost savings, or other incidental or consequential damages arising out of the use of or inability to use the Software, even if McTrans has been advised of the possibility of such damages, or for any claim by any other party. The above warranty gives the End User specific legal rights, and the End User may also have other rights in the United States, which vary from state to state.

Use of the Software where the End User believes or has reason to believe that damage may occur constitutes a violation of any and all warranties. McTrans has no knowledge of the hardware or Software configurations of the End User and assumes no liability for their damage.

12. TERMINATION:

12.1 Termination by McTrans:

McTrans may terminate this Agreement immediately upon notice if you fail to comply with any term or condition of this Agreement. Upon termination, you must cease all use of the Software and destroy all copies of the Software in your possession.

12.2 Termination by End User:

You may terminate this Agreement at any time by discontinuing the use of the Software and notifying McTrans. No refunds will be provided for any remaining portion of the Subscription Term.

13. GOVERNING LAW:

This License Agreement shall be governed by the laws of the State of Florida, U.S.A. Venue for all disputes related to this License Agreement shall be in the United States District Court of the Northern District of Florida, Gainesville Division, or in the Circuit Court of the Eighth Judicial Circuit for Alachua County, Florida.

14. U.S. GOVERNMENT RESTRICTED RIGHTS:

The Software and associated documentation are provided with RESTRICTED RIGHTS. Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subdivision (c)(1)(ii) of The Rights in Technical Data and Computer Software clause at 52.227-7013 or subparagraphs (c)(1) and (2) of the Commercial Computer Software - Restricted Rights at 48CFR52.227-19. The contractor is McTrans, University of Florida, PO Box 116585, Gainesville, FL 32611-6585.

15. EXPORT REGULATION:

The Software may be subject to U.S. export control laws and regulations, including the U.S. Export Control Reform Act and its associated regulations. End User will not directly or indirectly export, re-export, transfer, or release the Software to, or make the Software accessible from, any country, jurisdiction, or person to which export, re-export, transfer, or release is prohibited by applicable U.S. laws and regulations. End User will comply with all applicable laws and regulations and complete all required undertakings (including obtaining any necessary export license or other governmental approval) prior to exporting, re-exporting, transferring, or releasing, or otherwise making the Software available, outside the U.S. End User shall not export, re-export, transfer, or release the software or software source code to any country which is comprehensively sanctioned by the U.S. Department of the Treasury, Office of Foreign Assets Control (OFAC), as updated from time to time, which currently includes: Cuba, Iran, North Korea, Syria, and the Donetsk, Luhansk, and Crimea regions of Ukraine.

16. SEVERABILITY:

If any portion of this License Agreement shall be declared void or a nullity by a court of competent jurisdiction, then the remainder shall survive and remain in full force. Should you have any questions concerning this license, you may contact the McTrans Center, University of Florida, PO Box 116585, Gainesville, FL 32611-6585, U.S.A., [1] (800) 226-1013.

Acknowledgements

McTrans Center, University of Florida Transportation Institute PO Box 116585, Gainesville FL 32611-6585

Telephone: 1-800-226-1013 Fax: 352-392-6629 Web: mctrans.ce.ufl.edu Email: mctrans@ce.ufl.edu

We acknowledge the Transportation Research Board (TRB), the USDOT's Federal Highway Administration (FHWA), the American Traffic Safety Services Association (ATSSA), the Institute of Transportation Engineers (ITE), and the American Association of State Highway and Transportation Officials (AASHTO) for all text, figures, and references included in HSS and express our sincere appreciation for permission to include this information.

Trademarks and Copyrights

- Microsoft(R), MS-DOS(R), and Windows(TM) are registered trademarks of Microsoft Corporation.
- McTrans(TM), HCS(TM), HSS(TM), TSIS-CORSIM(TM), and TRANSYT-7F(TM) are trademarks of the University of Florida.
- HCS, HCS2025, HCS2024, HCS2023, HCS2022, HCS7, HCS 2010, HCS+, HSS, HSS2025, HSS2024, TRANSYT-7F, and T7F are copyright University of Florida.
- TSIS-CORSIM, TSIS-CORSIM2025, TSIS-CORSIM2024, TSIS-CORSIM2023, TSIS-CORSIM2022, TSIS, CORSIM, NETSIM, FRESIM, TRAFED, TRAFVU, and TShell are copyright University of Florida, with portions copyright ITT Industries, Inc., Systems Division.

Getting Started

Getting Started

To begin, click on File then New (or the "New File..." button on the Start page).

Normal Windows keyboard and mouse functions are available. Tabbing, clicking to a new field, or pressing the Enter key will trigger a recalculation and update the report.

General Controls

Menu Items

New – Creates a new HSS file (*.xhz) and starts a new analysis project based on one of the selections below; shortcut is Ctrl+N

Segment - Creates a new HSS file (*.xhz) and starts a new Segment analysis project

Intersection/Speed Change Lanes – Creates a new HSS file (*.xhz) and starts a new Intersection/Speed Change Lanes analysis project

Rural Facility - Creates a new HSS file (*.xhz) and starts a new Rural Facility analysis project

Urban Facility - Creates a new HSS file (*.xhz) and starts a new Urban Facility analysis project

Freeway and Ramp Facility – Creates a new HSS file (*.xhz) and starts a new Freeway and Ramp Facility analysis project

Open - Opens an existing HSS file (*xhz) or HCS Freeways/Highways file (*.xuf); shortcut is Ctrl+O

Example Folder - Opens folder with HSS examples in File Explorer

Save - Saves an open HSS file (*.xhz) using the current file name; shortcut is Ctrl+S

Save As... - Saves an open HSS file (*.xhz) using a specified file name; shortcut is F12

Close - Closes an existing HSS file (*.xhz); shortcut is Ctrl+W

Units

USC Units – Changes the units of the current file to U.S. Customary

Metric Units – Changes the units of the current file to Metric

Print - Brings up printer selection and prints an HSS report to the printer or specified file type; shortcut is Ctrl+P

Print Preview – Displays preview of current report before printing; shortcut is Ctrl+F2

View

Page View - Changes the view to display inputs and report by pages; shortcut is F9

Full View

Report -> Right – Changes the view to display both the input screen and report simultaneously; the report is displayed on the right portion of the screen; shortcut is F10

Report

Formatted Report - Displays formatted report including the most important values; shortcut is F4

Text Report - Displays text report with input, intermediary, and final results; shortcut is F6

Parameter Template

View/Edit Template – Displays all Segment and Intersection Common Parameters for every Facility Type on the General page, including the Economic Analysis Common Parameters, for editing; all other pages and navigation buttons will be disabled until editing is finished; during editing, 'View/Edit Template' changes to 'To Normal Mode', which can be selected after editing is finished

Export Template – Opens a Save As dialog box for user to save the exported template as an HSS Template File (*.xhzt)

Import Template – Displays a popup indicating the template was successfully imported; all parameters for the file will update according to values saved in the imported template

Export to CSV – Opens a Save As dialog box for the user to save exported results as an HSS CSV file (*.csv); results saved in exported file are dependent on the Analysis Type of the dataset

Default Settings – Opens a dialog box for the user to input defaults for Analyst, Agency, Jurisdiction, and Default Template (which allows the user to add a default path to a saved template), which will be applied to all new files; also allows selection of USC or SI units, which will be applied to all new files; shortcut is Alt+F

Help

Contents – Provides access to glossary, acknowledgements, copyrights, and information on the HSS procedures; shortcut is Ctrl+F1

Index - Allows user to search keywords within the glossary

Search - Allows user to search for any word within the glossary

User Guide - Opens a comprehensive user guide in PDF format; shortcut is Ctrl+G

HSS Updates – Sends the HSS version number anonymously without any personally identifiable information to McTrans to check for a newer version

HSM/HSS Training – Opens the McTrans Training Page in the default web browser to view the latest training opportunities

Support

Frequently Asked Questions – Opens the McTrans support page for HSS in the default web browser

HSS Overview - Opens the McTrans HSS Overview page in the default web browser

McTrans Website - Opens the McTrans home page in the default web browser

E-mail McTrans – Composes a new e-mail addressed to McTrans in the default e-mail client with registration number, serial key, module, and version number already populated in the Subject field

About HSS – Opens an about window with software version information, EULA, general acknowledgements, contact information, and other relevant links

Exit - Exits the Highway Safety Software; shortcut is Alt+F

Highway Safety

Highway Safety Manual

The Highway Safety Software (HSS) is designed to determine the predicted number of crashes for segments and intersections following the Predictive Method found in the AASHTO Highway Safety Manual (HSM) and NCHRP reports. The basis of the Predictive Method is calculating a Safety Performance Function (SPF) and applying Crash Modification Factors (CMFs) based on certain geometric and safety feature data in the intersection/segment. The Crash Modification Factors Clearinghouse provides a searchable database of CMFs along with guidance and resources on using CMFs in road safety practice: https://cmfclearinghouse.fhwa.dot.gov/index.php. The Predictive Method is explained in the HSM Part C and the HSM Supplement in the following chapters:

- Chapter 10 Rural Two-Lane, Two-Way Roads
- Chapter 11 Rural Multilane Highways
- Chapter 12 Urban and Suburban Arterials
- Chapter 18 Freeways
- Chapter 19 Ramps

The Highway Safety Software also includes new methods developed as a product of research projects. These methods were implemented as published in the reports listed below, and may be adjusted when formally incorporated in a future release of the Highway Safety Manual:

- Roundabouts NCHRP Report 888: Development of Roundabout Crash Prediction Models and Methods / NCHRP Project 17-70
- Intersections with All-Way Stop Control NCHRP Web-Only Document 297: Intersection Crash Prediction Methods for the Highway Safety Manual / NCHRP Project 17-68, Chapter 3
- Three-Leg Intersections with Signal Control on Rural Highways NCHRP Web-Only Document 297:
 Intersection Crash Prediction Methods for the Highway Safety Manual / NCHRP Project 17-68, Chapter 4
- Urban and Suburban Segments with Six or More Lanes NCHRP Web-Only Document 318: Safety Prediction Models for Six-Lane and One-Way Urban and Suburban Arterials / NCHRP Project 17-58, Chapter 5
- Intersections of Urban and Suburban Arterials with Six or More Lanes NCHRP Web-Only Document 318: Safety Prediction Models for Six-Lane and One-Way Urban and Suburban Arterials / NCHRP Project 17-58, Chapter 6
- Urban and Suburban One-Way Arterial Roadway Segments NCHRP Web-Only Document 318: Safety Prediction Models for Six-Lane and One-Way Urban and Suburban Arterials / NCHRP Project 17-58, Chapter 7
- Intersections of Urban and Suburban One-Way Arterials NCHRP Web-Only Document 318: Safety Prediction Models for Six-Lane and One-Way Urban and Suburban Arterials / NCHRP Project 17-58, Chapter 8
- Intersections on High-Speed Urban and Suburban Arterials NCHRP Web-Only Document 297: Intersection Crash Prediction Methods for the Highway Safety Manual / NCHRP Project 17-68, Chapter 5
- Crossroad Ramp Terminals at Single-Point Diamond Interchanges NCHRP Web-Only Document 297:
 Intersection Crash Prediction Methods for the Highway Safety Manual / NCHRP Project 17-68, Chapter 8

Crossroad Ramp Terminals at Tight Diamond Interchanges – NCHRP Web-Only Document 297:
 Intersection Crash Prediction Methods for the Highway Safety Manual / NCHRP Project 17-68, Chapter 9

Initial Steps

When creating a new file in HSS from the Start page, a prompt appears asking for the Analysis Type, as shown below:



The process for user inputs is very similar between all five available Analysis Types. Once Analysis Type is selected, it cannot be changed. A new file must be created if the user wishes to change the Analysis Type.

Segment Analysis

Once Segment is selected as the Analysis Type, the user will be brought to the General page, which includes a section for Project Properties. The Project Properties section includes general information about the project, which include: Analyst, Agency, Date, Jurisdiction, Analysis Year, Project Description, Empirical Bayes Analysis, Number of Years of Observed Crashes, Facility Type, and Area Type. The user can switch between different Facility Types. The five choices of Facility Type include: Rural Two-Lane Segment, Rural Multilane Segment, Urban Segment, Freeway Segment, and Ramp Segment. If the Facility Type selected is Rural Two-Lane Segment or Rural Multilane Segment, the Area Type will automatically be set to Rural. If the Facility Type selected is Urban Segment, a drop-down menu will be enabled for Area Type, allowing a selection between Rural and Urban. An Empirical Bayes (EB) Analysis checkbox is provided for the user to indicate whether or not to use the EB analysis, which is a method used to combine observed crash frequency data for a given site with predicted crash frequency data from many similar sites to estimate its expected crash frequency. Checking this will also enable the Number of Years of Observed Crashes input on the General page and the Observed Crashes inputs on the Details page.

If economic results are enabled through the Default Settings, then Economic Analysis Common Parameters will also show on the General page. Other parameters are included on the Details page under the Parameters section. The Facility Type selected on the General page will determine which segment parameters to show. The parameters listed vary based on the Model Type under analysis.

Rural Two-Lane Segment Common Parameters include:

- Calibration Factor, C
- Proportion of Related Crashes, Pra
- Proportion of Nighttime Crashes that Involve a Fatality or Injury, Pinr
- Proportion of Nighttime Crashes that Involve Property Damage, Ppnr
- Proportion of Crashes that Occur at Night, Pnr
- Proportion of Fatal
- Proportion of Incapacitating Injury
- Proportion of Nonincapacitating Injury
- Proportion of Possible Injury
- Crash distribution proportions for Total, Fatal-and-Injury, and Property-Damage-Only crashes:
 - Single-Vehicle Crashes
 - Collision with Animal
 - Collision with Bicycle
 - Collision with Pedestrian
 - Overturned
 - Ran Off Road
 - Other Single-Vehicle Collision
 - Multiple-Vehicle Crashes
 - Angle Collision
 - Head-On Collision
 - Rear-End Collision
 - Sideswipe Collision
 - Other Multiple-Vehicle Collision

Rural Multilane Segment Common Parameters include:

- Calibration Factor, C
- Proportion of Related Crashes, Pra
- Proportion of Nighttime Crashes that Involve a Fatality or Injury, Pinr
- Proportion of Nighttime Crashes that Involve Property Damage, Ppnr
- Proportion of Crashes that Occur at Night, Pnr
- Crash distribution proportions for Total, Fatal-and-Injury, Fatal-and-Injury KAB, and Property-Damage-Only crashes:
 - Head-On Collision
 - Sideswipe Collision
 - Rear-End Collision
 - o Angle Collision
 - Single-Vehicle Crashes
 - Other Multiple-Vehicle Crashes

Urban Segment Common Parameters include:

- Calibration Factor, C (Speed <=30)
- Calibration Factor, C (Speed >30)
- Proportion of Nighttime Crashes that Involve a Fatality or Injury, Pinr
- Proportion of Nighttime Crashes that Involve Property Damage, Ppnr
- Proportion of Crashes that Occur at Night, Pnr
- Pedestrian Crash Adjustment Factor, fpedr (Speed <=30)
- Pedestrian Crash Adjustment Factor, fpedr (Speed >30)
- Bicycle Crash Adjustment Factor, fbiker (Speed <=30)
- Bicycle Crash Adjustment Factor, f_{biker} (Speed >30)

- Crash distribution proportions for Fatal-and-Injury and Property-Damage-Only crashes:
 - o Single-Vehicle Crashes
 - Collision with Animal
 - Collision with Fixed Object
 - Collision with Fixed Object-Left
 - Collision with Fixed Object-Right
 - Collision with Other Object
 - Other Single-Vehicle Collisions
 - o Multiple-Vehicle Crashes
 - Rear-End Collisions
 - Head-On Collisions
 - Angle Collisions
 - Sideswipe, Same Direction
 - Sideswipe, Opposite Direction
 - Other Multiple-Vehicle Collision

Freeway Segment Common Parameters include:

- Calibration Factor for Multiple-Vehicle Fatal-and-Injury Crashes, C_{mv,fi}
- Calibration Factor for Multiple-Vehicle Property-Damage-Only Crashes, Cmv,pdo
- Calibration Factor for Single-Vehicle Fatal-and-Injury Crashes, Csv,fi
- Calibration Factor for Single-Vehicle Property-Damage-Only Crashes, Csv,pdo


Ramp Segment Common Parameters include:

- Calibration Factor for Multiple-Vehicle Fatal-and-Injury Crashes, Cmv,fi
- Calibration Factor for Multiple-Vehicle Property-Damage-Only Crashes, C_{mv,pdo}
- Calibration Factor for Single-Vehicle Fatal-and-Injury Crashes, Csv,fi
- Calibration Factor for Single-Vehicle Property-Damage-Only Crashes, Csv.pdo

The Economic Analysis Common Parameters include Societal Crash Costs by Crash Severity:


- Fatal/Injury, \$
- Property Damage Only, \$

Below is an example of the General page:



On the Details page, four sections are provided: Segment, Input, Parameters, and Output. Depending on if Empirical Bayes Analysis is selected on the General page, there could also be an additional Observed Crashes section. The Segment section states the Facility Type selected on the General page and provides a drop-down menu for selecting the Model Type based on the Facility Type selected. Inputs and Parameters available are based on the Facility Type and Model Type selected. Outputs include the Safety Performance Functions (SPFs), the various Crash Modification Factors (CMFs), and the Predicted Crash Frequencies.

Below is an example of the Details page for a Rural Two-Lane Facility Type and an Undivided Roadway Segment (2U) Model Type, with Empirical Bayes Analysis checked on the General page:



Intersection Analysis

Once Intersection/Speed Change Lanes is selected as the Analysis Type, the user will be brought to the General page, which includes a section for Project Properties. The Project Properties section includes general information about the project, which include: Analyst, Agency, Date, Jurisdiction, Analysis Year, Project Description, Empirical Bayes Analysis, Number of Years of Observed Crashes, Facility Type, and Area Type. The user can switch between different Facility Types. The five choices of Facility Type include: Rural Two-Lane Intersection, Rural Multilane Intersection, Urban Intersection, Speed Change Lanes, and Ramp Terminal. If the Facility Type selected is Rural Two-Lane Intersection or Rural Multilane Intersection, the Area Type will automatically be set to Rural. If the Facility Type selected is Urban Intersection, the Area Type will automatically be set to Urban. If the Facility Type selected is Speed Changes Lanes or Ramp Terminal, a drop-down menu will be enabled for Area Type, allowing a selection between Rural and Urban. An Empirical Bayes (EB) Analysis checkbox is provided for the user to indicate whether or not to use the EB analysis, which is a method used to combine observed crash frequency data for a given site with predicted crash frequency data from many similar sites to estimate its expected crash frequency. Checking this will also enable the Number of Years of Observed Crashes input on the General page and the Observed Crashes inputs on the Details page.

If economic results are enabled through the Default Settings, then Economic Analysis Common Parameters will also show on the General page. Other parameters are included on the Details page under the Parameters section. The Facility Type selected on the General page will determine which intersection parameters to show. The parameters listed vary based on the Model Type under analysis.

Rural Two-Lane Intersection Common Parameters include:

- Calibration Factor, C
- Proportion of Total Crashes for Unlighted Intersections that Occur at Night, Pni
- Proportion of Fatal
- Proportion of Incapacitating Injury
- Proportion of Nonincapacitating Injury

- Proportion of Possible Injury
- Crash distribution proportions for Total, Fatal-and-Injury, and Property-Damage-Only crashes:
 - Single-Vehicle Crashes
 - Collision with Animal
 - Collision with Bicycle
 - Collision with Pedestrian
 - Vehicle Overturned
 - Ran Off Road
 - Other Single-Vehicle Collision
 - Multiple-Vehicle Crashes
 - Angle Collision
 - Head-On Collision
 - Rear-End Collision
 - Sideswipe Collision
 - Other Multiple-Vehicle Collision

Rural Multilane Intersection Common Parameters include:

- Calibration Factor, C
- Proportion of Total Crashes for Unlighted Intersections that Occur at Night, Pni
- Crash distribution proportions for Total, Fatal-and-Injury, Fatal-and-Injury KAB, and Property-Damage-Only crashes:
 - o Head-On Collision
 - Sideswipe Collision
 - Rear-End Collision
 - Angle Collision
 - Single-Vehicle Crashes
 - o Other Multiple-Vehicle Crashes

Urban Intersection Common Parameters include:

- Calibration Factor, C
- Proportion of Total Crashes that Occur at Night, Pni
- Pedestrian Crash Adjustment Factor, fpedi
- Bicycle Crash Adjustment Factor, fbikei
- Proportion of MV Crashes by Right-Angle Collisions, Pramv (FI)
- Proportion of MV Crashes by Right-Angle Collisions, Pramy (PDO)
- Proportion of MV Crashes by Rear-End Collisions, Premv (FI)
- Proportion of MV Crashes by Rear-End Collisions, Premy (PDO)
- Proportion of Fatal-and-Injury Crashes for Combined Sites, fbisv
- Crash distribution proportions for Fatal-and-Injury and Property-Damage-Only crashes:
 - Single-Vehicle Crashes
 - Collision with Parked Vehicle
 - Collision with Animal
 - Vehicle Overturned
 - Collision with Fixed Object
 - Collision with Other Object
 - Other Single-Vehicle Collision
 - Noncollision
 - Multiple-Vehicle Crashes
 - Rear-End Collision
 - Head-On Collision
 - Angle Collision
 - Sideswipe
 - Other Multiple-Vehicle Collision

Speed Change Lanes Intersection Common Parameters include:

- Calibration Factor for Fatal-and-Injury Crashes, Cfi
- Calibration Factor for Property-Damage-Only Crashes, Cpdo


Ramp Terminal Intersection Common Parameters include:

- Calibration Factor for Fatal-and-Injury Crashes, Cfi
- Calibration Factor for Property-Damage-Only Crashes, Cpdo

The Economic Analysis Common Parameters include Societal Crash Costs by Crash Severity:


- Fatal/Injury, \$
- Property Damage Only, \$

Below is an example of the General page:



On the Details page, four sections are provided: Intersection, Input, Parameters, and Output. Depending on if Empirical Bayes Analysis is selected on the General page, there could also be an additional Observed Crashes section. The Intersection section states the Facility Type selected on the General page and provides a drop-down menu for selecting the Model Type based on the Facility Type selected. Inputs and Parameters available are based on the Facility Type and Model Type selected. Additional input sections may also appear depending on the Facility Type and/or Model Type selected. Outputs include the Safety Performance Functions (SPFs), the various Crash Modification Factors (CMFs), and the Predicted Crash Frequencies.

Below is an example of the Details page for an Urban Facility Type and a Four Approach Stop (4ST) General Model Type, with Empirical Bayes Analysis checked on the General page:



Roundabout Analysis

Intersection-level inputs:

- Inscribed Circle Diameter (ICD)
- Number of legs: different crash prediction models are applied for 3-leg or 4-leg intersections
- Max. number of circulating lanes: different crash prediction models are applied to one or two circulating lanes; hybrid roundabouts mixed circulating lanes (one or two) are always analyzed as two circulating lanes

Leg-level inputs:

- Number of entering lanes
- Number of circulating lanes
- Number of exiting lanes
- Entry width
- Circulating width
- Posted speed limit
- Entering AADT
- Circulating AADT
- Exiting AADT

Note: The Highway Safety Software implements the "Design Level" crash prediction model for roundabouts. NCHRP Report 888 also developed a planning-level method, which is not included in the software.

Method Type

For urban intersections, there are different method types available for calculations. The method types include: General, Six or More Lanes, One-Way, and High-Speed. The General methodology can be found in Chapter 12 of the Highway Safety Manual. The Six or More Lanes methodology can be found in Chapter 6 of NCHRP 17-58. The One-Way methodology can be found in Chapter 8 of NCHRP 17-58. The High-Speed methodology can be found in Chapter 5 of NCHRP 17-68.

The following inputs help indicate which method type will be used:

- Number of Through Lanes on Major Street
 - o If the number of lanes is 5 or less, the method type used will be General. If the number of lanes is 6 or more, the method type used will be Six or More Lanes. If 'Is Major Street One-Way?' is checked, the method type used will be One-Way and the number of through lanes on major street will have no influence on the method type used.
- Is Major Street One-Way
 - A checkbox is provided to indicate whether or not the major street is one-way. If checked, the method used will be One-Way.
- Major-Street Posted Speed
 - A drop-down selection is provided to indicate whether the posted speed is 'Under 50 mi/h' (or 'Under 80 km/h' in metric) or '50 mi/h and Over' (or '80 km/h and Over' in metric). If the posted speed is under 50 mi/h (or 80 km/h in metric), the method type used will be General, Six or More Lanes, or One-Way, depending on the other inputs previously mentioned. If the posted speed is 50 mi/h or over (or 80 km/h or over in metric), the method type used will be High-Speed.

Rural Facility Analysis


Once Rural Facility is selected as the Analysis Type, the user will be brought to the General page, which includes sections for Project Description, Facility Data, and Parameters. The Project Description section includes general information about the project, which include: Analyst, Agency, Date, Jurisdiction, Analysis Year, Project Description, Empirical Bayes Analysis, and Number of Years of Observed Crashes. An Empirical Bayes (EB) Analysis checkbox is provided for the user to indicate whether or not to use the EB analysis, which is a method used to combine observed crash frequency data for a given site with predicted crash frequency data from many similar sites to

estimate its expected crash frequency. Checking this will also enable the Number of Years of Observed Crashes input on the General page and the Observed Crashes input on the Details page.

The Facility Data section includes a table that specifies details for individual sections within a rural facility. When a new Rural Facility analysis is created, the table will have one row of section data already added to the table. The user can choose to keep this section or delete it by selecting the row and clicking the button 'Delete Section'. If there are multiple rows of data the user wishes to delete, consecutive rows can be selected at a time and then deleted together using the same button. To add a section, two buttons are provided: 'Add Section' and 'Insert Section'. 'Add Section' will add a new row of section data at the end of the table. 'Insert Section' will add a new row of section data before the selected row. Before adding or inserting a section, the user can specify the Facility Type and Section Type of the new section being added. The New Section Facility Types include: Rural Two-Lane and Rural Multilane. The New Section Types include: Segment and Intersection. The row of data added to the table includes: Section Type; Facility Type; Name; Model Type; AADT, veh/day; Length; Details; N(spf); and N(predicted). Observed Crashes and N(expected) are also included in the table if Empirical Bayes Analysis is checked. Clicking on Details will bring the user to the corresponding Details page. N(spf), N(predicted), Observed Crashes, and N(expected) are determined by the inputs found on the Details page. Under the table, the total number of predicted crashes, which is the summation of N(predicted) for all sections, is specified.


The Parameters section gives the option of using Project-Level Parameters or Section-Level Parameters. A checkbox is provided to indicate this. If Project-Level Parameters is checked, the Parameters section on the General page will include Segment Common Parameters and Intersection Common Parameters for Rural Two-Lane and Rural Multilane facilities, along with corresponding crash distribution proportions; and Economic Analysis Common Parameters if enabled. If Project-Level Parameters is not checked, only Economic Analysis Common Parameters will display on the General page if enabled. Corresponding section-level parameters will display on the Details page of each of the sections. For the list of parameters, please see Segment Analysis and/or Intersection Analysis.

Below is an example of the General page:



On the Details page, three sections are provided: Section Data, Input, and Output. If Project-Level Parameters is not checked on the General page, a fourth section (Parameters) will appear on the Details page after the Input section. Section Data allows the user to select which section details to display. It also specifies the Facility Type, Section Type, and Model Type of the section. Inputs available are based on the Facility Type, Section Type, and Model Type selected. Section-level parameters display in the Parameters section according to the Facility, Section, and Model Type of the section displayed. Outputs include the Safety Performance Function (SPF), the various Crash Modification Factors (CMFs), and the Predicted Crash Frequency (Npredicted).

Below is an example of the Details page for a Rural Multilane Facility Type, Segment Section Type, and Divided Model Type combination, with Empirical Bayes Analysis checked and Project-Level Parameters not checked on the General page:




Urban Facility Analysis

Once Urban Facility is selected as the Analysis Type, the user will be brought to the General page, which includes sections for Project Description, Facility Data, and Parameters. The Project Description section includes general information about the project, which include: Analyst, Agency, Date, Jurisdiction, Analysis Year, Project Description, Empirical Bayes Analysis, and Number of Years of Observed Crashes. An Empirical Bayes (EB) Analysis checkbox is provided for the user to indicate whether or not to use the EB analysis, which is a method used to combine observed crash frequency data for a given site with predicted crash frequency data from many similar sites to estimate its expected crash frequency. Checking this will also enable the Number of Years of Observed Crashes input on the General page and the Observed Crashes input on the Details page.

The Facility Data section includes a table that specifies details for individual sections within an urban facility. When a new Urban Facility analysis is created, the table will have one row of section data already added to the table. The user can choose to keep this section or delete it by selecting the row and clicking the button 'Delete Section'. If there are multiple rows of data the user wishes to delete, consecutive rows can be selected at a time and then deleted together using the same button. To add a section, two buttons are provided: 'Add Section' and 'Insert Section'. 'Add Section' will add a new row of section data at the end of the table. 'Insert Section' will add a new row of section data before the selected row. Before adding or inserting a section, the user can specify the Section Type of the new section being added. The New Section Types include: Segment and Intersection. The row of data added to the table includes: Section Type; Facility Type; Name; Model Type; AADT, veh/day; Length; Details; N(spf); and N(predicted). Observed Crashes and N(expected) are also included in the table if Empirical Bayes Analysis is checked. Clicking on Details will bring the user to the corresponding Details page. N(spf), N(predicted), Observed Crashes, and N(expected) are determined by the inputs found on the Details page. Under the table, the total number of predicted crashes, which is the summation of N(predicted) for all sections, is specified.


The Parameters section gives the option of using Project-Level Parameters or Section-Level Parameters. A checkbox is provided to indicate this. If Project-Level Parameters is checked, the Parameters section on the General page will include Segment Common Parameters and Intersection Common Parameters for an Urban facility, along with corresponding crash distribution proportions; and Economic Analysis Common Parameters. If Project-Level Parameters is not checked, only Economic Analysis Common Parameters will display on the General page. Corresponding section-level parameters will display on the Details page of each of the sections. For the list of parameters, please see *Segment Analysis* and/or *Intersection Analysis*.

Below is an example of the General page:



On the Details page, three sections are provided: Section Data, Input, and Output. If Project-Level Parameters is not checked on the General page, an extra section (Parameters) will appear on the Details page after the Input section. If Empirical Bayes Analysis is checked on the General page, an extra section (Observed Crashes) will appear on the Details page before the Output section. Section Data allows the user to select which section details to display. It also specifies the Facility Type, Section Type, and Model Type of the section. Inputs available are based on the Facility Type, Section Type, and Model Type selected on the General page. Section-level parameters display in the Parameters section according to the Facility, Section, and Model Type of the section displayed. Observed Crashes inputs are based on the Section Type selected. Outputs include the Safety Performance Functions (SPFs), the various Crash Modification Factors (CMFs), and the Predicted Crash Frequencies.

Below is an example of the Details page for an Urban Facility Type, Intersection Section Type, and Three Approach Stop (3ST) General Model Type combination, with Empirical Bayes Analysis checked and Project-Level Parameters not checked on the General page:




Freeway and Ramp Facility Analysis

Once Freeway and Ramp Facility is selected as the Analysis Type, the user will be brought to the General page, which includes sections for Project Description, Facility Data, and Parameters. The Project Description section includes general information about the project, which include: Analyst, Agency, Date, Jurisdiction, Analysis Year, Project Description, Area Type, Empirical Bayes Analysis, and Number of Years of Observed Crashes. An Empirical Bayes (EB) Analysis checkbox is provided for the user to indicate whether or not to use the EB analysis, which is a method used to combine observed crash frequency data for a given site with predicted crash frequency data from many similar sites to estimate its expected crash frequency. Checking this will also enable the Number of Years of Observed Crashes input on the General page and the Observed Crashes input on the Details page.

The Facility Data section includes a table that specifies details for individual sections within a freeway facility. When a new Freeway and Ramp Facility analysis is created, the table will have one row of section data already added to the table. The user can choose to keep this section or delete it by selecting the row and clicking the button 'Delete Section'. If there are multiple rows of data the user wishes to delete, consecutive rows can be selected at a time and then deleted together using the same button. To add a section, two buttons are provided: 'Add Section' and 'Insert Section'. 'Add Section' will add a new row of section data at the end of the table. 'Insert Section' will add a new row of section data before the selected row. Before adding or inserting a section, the user can specify the Section Type of the new section being added. The New Section Types include: Segment and Intersection. The row of data added to the table includes: Section Type; Facility Type; Name; Model Type; AADT, veh/day; Length; Details; N(spf); and N(predicted). Observed Crashes and N(expected) are also included in the table if Empirical Bayes Analysis is checked. Clicking on Details will bring the user to the corresponding Details page. N(spf), N(predicted), Observed Crashes, and N(expected) are determined by the inputs found on the Details page. Under the table, the total number of predicted crashes, which is the summation of N(predicted) for all sections, is specified.


The Parameters section gives the option of using Project-Level Parameters or Section-Level Parameters. A checkbox is provided to indicate this. If Project-Level Parameters is checked, the Parameters section on the General page will include Segment Common Parameters and Intersection Common Parameters for Freeway Segment and Ramp Segment, and Speed Change Lanes and Ramp Terminal, respectively; and Economic Analysis Common Parameters. If Project-Level Parameters is not checked, only Economic Analysis Common Parameters will display on the General page. Corresponding section-level parameters will display on the Details page of each of the sections. For the list of parameters, please see *Segment Analysis* and/or *Intersection Analysis*.

Below is an example of the General page:



On the Details page, three sections are provided: Section Data, Input, and Output. If Project-Level Parameters is not checked on the General page, an extra section (Parameters) will appear on the Details page after the Input section. If Empirical Bayes Analysis is checked on the General page, an extra section (Observed Crashes) will appear on the Details page before the Output section. Section Data allows the user to select which section details to display. It also specifies the Facility Type, Section Type, and Model Type of the section. Inputs available are based on the Facility Type, Section Type, and Model Type selected on the General page. Section-level parameters display in the Parameters section according to the Facility, Section, and Model Type of the section displayed. Observed Crashes inputs are based on the Section Type selected. Outputs include the Safety Performance Functions (SPFs), the various Crash Modification Factors (CMFs), and the Predicted Crash Frequencies.

Below is an example of the Details page for a Freeway Facility Type, Speed Changes Lanes Section Type, and Speed Change Lanes Model Type combination, with Empirical Bayes Analysis checked and Project-Level Parameters not checked on the General page:



Report

The report page shows a formatted version of the analysis in a dynamic form, reacting to changes in the General and Details pages. All or a portion can be copied to the Windows clipboard for insertion into other files by right-clicking into the report and selecting Copy.

Both formatted and text reports are available for viewing (through the Report tab or Print Preview) and printing. The formatted report provides data and results that are most important to the user, and are displayed in a clean and more presentable fashion. The text report provides more details to the user, rather than a summary. A drop-down menu is provided for section selection for both formatted and text reports. Reports can be displayed based on the specific individual section selected or all sections can be displayed together.

How To

Create a New File

1. From the Start screen, there are three options for creating a new file:



Note: A new file can be created if an existing file is already open; you do not need to start from the Start screen.


a. Selecting *File > New* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen, hovering over "New", and then selecting one of the analysis types.




b. Selecting "New File..." from the Start screen; this can be found below in the red box. A Select New File Type dialog box will pop up after selecting "New File..." which allows you to choose the desired analysis type.



c. Using the keyboard shortcut "Ctrl+N", selecting one of the analysis types from the Select New File Type dialog box, and clicking "OK"



2. Once a new file is created, you will be brought to the General page of the selected analysis type.



Open an Existing File

1. From the Start screen, there are six options for opening an existing file:



Note: A file can be opened even if another file is currently open; you do not need to start from the Start screen.

a. Selecting *File* > *Open* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Open"



o. Selecting "Open File..." from the Start screen; this can be found below in the red box



c. Using the keyboard shortcut "Ctrl+O"

d. Selecting a file under the Recent files list from the Start screen; this can be found below in the red box




e. Selecting File > Example Folder from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Example Folder". Opening the example folder will open the path of the HSS example files in File Explorer. The desired example file can be double-clicked or right-clicked and selecting 'Open', which will open the example file in the Highway Safety Software program.




f. Selecting "Example Folder..." from the Start screen; this can be found below in the red box. Opening the example folder will open the path of the HSS example files in File Explorer. The desired example file can be double-clicked or right-clicked and selecting 'Open', which will open the example file in the Highway Safety Software program.



Once an existing file is opened, you will be brought to the General page




3. Note: HSS can open both HSS files (*.xhz) and HCS Freeways/Highways (*.xuf) files. By default, the Open dialog will display HSS files (*.xhz). To open Freeways/Highways (*.xuf), please change the file type in the Open dialog. If opening a Freeways/Highways file, HSS will convert any relevant Freeways/Highways inputs to the corresponding HSS inputs. It is recommended to review inputs for accuracy.




Save a File


- 1. There are five options for saving an open file:
 - a. Selecting *File > Save* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Save"



b. Selecting *File > Save As...* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Save As..."



- c. Using the keyboard shortcut "Ctrl+S" for Save
- d. Using the keyboard shortcut "F12" for Save As
- e. Exiting the program or closing the file without saving changes beforehand; this will prompt you to save changes to the file before anything is closed




- Selecting "Yes" will save the file if it is an existing file. If the file has not been previously saved, the Save As dialog box will pop up allowing you to change the file name and save it.
- ii. Selecting "No" will exit the program or close the file without saving the file
- iii. Selecting "Cancel" will prevent the file from closing

Note: Using Save with an existing file will save a file without prompting you to specify a file name. Using Save with a new file will bring up the Save As dialog box for you to specify a file name for saving. Using Save As will always bring up the Save As dialog box for you to specify a file name for saving.

Close a File

- 1. There are three options for closing an open file:
 - a. Selecting *File > Close* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Close"



- b. Using the keyboard shortcut "Ctrl+W"
- c. Exiting the program itself; please see How To: Exit the Program

Exit the Program

1. From the Start screen, there are three options for exiting the program:



Note: The program can be exited even if a file is still open; you do not need to start from the Start screen.

a. Selecting *File > Exit* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Exit"



- b. Using the keyboard shortcut "Alt+F4"
- c. Selecting "X" in the top right-hand corner of the screen; this can be found below in the red box



Edit the Default Settings

1. From the Start screen, there are two options for editing the Default Settings:




Note: The Default Settings can be changed even if an existing file is already open; you do not need to start from the Start screen.

a. Selecting *File > Default Settings* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Default Settings"



b. Using the keyboard shortcut "Alt+F4"


2. Opening the Default Settings will cause a Default Settings window to pop up:



- 3. You can specify Analyst, Agency, and Jurisdiction by clicking in the corresponding text boxes and typing the desired text.
- 4. You are also given the option to specify a default parameters template. You can either click the 'Default Template' button which will allow you to browse through files in an Open dialog box and select an HSS Template File (*.xhzt) or you can type out the path of the file in the provided text box. Selecting a file through the dialog box will automatically fill out the text box with the path of the file. For more information on the Default Template, please see *How To: Change Parameters*.
- 5. Under 'Units', you are given the option of running the analysis in either *U.S. Customary (USC)* or *SI (Metric)* units.
- 6. Clicking "OK" will save the changes made and close the Default Settings window; clicking "Cancel" will close the Default Settings window without saving any changes.
- 7. When a new file is created, the Analyst, Agency, and Jurisdiction fields will automatically be populated with the text specified in the Default Settings.
- 8. When a new file is created or an existing file is opened, the parameters from the default template selected will be applied to the analysis.
- 9. When starting a new file, the inputs and results will display according to the units specified in the Default Settings

Change Parameters


- 1. Parameters within HSS can be changed by editing individual fields or with the use of a Parameters Template.
- 2. Individual Fields
 - a. To edit individual fields, you can access parameters either on the General page with Project-Level Parameters or the Details page with Section-Level Parameters.
 - i. Project-Level Parameters
 - 1. On the General page, there is a 'Project-Level Parameters' checkbox. Checking this box will add the parameters to the General page where you can edit any of the enabled fields. Note: Parameter fields are enabled/disabled depending on the analysis type.



- 2. Corresponding parameters are applied to all the sections within the facility.
- 3. The Parameters section on the Details page is hidden when 'Project-Level Parameters' is checked.

ii. Section-Level Parameters

1. On the Details page, there is a Parameters section. This section is only available when 'Project-Level Parameters' on the General page is unchecked. If it is checked, then the Parameters section on the Details page will be hidden.




 The parameters available in the Parameters section is dependent on the Facility Type, Section Type, and Model Type of the current section displayed. Note: You can switch between sections by selecting a different section using the Section drop down menu on the Details page.

3. Parameters Template

a. Default Template in Default Settings


- i. To specify a default parameters template to use, a valid path must be provided in the Default Template textbox within the Default Settings. This can be done by either selecting the HSS Template File (*.xhzt) or typing out the path of the file in the textbox.
 - To select the template file, click the 'Default Template' button. An Open dialog box will pop up allowing you to browse through files and select a template. Once selected and opened, the Default Template textbox will automatically populate with the path of the selected file.




- 2. When typing out the path itself, the full path must be specified, and it must be valid. An example of a parameters template file path would be C:\Users\UserName\Desktop\FileName.xhzt.
- Once a default template file is specified in the Default Settings, the parameters within that template will apply to all new files or to any changes made in existing files (e.g., adding new sections).

b. View/Edit Template

i. To view or edit the parameters template, select File > Parameter Template > View/Edit Template from the main menu; this can be found by selecting the three lines in the top lefthand corner of the screen, hovering over "Parameter Template", and then selecting "View/Edit Template".




ii. When viewing or editing the parameters template, you are taken to the General page where all existing parameters for all facility types, model types, and section types become available to view and edit.




iii. Other pages become disabled, and you can no longer navigate to other pages to make edits to inputs. Viewing or editing of the parameters template must be completed before editing other inputs.

iv. To finish viewing or editing the parameters template, select *File > Parameter Template > To Normal Mode* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen, hovering over "Parameter Template", and then selecting "To Normal Mode". *Note: This option only becomes available when in the middle of viewing or editing the parameters template.*




c. Export Template


- i. Editing the parameters template is necessary before exporting if you want to export parameters other than the default HSM/HSS parameters.
- ii. To export the parameters into a template, select *File > Parameter Template > Export Template* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen, hovering over "Parameter Template", and then selecting "Export Template".



iii. This will open a Save As dialog box allowing you to specify a name for saving the template file (*.xhzt).




- iv. Once a file name is specified, click the Save button. Note: The default template file name is the name of the HSS file with the template file extension (*.xhzt) but can be overwritten.
- v. The template file will be saved in the folder you specified when saving.




- d. Import Template
 - i. Importing a parameters template file requires access to an already saved template file (*.xhzt).
 - ii. To import parameters from a template, select *File > Parameter Template > Import Template* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen, hovering over "Parameter Template", and then selecting "Import Template".




iii. This will open an Open dialog box allowing you to select a template file (*.xhzt).



iv. Once a file name is selected, click the Open button.




v. The template file will be imported, and a message will pop up saying if the template was imported successfully.




vi. The 'Project-Level Parameters' checkbox on the General page should now be checked, if it was not already, and the parameters from the imported template file should be reflected in the project-level parameters.

Export to CSV


1. To export data to a CSV file, select *File > Export to CSV* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen, and then selecting "Export to CSV".




2. When an analysis is exported to a CSV file, a Save As dialog box will pop up allowing you to specify a name for saving the HCS CSV file (*.csv). Note: The default CSV file name is the name of the HSS file (*.xhz) along with "-Results.csv" but can be overwritten.




3. Once a file name is specified, click the Save button.



4. The CSV file of the analysis results will be saved in the folder you specified when saving.




5. If you open the exported CSV file, the default program for CSV files will open.



6. Results from the HSS file (*.xhz) will be displayed in the CSV file. HSS currently only exports select outputs from each analysis type.

Run an Empirical Bayes Analysis


- 1. Empirical Bayes Analysis, or EB Analysis, is a method used to combine observed crash frequency data for a given site with predicted crash frequency data from many similar sites to estimate its expected crash frequency.
- 2. To run an EB Analysis, the 'Empirical Bayes Analysis' checkbox on the General page must be checked.




3. Running an EB analysis will enable new fields:

'Observed Crashes' in the table on the General page for facility analyses; Note: Depending on the


analysis type of the dataset, these field may be readable only.




b. 'N(expected)' in the table on the General page for facility analyses; Note: These fields are readable only.




c. Observed Crashes on the Details page; *Note: Depending on the analysis type of the dataset, there may be an Observed Crashes section with multiple fields.*



- 4. Running an EB analysis will add new sections and results to the reports:
 - a. 'Expected Roadway Section Crashes' in the formatted report




b. 'Expected Crashes' in the text report




5. Economic analysis will be based on Expected Crash Frequency instead of Predicted Crash Frequency when an EB analysis is run. Please see *How To: Run an Economic Analysis*.

Run an Economic Analysis

- 1. The Federal Highway Administration (FHWA) has completed research that established a basis for quantifying, in monetary terms, the human capital crash costs to society of fatalities and injuries from highway crashes
- 2. State and local jurisdictions often have accepted societal crash costs by crash severity and collision type. When available, their locally-developed societal crash cost data are used with procedures in the HSM.
- To run the economic analysis, it must first be enabled in the Default Settings. This can be done by checking 'Show Economic Results in Reports'.




4. On the General page of an analysis, Economic Analysis Common Parameters are provided. This includes Societal Crash Costs by Crash Severity.




- a. Default Values
 - i. Fatal/Injury: \$158,200
 - ii. Property Damage Only: \$7,400
- An Economic Analysis in HSS is automatically run. However, you have the option of adjusting the cost of fatal and injury (FI) crashes and property damage only (PDO) crashes by editing the monetary value in the corresponding text boxes.
- 6. On both the formatted and text reports, an Economic Analysis section is provided.
 - Formatted Report START GENERAL DETAILS REPO **Crash Modification Factors** ane Width - CMF1 Lighting - CMF4 Shoulder Type/Width - CMF2 Auto. Speed Enforcement - CMF5 1.000 1.040 Median Width - CMF3 1 020 Combined CMF **Predicted Roadway Section Crashes** Crash Severity Nspf,rs by Severity Predicted Crash Frequency (crashes/year) Predicted Crash Rate (crashes/mi/year) Predicted Crash Rate (crashes/100M VMT) Fatal and Injury (FI) 1.480 1.727 1.151 31.541 Property Damage Only (PDO) 1.355 1.581 1.054 28.885 2.835 3.308 2.206 60.426 **Expected Roadway Section Crashes** Average Observed Crashes Expected Crash Rate (crashes/mi/year) Expected Crash Rate (crashes/100M VMT) Crash Severity Expected Crash Frequency Weight Fatal and Injury (FI) 4.000 38.813 2.125 1.417 0.000 1,404 0.936 25.644 3.529 **Economic Analysis (Expected Crashes)** Crash Severity Per Crash Societal Crash Cost Expected Annual Crashes Total Societal Crash Cost \$158,200.00 \$336,175.00 Fatal and Injury (FI) Property Damage Only (PDO) 1.404 \$10,389.60 \$7,400.00 Total 3.529 \$346,564.60


b. Text Report



- 7. The societal crash costs are based on either predicted crashes or expected crashes. This is dependent on whether an EB analysis is run.
 - a. If 'Empirical Bayes Analysis' is unchecked on the General page, then the societal crash costs are based on predicted crashes.




b. If 'Empirical Bayes Analysis' is checked on the General page, then the societal crash costs are based on expected crashes.




Apply User-Defined CMFs


- In any analysis, a user has the option to add additional CMFs that they can define. Once defined, the CMFs added will get applied in the analysis in addition to the CMFs that are already calculated in the methodology.
- 2. On the Details page, there is a 'User-Defined CMFs' section provided. By default, the table is empty.




3. To add a user-defined CMF, click on the 'Add User-Defined CMF' button.




4. This will add a row to the table where the following can be edited:



- a. CMF Name this allows the user to specify a short name for any CMF added
- b. CMF Description this allows the user to specify a longer detailed description of any CMF added
- c. CMF Type this allows the user to specify the type of CMF for any added CMFs. The different CMF types include the following: Total, FI, PDO. Depending on the type selected, the user-defined CMF will get applied with the calculated CMFs in the methodology for the facility/model type combination established.
- d. CMF Value this allows the user to specify the value of the CMF for any added CMFs. This value will then get applied in the analysis based on the CMF type established for it.
- 5. If any added CMFs need to be removed, a 'Delete User-Defined CMF' button is provided.




6. To remove a CMF, select the row(s) desired to be removed. Then click the 'Delete User-Defined CMF' button.



7. The selected row(s) will be removed and those CMFs will no longer apply in the analysis.

View Results of the Analysis

- 1. After editing all the necessary inputs, results of the analysis can be found in the form of pages and in the form of reports.
- 2. There are two options for pages: Details and Report
 - a. Although the Details page includes inputs, there is an Output section at the bottom of the page that includes a few results.



b. The Report page can display single section formatted reports and single section text reports.



- 3. There are two options for reports: Formatted and Text
 - a. Formatted reports show the most important results in a presentable format


	ighwa	y Safety	Softwa	re Rui	ral Two Lane S	egment Rep		
Project Information								
Analyst	1			Date		9/9/2024		
Jurisdiction					Analysis Year		2024	***
Project Description		HSM Chapter 10: Sample Problem 5			Section Number		1	
Input Data								
Length of Segment (mi)		1.500			AADT (veh/day)		10000	
Lane Width (ft)		10.0			Grade (%)		2.0	
Shoulder Type		Gravel			Shoulder Width (ft)		4.0	
Driveway Density (driveway/mi	i)	6			Roadside Hazard Ra	ting	4	
Centerline Rumble Strips		No			Passing Lanes		No Pas	sing or Climbing Lanes
Two-Way Left Turn Lane		No			Segment Lighting		No	
Automated Speed Enforcemen	ıt	No			Calibration Factor		1.10	
Crash Modification Fa	ctors							
Lane Width - CMF1		1.172			Centerline Rumble S	trips - CMF7	1.000	
Shoulder Type/Width - CMF2		1.093			Passing Lanes - CMF8		1.000	
Horizontal Curve - CMF3		1.000			Two-Way Left Turn Lane - CMF9		1.000	
Superelevation - CMF4		1.000			Roadside Design - CMF10		1.069	
Grade - CMF5		1.000			Lighting - CMF11		1.000	
Driveway Density - CMF6		1.012			Auto. Speed Enforcement - CMF12		1.000	
Combined CMF		1.385						
Predicted Roadway Se	ection	Crashes			'			
Crash Severity	Crash Severity Nspt,rs by Se				ted Crash Frequency (crashes/year)	Predicted Crash Rate (crashes/mi/year)		Predicted Crash Rate (crashes/100M VMT)
Fatal and Injury (FI)	1.286			1.960		1.307		35.801
Property Damage Only (PDO)	2.721		4.146			2.764		75.730
Total	4.008		6.106			4.071		111.531
Expected Roadway Se	ction	Crashes						
Crash Severity		Average Observed Weight Crashes		Expected Crash Frequency (crashes/mi/year)		Expected Crash Rate (crashes/mi/year)		Expected Crash Rate (crashes/100M VMT)
Fatal and Injury (FI)	-	- 2.57		2.571		1.714		99.339
Property Damage Only (PDO)	2.	- 5.4		5.439		3.626		99.339
Total	10.000		0.511	8.010		5.340		146.301
Economic Analysis (Ex	kpecte	d Crashe	s)					ir.
Crash Severity	Per Crash So	er Crash Societal Crash Cost		Expected Annual Crashes		Total Societal Crash Cost		
Fatal and Injury (FI)		\$158,200.00			2.571		\$406,765.42	
Property Damage Only (PDO)		\$7,400.00			5.439		\$40,247.05	
Total		4			8.010		\$447,012.47	

b. Text reports show a more detailed analysis in plain text

- 4. The type of report displayed can be changed by using the main menu items, keyboard shortcuts, or toggle buttons found under the report
 - a. Main Menu Items
 - i. To switch to the Formatted Report, select *File > Report > Formatted Report* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen, hovering over "Report", and then selecting "Formatted Report".




ii. To switch to the Text Report, select *File > Report > Text Report* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen, hovering over "Report", and then selecting "Text Report".




b. Keyboard Shortcuts


- i. Formatted Report: keyboard shortcut is "F4"
- ii. Text Report: keyboard shortcut is "F6"
- c. Report Toggle Buttons
 - i. If the formatted report is currently being displayed, the toggle button will say "Switch to Text Report" which will allow you to display the text report if clicked.




ii. If the text report is currently being displayed, the toggle buttons will say "Switch to Formatted Report" which will allow you to display the formatted report if clicked.



5. For both formatted and text reports, a Section drop down menu is provided next to the toggle button. All reports are section specific reports. The drop-down menu allows you to select which section to display on the Report page. There is also the option of showing all sections which will show each of the section reports one after the other.




The magnification of the report currently being displayed can be changed using the zoom slider found at the bottom right-hand corner of the screen.



- To zoom in, drag the slider to the right; to zoom out, drag the slider to the left
- b. Clicking the plus (+) button will zoom in; clicking the minus (-) button will zoom out
- c. Holding down "ctrl" on the keyboard and scrolling up on the mouse wheel will zoom in; holding down "ctrl" on the keyboard and scrolling down on the mouse wheel will zoom out

Print a Report

- 1. There are four options for printing a report:
 - a. Selecting *File > Print* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Print"




b. Selecting *File > Print Preview* from the main menu; this can be found by selecting the three lines in the top left-hand corner of the screen and then selecting "Print Preview"



- c. Using the keyboard shortcut "Ctrl+P" for Print
- d. Using the keyboard shortcut "Ctrl+F2" for Print Preview


2. Print

a. Using Print will bring up a Print dialog box where you can select which printer to print to



3. Print Preview


a. Using Print Preview will bring up a window where you can view how the report will look on paper before sending it to the printer



b. The print icon in the toolbar found in the top left-hand corner can then be selected



c. A print dialog box will pop up where you can select which printer to print to



Glossary of Terms

AADT

Annual average daily traffic; the counted (or estimated) total traffic volume in one year divided by 365 days/year.

Rural Two-Lane, Two-Way Roads (Chapter 10); Rural Multilane Highways (Chapter 11); Urban and Suburban Arterials (Chapter 12)

For each roadway segment, the AADT is the average daily two-way, 24-hour traffic volume on that roadway segment in each year of the evaluation period.

For each intersection, two values are required in each predictive model. These are the AADT of the major street, $AADT_{mai}$, and the two-way AADT of the minor street, $AADT_{min}$.

In Chapter 10, $AADT_{maj}$ and $AADT_{min}$ are determined as follows: if the AADTs on the two major road legs of an intersection differ, the larger of the two AADT values is used for the intersection. For a three-leg intersection, the minor road AADT is the AADT of the single minor road leg. For a four-leg intersection, if the AADTs of the two minor road legs differ, the larger of the two AADT values is used for that intersection. If AADTs are available for every roadway segment along a facility, the major road AADTs for intersection legs can be determined without additional data.

In Chapter 11, $AADT_{maj}$ and $AADT_{min}$ are determined as follows: if the $AADT_s$ on the two major-road legs of an intersection differ, the larger of the two AADT values are used for $AADT_{maj}$. For a three-leg intersection, the AADT of the minor-road leg is used for $AADT_{min}$. For a four-leg intersection, the larger of the $AADT_s$ for the two minor-road legs should be used for $AADT_{min}$. If a highway agency lacks data on the entering traffic volumes, but has two-way AADT data for the major and minor-road legs of the intersection, these may be used as a substitute for the entering volume data. Where needed, $AADT_{total}$ can be estimated as the sum of $AADT_{maj}$ and $AADT_{min}$.

In Chapter 12, AADT_{maj} and AADT_{min} are determined as follows: if the AADTs on the two-major-road legs of a four-leg intersection differ, the larger of the AADTs for the two minor road legs is used. For a three-leg intersection, the AADT of the single minor road leg is used. If AADTs are available for every roadway segment along a facility, the major-road AADTs for intersection legs can be determined without additional data.

Freeways (Chapter 18)

For each freeway segment, the following five AADT values are required:


- (1) the AADT volume of the freeway segment (AADT_{fs}),
- (2) the AADT volume of the nearest entrance ramp upstream of the segment for the increasing milepost travel direction (AADT_{b,ent}),
- (3) the AADT volume of the nearest entrance ramp upstream of the segment for the decreasing milepost travel direction (AADT_{e,ent}),
- (4) the AADT volume of the nearest exit ramp downstream of the segment for the increasing milepost travel direction (AADT_{b.ext}), and

(5) the AADT volume of the nearest exit ramp downstream of the segment for the decreasing milepost travel direction (AADT_{b.ext}).

For each ramp entrance speed-change lane, two values are required. They include the AADT volume of the freeway segment and the AADT volume of the ramp.

For each ramp exit speed-change lane, only the AADT volume of the freeway segment is required. The AADT volume of the ramp is not needed.

The AADT volumes are needed for each year of the evaluation period. The AADT volume for a given year represents an annual average daily 24-hour traffic volume. The freeway segment AADT volume is a two-way volume (i.e., the total of both travel directions). Each ramp AADT volume represents a one-way volume.



Ramps (Chapter 19)

The AADT volume of the ramp is needed for each ramp segment. The AADT volume of the C-D road is needed for the evaluation of each C-D road segment.

For each crossroad ramp terminal, one AADT value is needed for each intersection leg. Thus, for a four-leg ramp terminal, the following values are needed: AADT volume of the crossroad leg "inside" the interchange, AADT volume of the crossroad leg "outside" of the interchange, AADT volume of the exit ramp, and AADT volume of the entrance ramp. The inside crossroad leg is the leg that is on the side of the ramp terminal nearest to the freeway. The outside crossroad leg is on the other side of the ramp terminal. The AADT of the loop ramp at a terminal with either an A4 or B4 configuration is not needed (or used in the calculations.

The AADT volumes are needed for each year of the evaluation period. The AADT volume for a given year represents an annual average daily 24-hour traffic volume. The ramp and C-D road segment AADT volume is a one-way volume. The crossroad segment AADT volume is a two-way volume (i.e., total of both travel directions).

 $AADT_r$ is the AADT volume of the ramp segment in veh/day. $AADT_c$ is the AADT volume of the C-D road segment in veh/day.

Crossroad Ramp Terminals at Single-Point (SP) Diamond Interchanges and Tight Diamond (TD) Interchanges (NCHRP 17-68 Chapters 8 and 9)

AADT_{xrd} is the AADT volume on the crossroad in veh/day. AADT_{ramp} is the sum of ramp AADTs in veh/day. Ramp AADTs include entrance ramp 1 AADT (AADT_{en1}), entrance ramp 2 AADT (AADT_{en2}), exit ramp 1 AADT (AADT_{ex1}), and exit ramp 2 AADT (AADT_{ex2}). All ramp AADTs are in veh/day.

Add Horizontal Curve

For Freeway Segment, Ramp Segment, and Freeway Intersection analyses, a button for adding a horizontal curve is available when 'Include Horizontal Curves' is checked.

For Freeway Segment and Speed Change Lanes analyses, clicking on the button 'Add Horizontal Curve' will add a row of inputs which include the following: Primary Radius, Secondary Radius, and Length in Segment. Primary Radius is measured for roadbed curves and Secondary Radius is measured to the inside edge of the traveled way.

For Ramp Segment and C-D Road Segment analyses, clicking on the button 'Add Horizontal Curve' will add a row of inputs which include the following: Radius of Curve, Average Entry Speed, and Length in Segment.

The user can add an unlimited number of horizontal curves.

Add Section

For facility analyses, a button for adding a section is available. Clicking on the button 'Add Section' will add a row of inputs which include the following: Section Type, Facility Type, Model Type, Details, N(spf), and N(predicted). Section Type can either be Segment or Intersection. Facility Type can either be Rural Two-Lane or Rural Multilane in a Rural Facility analysis. Facility Type can only be Urban in an Urban Facility analysis. Section Type and Facility Type cannot be changed within the rows. They must be specified before the new section is added. Model Type can be changed within the rows and the choices available are dependent on Section Type and Facility Type combinations. Clicking on Details within a row will bring the user to the Details page for that specific section. N(spf) specifies the predicted average crash frequency for base conditions for that individual section. N(predicted) specifies the predicted average crash frequency for that individual section, which is dependent on the inputs specified on the Details page. The user can add an unlimited number of sections.

Add User-Defined CMF

A button is provided to add user-defined CMFs, if desired. After clicking 'Add User-Defined CMF', a row will be added to the User-Defined CMFs table. The row includes the following: CMF Name, CMF Description, CMF Type, and CMF Value. The user can make changes to each of these inputs and the value specified for the CMF will get applied in the analysis.

Agency

This field is provided to document the agency or company associated with this analysis or project.

Analysis Type

This specifies the type of analysis to be done. Choices include: Segment, Intersection, Rural Facility, Urban Facility, Freeway Facility, and Ramp Facility.

Analysis Year

This field is provided to document the year for which the analysis is being performed.

Analyst

This field is provided to document the name of the analyst.

Angle

The angle to next leg is used to measure the relative intersection skew; it is measured in degrees. Angle is measured for each leg of the roundabout.

Any Ramps within 0.5 mi

A checkbox is provided to indicate if there are any ramps within 0.5 miles (or 0.8 kilometers in metric). If ramps are within 0.5 miles (or 0.8 kilometers in metric) of the end point of the segment, there is a potential for increased crashes due to lane changing.

Approach

A lane or set of lanes at an intersection that accommodates all left-turn, through, and right-turn movements from a given direction.

Approaches for which Right-Turn-on-Red is Prohibited

This is the number of signalized intersection approaches for which right-turn-on-red is prohibited. This affects the CMF for right-turn-on-red operation (CMF_{4i}).

Approaches for which U-Turn is Prohibited

This indicates the number of approaches from which U-turns are prohibited via "No U-turn" signs. It is used in the calculation of the U-turn Prohibition CMF.

Approaches with Turn Lanes

The number of approaches with left-turn lanes and the number of approaches with right-turn lanes are necessary for determining the effects of individual geometric design of intersections. Approaches include the major and minor road approaches. Turn lanes include exclusive left-turn lanes and exclusive right-turn lanes. Stop-controlled approaches are not considered in determining the number of approaches with right- or left-turn lanes.

Area Type

This specifies whether the area is rural or urban.

See also Rural Areas and Urban Environment.

Automated Speed Enforcement

Automated speed enforcement systems use video or photographic identification in conjunction with radar or lasers to detect speeding drivers. The systems automatically record vehicle registrations without needing police officers at the scene.

Average Entry Speed


The estimated speed of vehicles upon entering the curve. HSM Equations 19-59 and 19-60 are used in the method for calculating average entry speed.

The procedure for predicting the average curve entry speed for each curve on a ramp or C-D road is developed for use with the horizontal curve CMF. It is not intended to be used with other applications, or to predict vehicle speed at other points along a ramp or C-D road.


The speed prediction procedure consists of a sequence of steps that lead to a prediction of average entry speed for each horizontal curve on the subject ramp or C-D road. Each curve is addressed by the procedure in the same sequence as they are encountered when traveling along the ramp or C-D road. In this manner, the speed for all previous curves encountered must be calculated first, before the speed on the subject curve can be calculated. The steps used will vary depending on whether the segment is part of an entrance ramp, exit ramp, connector ramp, or C-D road.

The horizontal curves are located along the ramp or C-D road using a linear referencing system. For exit ramps, ramp-mile 0.0 (or ramp-kilometer 0.0 in metric) is located at the gore point. For entrance ramps that intersect the crossroad, ramp-mile 0.0 (or ramp-kilometer 0.0 in metric) is located at the point where the ramp reference line intersects with the near edge of traveled way of the crossroad. The location of ramp-mile 0.0 (or ramp-kilometer 0.0 in metric) is shown in the figure below for simple situations.


Exit Ramp, C-D Road, Entrance Ramp with Speed-Change Lane



It is shown in the figure below for more complex ramp and C-D road combinations.



C-D road 1 has the highest volume so its ramp-mile 0.0 is used for the combined entrance ramp segments.



c. Entrance and Exit Ramps with C-D Road

When a specific entrance ramp or C-D road segment serves traffic from two or more sources combined, ramp-mile 0.0 (or ramp-kilometer 0.0 in metric) for this segment should be that of the one ramp that is the source of the highest daily traffic volume.

The input data needed for this procedure are identified in the table below. The first three variables listed represent required input data. Default values are provided for the remaining variables.

Variable	Description	Default Value	Applicable Site Type All	
X_{i}	Ramp-mile of the point of change from tangent to curve (PC) for curve i (mi) a	None		
R_{i}	Radius of curve i (ft) b	None	All	
$L_{c,i}$	Length of horizontal curve i (mi)	None	All	
V_{frey}	Average traffic speed on the freeway during off-peak periods of the typical day (mi/h)	Estimate as equal to the speed limit	All	
V_{xroad}	Average speed at the point where the ramp connects to the crossroad (mi/h)	15 – ramps with stop-, yield-, or signal-controlled crossroad ramp terminals	Entrance ramp, exit ramp, connector ramp at service interchange	
		30 – all other ramps at service interchanges		
V_{cdroad}	Average speed on C-D road or connector ramp (measured at the mid-point of the C-D road or ramp) (mi/h)	40	C-D road, connector ramp at system interchange	

^a If the curve is preceded by a spiral transition, then X_i is computed as equal to the average of the TS and SC ramp-mile locations, where TS is the point of change from tangent to spiral and SC is the point of change from spiral to curve.

Base Model

A regression model for predicting the expected average crash frequency in each HSM prediction procedure given a set of site characteristics. The base model, like all regression models, predicts the value of a dependent variable as a function of a set of independent variables. The expected average crash frequency is adjusted for changes to set site characteristics with the use of a CMF.

Bicycle Crash Adjustment Factor

For roadway segments, f_{biker} is the bicycle crash adjustment factor. It is used in the determination of the number of vehicle-bicycle collisions per year for a roadway segment. The values of f_{biker} are likely to depend on the climate and the bicycling environment in particular states or communities. The following tables show the bicycle crash adjustment factors for roadway segments, but users are encouraged to replace the values in the table with suitable values for their own state or community through the calibration process.

 $^{^{}b}$ If the curve has spiral transitions, then R_{i} is equal to the radius of the central circular portion of the curve.

Table 54. Bicycle crash adjustment factor for two-way roadway segments.

Source	Road Type	Bicycle Crash Adjustment Factor (fbiker)									
		Post	ted Speed 30	mph or Lov	Posted Speed Greater Than 30 mph						
		Number of Segments	Total Bicycle Crashes	Total MV and SV Crashes ^a	f biker	Number of Segments	Total Bicycle Crashes	Total MV and SV Crashesa	fbiker		
2	2U		N		0.018		9)		0.004		
HSM Ch. 12	3T				0.027				0.007		
ō	4U				0.011				0.002		
SM	4D				0.013				0.005		
H	5T				0.050				0.012		
7	6U	22	7	549	0.013	72	9	1359	0.007		
ose	6D	106	16	2377	0.007	1661	190	24720	0.008		
Proposed	7T	16	8	324	0.025	250	46	10016	0.001		
P	8D	1	0	612		122	92	6623	0.014		

Note: Shaded cell = data not available.

Table 74. Bicycle crash adjustment factor for one-way roadway segments.

		Bicycle Crash Adjustment Factor (fbiker)									
		Poste	ed Speed 30	mph or Low	Posted Speed Greater Than 30 mph						
Source	Road Type	Number of Segments	Total Bicycle Crashes	Total MV and SV Crashes ^a	f_{ped}	Number of Segments	Total Bicycle Crashes	Total MV and SV Crashes ^a	fped		
eq	20	774	29	2767	0.011	276	11	676	0.016		
sodo	30	395	24	2217	0.011	162	11	911	0.012		
Pro	40	81	7	342	0.021	57	3	405	0.007		

^a Excludes pedestrian and bicycle crashes.

For intersections, f_{bikei} is the bicycle crash adjustment factor. It is used in the determination of the number of vehicle-bicycle collisions per year for an intersection. The values of f_{bikei} are likely to depend on the climate and bicycling environment in particular states or communities. The following table shows the bicycle crash adjustment factors for intersections, but users are encouraged to replace the values in the table with suitable values for their own state or community through the calibration process.

^a Excludes pedestrian and bicycle crashes.

Table 12-30. Bicycle Crash Adjustment Factors for Intersections

Intersection Category	Intersection Type	Bicycle Crash Adjustment Factor (fbikel)		
	3ST	0.016		
2 2 11 2 2	3SG	0.011		
2×2 with five or fewer lanes	4ST	0.018		
	4SG	0.015		
	3ST	0.048		
0.0.14	3SG	0.029		
2×2 with six or more lanes	4ST	0.039		
	4SG	0.019		
	3ST	0.018		
1 0 1 1	3SG	0.016		
1×2 or 1×1	4ST	0.022		
	4SG	0.012		

Note: These factors apply to the methodology for predicting total crashes (all severity levels combined). All bicycle collisions resulting from this adjustment factor are treated as FI crashes and none as PDO crashes.

Source: HSIS data from California (2002-2006) for 2×2 intersections with five or fewer lanes; HSIS data from California and Illinois (2006-2010) and state data from Texas (2008-2012) and Michigan (2008-2012) for other intersection categories.

Calibration Factor

A factor to adjust crash frequency estimates produced from a safety prediction procedure to approximate local conditions. The factor is computed by comparing existing crash data at the state, regional, or local level to estimates obtained from predictive models.

California State

A checkbox is provided to indicate if the site under analysis is in California. If checked, the California state indicator variable is 1.0. If not, it is 0.0. This indicator variable is used in the safety performance function calculations and is only applicable to the following models: Urban Intersection Six or More Lanes 4SG and Urban Intersection Six or More Lanes 3SG.

The project database was developed using data from five states: Texas, Illinois, California, Michigan, and Oregon. These states were selected based on the state-owned mileage of the two street categories of interest and the availability of crash data.

Crash and roadway data from California and Illinois were obtained from the Highway Safety Information System (HSIS), while data from Texas, Michigan, and Oregon were obtained directly from the state highway agencies. Data from Texas, Illinois, and California comprised the bulk of the project database. Data from Oregon were later added to increase the mileage of one-way streets, and data from Michigan were added to increase the number of intersections in the sample.

Data for the five states were combined for model calibration and the development of crash modification factors (CMFs). These data were enriched through the inclusion of additional road inventory data extracted from Google Earth and Google Street View. The enhanced database was then combined with the crash data to form the highway safety database needed for model and CMF development and calibration.

Circulating AADT

Average annual daily traffic volume circulating the roundabout; measured in vehicles per day for each approach leg

Circulating Width

Circulating width is the width of the circulatory roadway within the roundabout. It is measured in feet and recorded as the nearest integer foot (or nearest tenth of a meter in metric). Roundabouts in which the number of circulating

lanes varies and/or roundabouts that are not circular (e.g., oblong shaped) may have circulating widths that vary. In these instances, the aligned dimension will need to be used to measure the circulating width in front of the splitter island on each leg.

Clear Zone

The total roadside border area, starting at the edge of the traveled way, available for use by errant vehicles.

Clear Zone Width

This width is measured from the edge of traveled way to typical limits of vertical obstruction (e.g., non-traversable slope, fence line, utility poles) along the roadway. The clear zone width includes the outside shoulder. It is measured for both travel directions. If this width varies along the segment, then use the estimated length-weighted average clear zone width (excluding the portion of the segment with barrier). Do not consider roadside barrier when determining the clear zone width for the predictive method. Barrier location and influence is addressed in other CMFs. If the segment has roadside barrier on both sides for its entire length, then the clear zone width will not influence the model prediction, and any value can be used as model input.

Controlled Right Turn at Exit Ramp

This information is needed only for the exit ramp. It is focused on the right turn movement, which may have a different control type than the left-turn movement. Control types considered include: free flow, merge, yield, stop, and signal (where free-flow and merge operation are recognized to represent "no control").

Crash

A set of events not under human control that results in injury or property damage due to the collision of at least one motorized vehicle and may involve collision with another motorized vehicle, a bicyclist, a pedestrian, or an object.

Crash Distribution

Proportions to determine the distribution of crashes by collision type. Proportions can be edited, but defaults are based off the following tables found in the Highway Safety Manual (HSM) and NCHRP reports:

- **HSM Table 10-4.** Default Distribution by Collision Type for Specific Crash Severity Levels on Rural Two-Lane, Two-Way Roadway Segments
- HSM Table 10-6. Default Distribution for Collision Type and Manner of Collision at Rural Two-Way Intersections
- **HSM Table 11-4.** Default Distribution of Crashes by Collision Type and Crash Severity Level for Undivided Roadway Segments
- **HSM Table 11-6.** Default Distribution of Crashes by Collision Type and Crash Severity Level for Divided Roadway Segments
- HSM Table 11-9. Default Distribution of Intersection Crashes by Collision Type and Crash Severity
- HSM Table 12.4. Distribution of Multiple-Vehicle Nondriveway Collisions for Roadway Segments by Manner of Collision Type
- HSM Table 12-6. Distribution of Single-Vehicle Crashes for Roadway Segments by Collision Type
- HSM Table 12-11. Distribution of Multiple-Vehicle Collisions for Intersections by Collision Type
- HSM Table 12-13. Distribution of Single-Vehicle Crashes for Intersection by Collision Type
- NCHRP 17-58 Table 51. Distribution of multiple-vehicle collisions for roadway segments by manner of collision type

- NCHRP 17-58 Table 52. Distribution of single-vehicle crashes for roadway segments by collision type for arterials with six or more lanes
- NCHRP 17-58 Table 61. Distribution of total vehicle collisions for intersections with six or more lanes by collision type
- NCHRP 17-58 Table 71. Distribution of multiple-vehicle collisions for roadway segments by manner of collision type
- NCHRP 17-58 Table 72. Distribution of single-vehicle crashes for roadway segments by collision type for arterials with six or more lanes
- NCHRP 17-58 Table 79. Distribution of total vehicle collisions for 1×2 or 1×1 intersections by collision
- NCHRP 17-68 Table 10. Distributions for crash severity level at rural all-way stop-controlled intersections
- NCHRP 17-68 Table 11. Distributions for collision type and manner of collision and crash severity at rural all-way stop-controlled intersections
- NCHRP 17-68 Table 13. Distributions for collision type and manner of collision and crash severity at urban and suburban all-way stop-controlled intersections
- NCHRP 17-68 Table 26. Distributions for crash severity level at three-leg intersections with signal control on rural two-lane highways
- NCHRP 17-68 Table 27. Distributions for collision type and manner of collision and crash severity at threeleg intersections with signal control on rural two-lane highways
- NCHRP 17-68 Table 28. Distributions of intersection crashes by collision type and crash severity at threeleg intersections with signal control on rural multilane highways
- NCHRP 17-68 Table 47. Distribution of MV crashes for Intersection on high-speed urban and suburban arterials
- NCHRP 17-68 Table 48. Distribution of SV crashes for Intersections on high-speed urban and suburban arterials
- NCHRP 17-68 Table 98. Distributions for collision type and manner of collision at crossroad ramp terminals at single-point diamond interchanges
- NCHRP 17-68 Table 105. Distributions for collision type and manner of collision at tight diamond interchange crossroad ramp terminals

Crash Frequency

Number of crashes occurring at a particular site, facility, or network in a one-year period, and is measured in number of crashes per year.

Crash Modification Factor (CMF)

An index of how much crash experience is expected to change following a modification in design or traffic control. CMF is the ratio between the number of crashes per unit of time expected after a modification or measure is implemented and the number of crashes per unit of time estimated if the change does not take place.

Crash Prediction Algorithm

Procedure used to predict average crash frequency, consisting of three elements. It has two analytical components: baseline models and crash modification factors, as well as a third component: crash histories.

Crash Rate

The number of crashes per unit of exposure. For an intersection, this is typically the number of crashes divided by the total entering AADT; for road segments, this is typically the number of crashes per million vehicle-miles traveled on the segment.

Crash Rate Method

A method that normalizes the frequency of crashes against exposure (i.e., traffic volume for the study period for intersections, and traffic volume for the study period and segment length for roadway segments).

Crash Reduction Factor (CRF)

The percentage of crash reduction that might be expected after implementing a modification in design or traffic control. The CRF is equivalent to (1 – CMF).

Crash Severity

The level of injury or property damage due to a crash, commonly divided into categories based on the KABCO scale.

Cross Section Lanes

The total number of through lanes in the segment. Rural Ramp Segments are limited to one lane. Urban ramp segments are limited to two lanes. A segment with a lane-add or -drop taper is considered to have the same number of through lanes as the roadway just downstream of the taper. If the segment ends at a ramp terminal, then the number of through lanes is not based on the lane assignment, or lane markings, at the terminal.

Crossroad Median Width

This width is measured along a line perpendicular to the centerline of the crossroad in the vicinity of the intersection. If no median exists, then a width of 0.0 ft (or 0.0 m in metric) is used in the predictive model. If a raised curb is present, then the width is measured from face-of-curb to face-of-curb. If a raised curb is not present, then the width is measured between the near edge of the traveled way for the two opposing travel directions. If a left turn bay is present, then the median width includes the width of the left turn bay. It is measured from the lane line delineating the bay to the face of curb adjacent to (or the near edge of the traveled way for) the opposing travel direction. If the median width is different on the two crossroad legs, then use an average of the two widths.

Curb Length with On-Street Parking

This is the sum of curb length, in miles (or kilometers in metric), with on-street parking for both sides of the road combined. This can be determined from field measurements or video log review to verify parking regulations. Estimates can be made by deducting from twice the roadway segment length allowances for intersections widths, crosswalks, and driveway widths.

For one-way urban and suburban arterials, curb length with on-street parking is measured for the left side of the road and the right side of the road separately.

Daily Pedestrian Volume

This is the sum of daily pedestrian volumes, in pedestrians/day, crossing all intersection legs.

Date

This field is provided to document the date when the analysis is performed.

Delete Horizontal Curve

For Freeway Segment, Ramp Segment, and Freeway Intersection analyses, a button for deleting a horizontal curve is available when 'Include Horizontal Curves' is checked. Clicking on the button 'Delete Horizontal Curve' will delete the row of inputs corresponding to the currently selected horizontal curve(s).

Delete Section

For facility analyses, a button for deleting a section is available. Clicking on the button 'Delete Section' will delete the row of inputs corresponding to the currently selected section(s).

Delete User-Defined CMF

A button is provided to delete any user-defined CMFs. In the user-defined CMF table, the user must first select the desired CMF(s) to be deleted. After selecting the desired row(s), the user can click 'Delete User-Defined CMF' and then the selected row(s) will be removed and they will no longer apply to the analysis.

Distance from Inside Shoulder to Barrier

Measured from the edge of the inside shoulder to the barrier face. A barrier is associated with the freeway if the offset from the near edge of traveled way is 30 feet of less. Barrier adjacent to a ramp, but also within 30 feet of the freeway traveled way should also be associated with the freeway.

Distance from Outside Shoulder to Barrier


Measured from the edge of the outside shoulder to the barrier face. A barrier is associated with the freeway if the offset from the near edge of traveled way is 30 feet (or 9.1 meters in metric) or less. Barrier adjacent to a ramp, but also within 30 feet (or 9.1 meters in metric) of the freeway traveled way should also be associated with the freeway.

Distance from Segment to Downstream Ramp

This is the distance from the segment endpoint to the next downstream exit ramp. If there is an exit ramp within the segment, this value is equal to 0.

This value is computed separately for the increasing and decreasing milepost directions.

Downstream *entrance* ramps are not of direct interest, and data are not needed for them if they exist in the vicinity of the segment.




Distance from Segment to Upstream Ramp

This is the distance from the segment endpoint to the next upstream entrance ramp. If there is an entrance ramp within the segment, this value is equal to 0.

This value is computed separately for the increasing and decreasing milepost directions.

Upstream exit ramps are not of direct interest, and data are not needed for them if they exist in the vicinity of the segment.



Distance to Adjacent Intersection

Distance to the next public street intersection on the outside crossroad leg. This data element represents the distance between the subject ramp terminal and the nearest public street intersection located in a direction away from the freeway (measured along the crossroad from the subject terminal center to the intersection center).

Distance to Adjacent Ramp

This data element represents the distance between the subject ramp terminal and the adjacent ramp terminal (measured along the crossroad from terminal center to terminal center). If there is no adjacent ramp terminal, then use the distance to the next public street intersection (located in the direction opposite to the intersection described by the distance to adjacent intersection data field).

Driveway Density

The number of driveways per mile (or per kilometers in metric) on both sides of the roadway combined.

Driveway Type

Seven specific driveway types have been considered in modeling. These are:

- Major commercial driveways
- Minor commercial driveways
- Major industrial/institutional driveways
- Minor industrial/institutional driveways
- Major residential driveways
- Minor residential driveways
- Other driveways

Major driveways are those that serve sites with 50 or more parking spaces. Minor driveways are those that serve sites with less than 50 parking spaces. It is not intended that an exact count of the number of parking spaces be made for each site. Driveways can be readily classified as major or minor from a quick review of aerial photographs that show parking areas or though user judgment based on the character of the establishment served by the driveway. Commercial driveways provide access to establishments that serve retail customers. Residential driveways serve single- and multiple-family dwellings. Industrial/institutional driveways serve factories, warehouses, schools, hospitals, churches, offices, public facilities, and other places of employment. Commercial sites with no restriction on access along an entire property frontage are generally counted as two driveways.

The table below shows SPF coefficients for multiple-vehicle driveway related collisions:

		Coefficient	s for Specific Roa	dway Types	
Driveway Type (j)	2U	3T	4U	4D	5T
Number of Driveway-Related Collisions per Drivew	ay per Year (N _j)				
Major commercial	0.158	0.102	0.182	0.033	0.165
Minor commercial	0.050	0.032	0.058	0.011	0.053
Major industrial/institutional	0.172	0.110	0.198	0.036	0.181
Minor industrial/institutional	0.023	0.015	0.026	0.005	0.024
Major residential	0.083	0.053	0.096	0.018	0.087
Minor residential	0.016	0.010	0.018	0.003	0.016
Other	0.025	0.016	0.029	0.005	0.027
Regression Coefficient for AADT (t)					
All driveways	1.000	1.000	1.172	1.106	1.172
Overdispersion Parameter (k)					
All driveways	0.81	1.10	0.81	1.39	0.10
Proportion of Fatal-and-Injury Crashes (f_{dwy})					
All driveways	0.323	0.243	0.342	0.284	0.269
Proportion of Property-Damage-Only Crashes					
All driveways	0.677	0.757	0.658	0.716	0.731

Note: Includes only unsignalized driveways; signalized driveways are analyzed as signalized intersections. Major driveways serve 50 or more parking spaces; minor driveways serve less than 50 parking spaces.

Economic Analysis

Societal Crash Costs:

The Federal Highway Administration (FHWA) has completed research that establishes a basis for quantifying, in monetary terms, the human capital crash costs to society of fatalities and injuries from highway crashes. These estimates include monetary losses associated with medical care, emergency services, property damage, lost productivity, and the like, to society as a whole. They are not to be confused with damages that may be awarded to a particular plaintiff in a personal injury or wrongful death lawsuit. Tort liability damages are based only on the particularized loss to the individual plaintiff and are not allowed to include any societal costs of crashes, which can be used if desired.

State and local jurisdictions often have accepted societal crash costs by crash severity and collision type. When available, these locally-developed societal crash cost data are used with procedures in the HSM.

HSM Default Values:

Fatal/Injury (K/A/B/C): \$158,200

• PDO (O): \$7,400

Because SPFs and CMFs do not always differentiate between fatal and injury crashes when estimating average crash frequencies, many jurisdictions have established a societal cost that is representative of a combined fatal/injury crash.

Empirical Bayes Analysis

Method used to combine observed crash frequency data for a given site with predicted crash frequency data from many similar sites to estimate its expected crash frequency.

Entering AADT

Average annual daily traffic volume entering the intersection; measured in vehicles per day for each approach leg

Entrance/Exit

Entrance ramps: Merge points
Exit ramps: Diverge points

Entrance/Exit Ramp Name

An input is provided to specify the name of the entrance/exit ramp

Entry Width

The entry width should be measured per leg for each roundabout site. The entry width is measured at the entrance line (i.e., the continuation of the inscribed circle diameter) and is the perpendicular width of the lane relative to a vehicle entering the circulatory roadway. The width is measured from the splitter island curb to the curb face at the outside edge of travel way. In the absence of a curb on the outside edge of travel way, the width is measured from the splitter island curb face to the paved edge of travel way. Measurements should be entered in feet and rounded to the nearest foot.

Exit Ramp with Free-Flow Right Turn

A checkbox is provided to indicate whether the exit ramp has free-flow right turns

Exiting AADT

Average annual daily traffic volume exiting the intersection; measured in vehicles per day for each approach leg

Expected Average Crash Frequency

The estimate of long-term expected average crash frequency of a site, facility, or network under a given set of geometric conditions and traffic volumes (AADT) in a given period of years. In the Empirical Bayes (EB) methodology, this frequency is calculated from observed crash frequency at the site and predicted crash frequency at the site based on crash frequency estimates at other similar sites.

Expected Average Crash Frequency, Change in

The difference between the expected average crash frequency in the absence of treatment and with treatment in place.

Expected Crashes

As estimated of long-range average number of crashes per year for a particular type of roadway or intersection.

Facility

A length of highway that may consist of connected sections, segments, and intersections.

Facility Type

The facility types and facility site types in the HSM Part C are defined below.

Chapter 10

—Rural Two-Lane, Two-Way Roads

—includes all rural highways with two-lanes and two-way traffic operation. Chapter 10 also addresses two-lane two-way highways with center two-way left-turn lanes and two-lane highways with added passing or climbing lanes or with short segments of four-lane cross-sections (up to two miles in length) where the added lanes in each direction are provided specifically to

enhance passing opportunities. Short lengths of highway with four-lane cross-sections essentially function as two-lane highways with side-by-side passing lanes, and therefore, are within the scope of the two-lane, two-way highway methodology. Rural highways with longer sections of four-lane cross-sections can be addressed with the rural multilane highway procedures in Chapter 11. Chapter 10 includes three- and four-leg intersection with minor-road stop control and four-leg signalized intersections on all the roadway cross-sections to which the chapter applies.

- Chapter 11-Rural Multilane Highways-includes rural multilane highways without full access control. This
 includes all rural nonfreeways with four through travel lanes, except for two-lane highways with side-byside passing lanes, as described above. Chapter 11 includes three- and four-leg intersections with minorroad stop control and four-leg signalized intersections on all the roadway cross-sections to which the
 chapter applies.
- Chapter 12—Urban and Suburban Arterial Highways—includes arterials without full access control, other
 than freeways, with two or four through lanes in urban and suburban areas. Chapter 12 includes three- and
 four-leg intersections with minor-road stop control or traffic signal control and roundabouts on all of the
 roadway cross-sections to which the chapter applies.
- Chapter 18

 —Freeways—have fully-restricted access control and grade separation with all intersecting
 roadways. Freeways are accessed only through grade-separated interchanges. Roads having at-grade
 access should be analyzed as rural highways or suburban arterials.
- Chapter 19–Ramp/Ramp Terminals–applies to the following site types: entrance ramp segment with one or two lanes, exit ramp segment with one or two lanes, C-D road segment with one or two lanes, and crossroad ramp terminal. Connector ramp segments are represented using one of these site types.

Fixed-Object Density

In estimating the density of fixed objects, only point objects that are 4 inches (or 10.2 centimeters in metric) or more in diameter and do not have breakaway design are considered. Point objects that are within 70 ft (or 21.3 meters in metric) of one another longitudinally along the road are counted as a single object. Continuous objects that are not behind point objects are counted as one point object for each 70 ft (or 21.3 meters in metric) of length.

The Fixed-Object Density is measured in fixed objects per mile (or per kilometer in metric), for both sides of the road combined.

Fixed-Object Offset

The offset distance is an estimate of the average distance from the edge of the traveled way to roadside objects over an extended roadway segment. If the average offset to fixed objects exceeds 30 ft (or 9.1 meters in metric), use the value of offset for 30 ft (or 9.1 meters in metric). Only fixed objects on the roadside on the right side of the roadway in each direction of travel are considered; fixed objects in the roadway median on divided arterials are not considered.


Forward Direction

Setting the forward direction will indicate which approaches are on the major street and which approaches are on the minor street.

Freeway Segment

When using the predictive method, the freeway within the defined project limits is divided into individual sites. A site is either a homogenous freeway segment or a speed-change lane. A facility consists of a contiguous set of individual sites. A roadway network consists of a number of contiguous facilities.

Three freeway segments are shown schematically in the figure below. They are labeled F_r in the figure. The presence of a speed-change lane adjacent to a freeway segment requires a reduction in the effective length of the freeway segment. This reduction is used to account for the crashes assigned to the speed-change lanes. The equation for computing the "effective" segment length is shown in the bottom of the figure for a freeway segment with one ramp entrance and one ramp exit.



Note: Freeway segment length does not include the length of speed-change lanes if these lanes are adjacent to the segment.

Grade

The base condition for grade is a generally level roadway. The CMFs in the table below are applied to each individual grade segment on the roadway being evaluated without respect to the sign of the grade. The sign of the grade is irrelevant because each grade on a rural two-lane, two-way highway is an upgrade for one direction of travel and a downgrade for the other. The grade factors are applied to the entire grade from one point of vertical intersection (PVI) to the next (i.e., there is no special account taken of vertical curves). The CMFs in the following table apply to total roadway segment crashes:

Approximate Grade (%)			
Level Grade (≤ 3%)	Moderate Terrain (3%< grade ≤ 6%)	Steep Terrain (> 6%)	
1.00	1.10	1.16	

Horizontal Curve

The presence or absence of horizontal curve (curve/tangent) is necessary to select a SPF and to determine whether the site-specific conditions vary from the base conditions and, therefore, whether a CMF is applicable. If the segment has one or more curve:

- Length of horizontal curve (miles, or kilometers in metric), (this represents the total length of the horizontal
 curve and includes spiral transition curves, even if the curve extends beyond the limits of the roadway
 segment being analyzed);
- Radius of horizontal curve (feet, or meters in metric);
- Presence or absence of spiral transition curve, even if the beginning and/or end of the horizontal curve are beyond the limits of the segment being analyzed); and
- Superelevation of horizontal curve and the maximum superelevation (e_{max}) used according to policy for the
 jurisdiction, if available.

Horizontal Curve Length

Curve length is measured along the reference line from the point where the tangent ends and the curve begins (i.e., the PC) to the point where the curve ends, and the tangent begins (PT). If the curve PC and PT do not lie on the reference line, then they must be projected onto this line and the curve length measured between these projected points along the reference line.

If the curve has spiral transitions, then measure from the "effective" PC point to the "effective" PT point. The effective PC point is located midway between the TS and SC, where the TS is the point of change from tangent to spiral and the SC is the point of change from spiral to circular curve. The effective PT is located midway between the CS and ST, where CS is the point of change from circular curve to spiral and ST is the point of change from spiral to tangent.

The length of curve in segment is the length of the curve within the boundaries of the segment (or speed-change lane). This length cannot exceed the segment length or the curve length.

Horizontal Curve Radius

Radius is measured separately for each roadbed curve. The line used to define curve radius is the inside edge of the traveled way. This line is established separately on each roadbed. If the curve has spiral transitions, then use the radius of the central circular portion of the curve.

Illinois State

A checkbox is provided to indicate if the site under analysis is in Illinois. If checked, the Illinois state indicator variable is 1.0. If not, it is 0.0. This indicator variable is used in the safety performance function calculations and is only applicable to the following models:

- Urban Segments Six or More Lanes (i.e., 6D, 6U, 7T, 8D)
- Urban Segments One-Way (i.e., 20, 30, 40)
- Urban Intersections Six or More Lanes Signalized (i.e., 4SG, 3SG)
- Urban Intersections One-Way Signalized (i.e., 4SG, 3SG)

The project database was developed using data from five states: Texas, Illinois, California, Michigan, and Oregon. These states were selected based on the state-owned mileage of the two street categories of interest and the availability of crash data.

Crash and roadway data from California and Illinois were obtained from the Highway Safety Information System (HSIS), while data from Texas, Michigan, and Oregon were obtained directly from the state highway agencies. Data from Texas, Illinois, and California comprised the bulk of the project database. Data from Oregon were later added to increase the mileage of one-way streets, and data from Michigan were added to increase the number of intersections in the sample.

Data for the five states were combined for model calibration and the development of crash modification factors (CMFs). These data were enriched through the inclusion of additional road inventory data extracted from Google Earth and Google Street View. The enhanced database was then combined with the crash data to form the highway safety database needed for model and CMF development and calibration.

Include Horizontal Curves

If the segment includes 1 or more horizontal curves, select this box to input additional information about the curves.

For Rural Two-Lane Undivided Segments, segment endpoints should be located at the Point of Curvatures and the Point of Tangency of each curve, limiting each segment to either no curves, or the entire segment is a curve. To calculate values for multiple segments, use the Rural Facility Module.

Inscribed Circle Diameter

The inscribed circle diameter (ICD) is the parameter used to discuss the general size of a roundabout. It is the diameter of the largest circle that can be inscribed within the outer edges of the circulatory roadway. The ICD serves as the width of the roundabout. The measurement is taken in feet and rounded to the nearest integer (or meters and rounded to the nearest tenth of a meter in metric).

Insert Horizontal Curve

For Freeway Segment, Ramp Segment, and Freeway Intersection analyses, a button for inserting a horizontal curve is available when 'Include Horizontal Curves' is checked.

For Freeway Segment and Speed Change Lanes analyses, clicking on the button 'Insert Horizontal Curve' will add a row of inputs before the selected row. The added row includes the following inputs: Primary Radius, Secondary Radius, and Length in Segment. For Ramp Segment and C-D Road Segment analyses, clicking on the button 'Insert Horizontal Curve' will add a row of inputs before the selected row. The added row includes the following inputs: Radius of Curve, Average Entry Speed, and Length in Segment.

The user can insert an unlimited number of horizontal curves.

Insert Section

For facility analyses, a button for inserting a section is available. A row of inputs must be selected before inserting a section. Clicking on the button 'Insert Section' will add a row of inputs before the selected row. The added row includes the following inputs: Section Type, Facility Type, Model Type, Details, N(spf), and N(predicted). Section Type can either be Segment or Intersection. Facility Type can either be Rural Two-Lane or Rural Multilane in a Rural Facility analysis. Facility Type can only be Urban in an Urban Facility analysis. Section Type and Facility Type cannot be changed within the rows. They must be specified before the new section is added. Model Type can be changed within the rows and the choices available are dependent on Section Type and Facility Type combinations. Clicking on Details within a row will bring the user to the Details page for that specific section. N(spf) specifies the predicted average crash frequency for base conditions for that individual section. N(predicted) specifies the predicted average crash frequency for that individual section, which is dependent on the inputs specified on the Details page. The user can add an unlimited number of sections.

Inside Shoulder Width

Represents only the paved width, and is an average for both roadbeds. Should be measured where the cross section is constant, and should not be measured where one or more edges are discontinuous or tapered. If a width varies along the segment or speed change lane (but not enough to justify beginning a new segment), then compute the length-weighted average widths. Rules for defining segment boundaries are provided in section 18.5.2.

Interchange

Intersections that consist of structures that provide for the cross-flow of traffic at different levels without interruption, thus reducing delay, particularly when volumes are high.

Interchange Ramp Terminal

A junction with a surface street to serve vehicles entering or exiting a freeway.

Intersection

General area where two or more roadways or highways meet, including the roadway, and roadside facilities for pedestrian and bicycle movements within the area.

Intersection Related Crash

A crash that occurs at the intersection itself or a crash that occurs on an intersection approach within 250 ft (or 76.2 meters in metric) of the intersection and is related to the presence of the intersection.

Is Left Side Ramp

Ramp Entrance or Exit on left side of the roadbed.

Is Major Street One-Way

A checkbox is provided to indicate whether or not the major street is one-way. If checked, the method type used will be One-Way.

Is Minor Street One-Way

A checkbox is provided to indicate whether or not the minor street is one-way. If checked, the one-way on minor street indicator variable is 1.0. If not, it is 0.0. This indicator variable is used in the safety performance function calculations.

Jurisdiction

This field is provided to document any jurisdiction convention or project related information.

KABCO

An injury scale developed by the National Safety Council to measure the observed injury severity for any person involved as determined by law enforcement at the scene of the crash. The acronym is derived from (Fatal Injury (K), Incapacitating Injury (A), Non-Incapacitating Injury (B), Possible Injury (C), and No Injury (O).) The scale can also be applied to crashes, for example, a K crash would be a crash in which the most severe injury was a fatality, and so forth.

Lane Width

The lateral distance, measured in feet (or meters in metric), between stripes for a given lane.

Lanes Added

Lane added to the ramp segment or C-D road, not as a result of a second merging ramp. If a lane is added, then the length of the taper in the segment is needed.

Lanes Dropped

Lane dropped from the ramp segment or C-D road, not as a result of a second diverging ramp. If a lane is dropped, then the length of the taper in the segment is needed.

Lanes, Primary Direction

Number of through lanes in the increasing milepost direction. Rural Freeways are limited to eight lanes. Urban Freeways are limited to ten lanes. A segment with a lane add or drop taper is considered to have the same number of through lanes as the roadway just downstream of the taper.

Lanes, Secondary Direction

Number of through lanes in the decreasing milepost direction. Rural Freeways are limited to eight lanes. Urban Freeways are limited to ten lanes. A segment with a lane add or drop taper is considered to have the same number of through lanes as the roadway just downstream of the taper.

Left-Turn Lane Present on Crossroad Leg

The lane (or bay) can have one or two lanes. A lane (or bay) is considered to be present when it (a) is for the exclusive use of a turn movement, (b) extends 100 ft or more back from the stop line, and (c) ends at the intersection stop line.

The Crossroad Left-Turn Lane CMF is applicable to any crossroad approach that is either signalized or uncontrolled. It is not applicable to a stop-controlled approach. The CMF value is applicable to turn bays that have a design that is consistent with agency policy such that their length adequately provides for vehicle storage or deceleration, as appropriate.

Left-Turn Lane Width

This variable represents the total width of all lanes that exclusively serve turning vehicles on the subject approach. It is measured from the near edge of the traveled way of the adjacent through lane to the near lane marking (or curb face) that delineates the median.

Left-Turn Lanes

The lane (or bay) can have one or two lanes. A lane (or bay) is considered to be present when it (a) is for the exclusive use of a turn movement, (b) extends 100 ft or more back from the stop line, and (c) ends at the intersection stop line.

The base condition for intersection left-turn lanes is the absence of left-turn lanes on the intersection approaches. CMFs apply to installation of left-turn lanes on any approach to a signalized intersection but only on uncontrolled major-road approaches to stop-controlled intersections. The CMFs for installation of left-turn lanes on multiple approaches to an intersection are equal to the corresponding CMF for installation of a left-turn on one approach raised to a power equal to the number of approaches with left-turn lanes. There is no indication of any change in crash frequency for providing a left-turn lane on an approach controlled by a stop sign, so the presence of a left-turn lane on a stop-controlled approach is not considered in applying the table found below:

		1	Number of Approacl	nes with Left-Turn La	nesª
Intersection Type	Intersection Traffic Control	One Approach	Two Approaches	Three Approaches	Four Approaches
Three-leg intersection	Minor-road stop controlb	0.67	0.45	_	-
	Traffic signal	0.93	0.86	0.80	
Four-leg intersection	Minor-road stop controlb	0.73	0.53	-	<u> </u>
	Traffic signal	0.90	0.81	0.73	0.66

Stop-controlled approaches are not considered in determining the number of approaches with left-turn lanes.

The CMFs in the table apply to total intersection crashes (not including vehicle-pedestrian and vehicle-bicycle collisions). A CMF of 1.00 is always used when no left-turn lanes are present.

Left-Turn Phasing

Types of left-turn signal phasing considered include permissive, protected, protected/permissive, and permissive/protected. Protected/permissive operation is also referred to as a leading left-turn signal phase; permissive/protected operation is also referred to as a lagging left-turn signal phase. The base condition for the Intersection Left-Turn Signal Phasing CMF is permissive left-turn signal phasing. This CMF applies to total intersection crashes (not including vehicle-pedestrian and vehicle-bicycle collisions) and is applicable only to signalized intersections. A CMF value of 1.00 is always used for unsignalized intersections.

If several approaches to a signalized intersection have left-turn phasing, the values of CMF_{2i} for each approach are multiplied together.

Length

The distance, in miles (or kilometers in metric), from end to end of the segment.

Lighting

Artificial lighting is often provided on roadway segments in urban and suburban areas. Lighting is also often provided at rural locations where road users may need to make a decision.

Major Street Posted Speed

For Urban Intersections, the Major Street Posted Speed can be indicated. Options include the following: *Under 50 mi/h* (or *Under 80 km/h* in metric) and *50 mi/h and over* (or *80 km/h and over* in metric). If the former option is selected, the Method Type will be *General*, *Six or More Lanes*, or *One-Way* depending on other inputs entered. If the latter option is selected, the Method Type will be *High-Speed*.

Maximum Lanes Crossed by Pedestrian

The values of n_{lanesx} in Equation 12-29 represents the maximum number of traffic lanes that a pedestrian must cross in any crossing maneuver at the intersection. Both through and turning lanes that are crossed by a pedestrian along the crossing path are considered. If the crossing path is broken by an island that provides a suitable refuge for the pedestrian so that the crossing may be accomplished in two (or more) stages, then the number of lanes crossed in each stage is considered separately. To be considered as a suitable refuge, an island must be raised or depressed; a flush or painted island is not treated as a refuge for purposes of determining the values of n_{lanesx} .

Median

The portion of a divided highway separating the traveled ways from traffic in opposite directions.

^b Stop signs present on minor-road approaches only.

Median Barriers

Median barriers are devices used to prevent a vehicle from striking a more severe obstacle or feature located in the median or to prevent crossover median crashes.

Median Width

The width, in feet (or meters in metric), of the median, which is the portion of a divided highway separating the traveled ways from traffic in opposite directions.

Method Type

This indicates the method used for urban intersection calculations. The different method types include: General, Six or More Lanes, One-Way, and High-Speed. The General methodology can be found in Chapter 12 of the Highway Safety Manual. The Six or More Lanes methodology can be found in Chapter 6 of NCHRP 17-58. The One-Way methodology can be found in Chapter 8 of NCHRP 17-58. The High-Speed methodology can be found in Chapter 5 of NCHRP 17-68.

Michigan State

A checkbox is provided to indicate if the site under analysis is in Michigan. If checked, the Michigan state indicator variable is 1.0. If not, it is 0.0. This indicator variable is used in the safety performance function calculations and is only applicable to the following models: Urban Intersection Six or More Lanes 4SG and Urban Intersection Six or More Lanes 3SG.

The project database was developed using data from five states: Texas, Illinois, California, Michigan, and Oregon. These states were selected based on the state-owned mileage of the two street categories of interest and the availability of crash data.

Crash and roadway data from California and Illinois were obtained from the Highway Safety Information System (HSIS), while data from Texas, Michigan, and Oregon were obtained directly from the state highway agencies. Data from Texas, Illinois, and California comprised the bulk of the project database. Data from Oregon were later added to increase the mileage of one-way streets, and data from Michigan were added to increase the number of intersections in the sample.

Data for the five states were combined for model calibration and the development of crash modification factors (CMFs). These data were enriched through the inclusion of additional road inventory data extracted from Google Earth and Google Street View. The enhanced database was then combined with the crash data to form the highway safety database needed for model and CMF development and calibration.

Minor Street

The lower volume street controlled by stop signs at a two-way or four-way stop-controlled intersection; also referred to as a *side street*. The lower volume street at a signalized intersection.

Model Type

This specifies the Site Type for the combination of Facility Type and Section Type being analyzed. See also *Site Type*.

Multilane Highway

A highway with at least two lanes for the exclusive use of traffic in each direction, with no control, partial control, or full control of access, but that may have periodic interruptions to flow at signalized intersections.

Non-Ramp Public Street Leg

This situation occurs occasionally. When it does, the public street leg is opposite from one ramp, and the other ramp either does not exist or is located at some distance from the subject ramp terminal such that it is not part of the terminal. This information is needed only for signalized terminals.

Number of Access Points

An access point is a driveway (not a public roadway) located along one of the legs of the roundabout of interest. The count of access points on a leg represents the number of driveways or unsignalized access points on the leg (either side) within 250 feet (or 76.2 meters in metric) of the yield line.

Number of Alcohol Sales Establishments

The number of alcohol sales establishments within 1,000 ft (or 304.8 meters in metric) of the center of an intersection. The base condition for alcohol sales establishments is the absence of alcohol sales establishments near the intersection. Any alcohol sales establishments wholly or partly within 1,000 ft (or 304.8 meters in metric) of the intersection may be counted.

The CMF for alcohol sales establishments indicates that an intersection with alcohol sales establishments nearby is likely to experience more vehicle-pedestrian collisions than an intersection without alcohol sales establishments even if the traffic and pedestrian volumes at the two intersections are identical. This indicates the likelihood of higher risk behavior on the part of either pedestrians or drivers near alcohol sales establishments. The CMF includes any alcohol sales establishment which may include liquor stores, bars, restaurants, convenience stores, or grocery stores. Alcohol sales establishments are counted if they are on any intersection leg or even on another street, as long as they are within 1,000 ft (or 304.8 meters in metric) of the intersection being evaluated.

Number of Bus Stops

The number of bus stops within 1,000 ft (or 304.8 meters in metric) of the center of the intersection. The base condition for bus stops is the absence of bus stops near the intersection.

Multiple bus stops at the same intersection (i.e., bus stops in different intersection quadrants or located some distance apart along the same intersection leg) are counted separately. Bus stops located at adjacent intersections would also be counted as long as any portion of the bus stop is located within 1,000 ft (or 304.8 meters in metric) of the intersection being evaluated.

Number of Channelized Right-Turn Approaches

This indicates the number of approaches with channelized right-turn lanes. It is used in the calculation of the Right-Turn Channelization CMF for intersections of six-or-more lane arterials.

Number of Circulating Lanes

The number of circulating lanes represents the count of circulating lanes immediately downstream of the entry that forms the end of the segment under study.

Number of Crossroad Lanes

Lanes on the crossroad. This value only include lanes that continue through the intersection. Count the lanes along the crosswalk (or the logical location of the crosswalk if it is not marked).

Number of Driveways

The number of driveways of a specific type, n_j , is the sum of the number of driveways of that type for both sides of the road combined. The number of driveways is determined separately for each side of the road and then added together.

See also Driveway Type.

Number of Entering Lanes

The number of entering lanes represents the count of lanes entering the roundabout for each leg. The number of entering lanes per leg does not include right-turn bypass lanes on the leg.

Number of Exiting Lanes

The number of exiting lanes represents the count of lanes exiting the roundabout for each leg. The number of exit lanes per leg does not include any lanes that may be formed from a bypass lane.

Number of Lanes Serving the Exit Ramp

Lanes can serve any movement. If right turn channelization is provided, then count the lanes at the last point where all exiting movements are joined (i.e., count at the channelization gore point). All lanes counted must be fully developed for at least 100 ft before intersecting the crossroad. If a lane's development length is less than 100 ft, then it is not counted as a lane for this application. The lane (or lanes) associated with the loop exit ramp at a B4 terminal configuration are not included in this count.

Number of Legs

A leg of a roundabout should be counted as such it is a public roadway (i.e., not a private driveway). A leg does not need to accommodate two-way traffic. A leg can, but does not need to, separate opposing traffic with a physical or painted splitter island. Options are provided for 4-leg and 3-leg roundabouts.

Number of Luminaires

A luminaire is a light fixture that appears to have been designed to illuminate the roadway right-of-way along the legs of the roundabout and through a roundabout. Luminaires do not include adjacent lighting that is oriented to illuminate roadside buildings or features like billboards or other advertising signs. The number of luminaires represents the count of luminaires within 250 feet (or 76.2 meters in metric) of the roundabout entry point on each leg.

Number of Railroad Crossings

This indicates the number of railroad-highway crossings within the limits of the roadway segment. It is used in the calculation of the Railroad Crossing Presence CMF for six-or-more lane arterials.

Number of Through Lanes on Major Street

This indicates the number of through lanes on the major street. It is used in the calculation of the Number of Lanes CMF.

If the number of lanes is 5 or less, the method type used will be General. If the number of lanes is 6 or more, the method type used will be Six or More Lanes. If 'ls Major Street One-Way?' is checked, the method type used will be One-Way and the number of through lanes on major street will have no influence on the method type used. If the 'Major Street Posted Speed' selected is '50 mi/h and over' (or '80 km/h and over' in metric), then the method type used will be High-Speed.

Number of Through Lanes on Minor Street

This indicates the number of through lanes on the minor street. It is used in the calculation of the Number of Lanes CMF.

Number of Traffic Lanes that Oppose Left Turn

Number of lanes on the crossroad that conflict with left turn movements

Number of Unsignalized Driveways

This number represents the count of unsignalized driveways on the outside crossroad leg and within 250 feet (or 76.2 meters in metric) of the ramp terminal. The count is taken on both sides on the leg (two travel directions). The count should only include "active" driveways (i.e., those driveways with an average daily volume of 10 veh/day or more).

Number of Unsignalized Public Street Approaches

This number represents the count of unsignalized public street approaches on the outside crossroad leg and within 250 feet (or 76.2 meters in metric) of the ramp terminal. The count is taken on both sides on the leg (two travel directions). If a public street is present at the terminal, then it is not counted for this entry.

See Non-Ramp Public Street Leg.

Number of Years of Observed Crashes

The Empirical Bayes analysis uses prior years of observed crash history to estimate the expected crash frequency. This is the number of years of observed crashes used. The Highway Safety Manual recommends at least 2 years of observed crash history should be used. Each year of observed crash history used should have the same geometric conditions as reported on the details page.

Observed Crashes

Observed crashes for this segment or intersection occurring during the years specified. Crashes should be assigned to the appropriate segment or intersection depending on the appropriate criteria:

- 1. All crashes occurring within the curb-line limits of the intersection are assigned to the intersection
- 2. Other crashes are assigned to the segment or the intersection depending on their characteristics. Crashes classified on the crash report as intersection-related or have characteristics consistent with an intersection related crash are assigned to the intersection to which they are related; such crashes would include rearend collisions related to queues on an intersection approach. Crashes that occur between intersections and are not related to an intersection, such as collisions related to turning maneuvers at driveways, are assigned to the roadway segment on which they occur.

Outbound Leg associated with a Ramp Terminal

A roundabout is considered a ramp terminal intersection if one or more of the legs connected to the roundabout is a ramp leading to a controlled access facility, such as a freeway. This adjustment only applies to one-way outboundlegs (i.e. legs connected to an on-ramp that only serve exiting traffic from a roundabout). Checkboxes are provided to indicate if the subject leg is an outbound leg associated with a ramp terminal.

Outside Shoulder Width

Represents only the paved width, and is an average for both roadbeds. Should be measured where the cross section is constant, and should not be measured where one or more edges are discontinuous or tapered. If a width varies along the segment or speed change lane (but not enough to justify beginning a new segment), then compute the length-weighted average widths. Rules for defining segment boundaries are provided in section 18.5.2.

Parking

There are two broad types of parking facilities: at the curb or on-street parking, and off-street parking in lots or parking structures. Parking safety is influenced by a complex set of driver and pedestrian attitudinal and behavioral patterns.

Certain kinds of crashes may be caused by curb or on-street parking operations, these include:

- Sideswipe and rear-end crashes resulting from lane changes due to the presence of a parking vehicle or contact with a parked car;
- Sideswipe and rear-end crashes resulting from vehicles stopping prior to entering the parking stall;
- Sideswipe and rear-end crashes resulting from vehicles exiting parking stalls and making lane changes;
 and
- Pedestrian crashes resulting from passengers alighting from the street-side doors of parked vehicles, or due to pedestrians obscured by parked vehicles.

Parking Type

There are three types of on-street parking. These include: No Parking, Parallel Parking, and Angle Parking. No Parking is when parking is prohibited on the street. Parallel parking is when the vehicle parks aligned with the road. Angle parking is when the vehicle parks on a specified angle to the curb.

Passing Lane

A lane added to improve passing opportunities in one or both directions of travel on a two-lane highway.

The base condition for passing lanes is the absence of a lane (i.e., the normal two-lane cross section). The CMF for a conventional passing or climbing lane added in one direction of travel on a rural two-lane, two-way highway is 0.75 for total crashed in both directions of travel over the length of the passing lane from the upstream end of the lane addition taper to the downstream end of the lane drop taper. This value assumes that the passing lane is operationally warranted, and that the length of the passing lane is appropriate for the operational conditions on the roadway. There may also be some safety benefit on the roadway downstream of a passing lane, but this effect has not been quantified.

Pedestrian

A person traveling on foot or in a wheelchair

Pedestrian Activity

Pedestrian crossing volumes are categorized into general levels of Pedestrian Activity. There are five levels of pedestrian activity. These include: *High*, *Medium-high*, *Medium*, *Medium-low*, and *Low*. The following table shows estimates of pedestrian crossing volumes based on general level of pedestrian activity.

		ol (pedestrians/day) quation 12-29
General Level of Pedestrian Activity	3SG Intersections	4SG Intersections
High	1,700	3,200
Medium-high	750	1,500
Medium	400	700
Medium-low	120	240
Low	20	50

Pedestrian Crash Adjustment Factor

For roadway segments, f_{pedr} is the pedestrian crash adjustment factor. It is used in the determination of the number of vehicle-pedestrian collisions per year for a roadway segment. The values of f_{pedr} are likely to depend on the climate and the walking environment in particular states or communities. The following tables show the pedestrian crash adjustment factors for roadway segments, but users are encouraged to replace the values in the table with suitable values for their own state or community through the calibration process.

Table 53. Pedestrian crash adjustment factor for two-way roadway segments.

Cannas	Road			Pedestrian (Crash Adj	ustment Fac	tor (fpeds)		
Source	Type	Post	ed Speed 30 r	nph or Low	'er'	Posted	Speed Greate	er Than 30	mph
		Number of Segments	Total Pedestrian Crashes	Total MV and SV Crashesa	f pedr	Number of Segments	Total Pedestrian Crashes	Total MV and SV Crashesa	f pedr
7	2U				0.036				0.005
HSM Ch. 12	3T				0.041				0.013
D D	4U				0.022				0.009
SS	4D				0.067	=			0.019
H	5T				0.030				0.023
Р	6U	22	10	549	0.018	72	18	1359	0.013
ose	6D	106	69	2377	0.029	1661	369	24720	0.015
Proposed	7T	16	11	324	0.034	250	138	10016	0.014
Ы	8D	1	1	612		122	150	6623	0.023

Note: Shaded cell = data not available.

Table 73. Pedestrian crash adjustment factor for one-way roadway segments.

			1	Pedestrian C	rash Adj	ustment Fact	or (fpedr)	****	
	27	Post	ed Speed 30 r	nph or Low	er	Posted	Speed Great	er Than 30 i	nph
Source	Road Type	Number of Segments	Total Pedestrian Crashes	Total MV and SV Crashes ^a	f_{ped}	Number of Segments	Total Pedestrian Crashes	Total MV and SV Crashes ^a	f_{ped}
pa	20	774	48	2767	0.017	276	12	676	0.018
Proposed	30	395	52	2217	0.024	162	15	911	0.017
Pr	40	81	7	342	0.021	57	12	405	0.030

^a Excludes pedestrian and bicycle crashes.

For intersections, f_{pedi} is the pedestrian crash adjustment factor. It is used in the determination of the number of vehicle-pedestrian collisions per year for a stop-controlled intersection. The values of f_{pedi} are likely to depend on the climate and walking environment in particular states or communities. The following table shows the pedestrian crash adjustment factors for stop-controlled intersections, but users are encouraged to replace the values in the table with suitable values for their own state or community through the calibration process.

^a Excludes pedestrian and bicycle crashes.

Table 12-29. Pedestrian Crash Adjustment Factors for Stop-Controlled Intersections

Intersection Category	Intersection Type	Pedestrian Crash Adjustment Factor (fpedi)
0 0	3ST	0.021
2×2 with five or fewer lanes	4ST	0.022
0.0.41.1	3ST	0.051
2×2 with six or more lanes	4ST	0.049
1.01.1	3ST	0.015
1×2 or 1×1	4ST	0.020

Note: These factors apply to the methodology for predicting total crashes (all severity levels combined). All pedestrian collisions resulting from this adjustment factor are treated as FI crashes and none as PDO crashes.

Source: HSIS data from California (2002-2006) for 2×2 intersections with five or fewer lanes; HSIS data from California and Illinois (2006-2010) and state data from Texas (2008-2012) and Michigan (2008-2012) for other intersection categories.

Pedestrian Crosswalk

Pedestrian roadway crossing facility that represents a legal crosswalk at a particular location.

Pedestrian Refuge

An at-grade opening within a median island that allows pedestrians to wait for an acceptable gap in traffic.

pLT/D

 $p_{LT/D}$ is left-turn crashes susceptible to correction by a TWLTL as a proportion of driveway-related crashes. It is used in the calculation of CMF_{9r} (i.e., Two-Way Left-Turn Lanes CMF) for rural two-lane segments. The value of $p_{LT/D}$ is estimated as 0.5, and as such, is hardcoded as 0.5 in HSS.

Posted Speed

This is the speed limit, in mi/h (or km/h in metric), that is posted for the roadway.

Predicted Average Crash Frequency

The estimate of long-term average crash frequency which is forecast to occur at a site using a predictive model found in Part C of the HSM.

Predictive Method

The methodology in Part C of the HSM used to estimate the 'expected average crash frequency' of a site, facility, or roadway under given geometric conditions, traffic volumes, and period of time.

Presence of School

The base condition for schools is the absence of a school near the intersection. The CMF for schools within 1,000 ft (or 304.8 meters in metric) of the center of the intersection is presented in the following table:

Presence of Schools within 1,000 ft of the Intersection	\mathbf{CMF}_{2p}
No school present	1.00
School present	1.35

A school may be counted if any portion of the school grounds is within 1,000 ft (or 304.8 meters in metric) of the intersection. Where one or more schools are located near the intersection, the value of the CMF is independent of the number of schools present. This CMF applies to total vehicle-pedestrian collisions.

This CMF indicates that an intersection with a school nearby is likely to experience more vehicle-pedestrian collisions than an intersection without schools even if the traffic and pedestrian volumes at the two intersections are identical. Such increased crash frequencies indicate that school children are at higher risk than other pedestrians.

Project Description

This field is provided for the user to document the analysis with any information for identification purposes.

Project-Level Parameters

A checkbox is provided on the General page of a facility analysis for the user to indicate if parameters should be applied on a level that is project wide or if separate section-level parameters should be provided on the Details page of each section. Checking the box will indicate the project-level parameters will be applied to all the corresponding sections. Leaving the checkbox unchecked will indicate each section will apply its own parameters.

Proportion of AADT during High Volume Hours

Proportion of freeway AADT volume that occurs during hours where the lane volume exceeds 1,000 vehicles per hour per lane. If local data is not available, a default value can be computed as $1.0 - \exp(1.45 - 0.000124 \times AADT / n)$, where n is the number of lanes in both directions, and AADT is total AADT for both directions.

Proportion of Barrier on Outside Shoulder

Length of barrier present divided by length of segment

Proportion of Crashes that Occur at Night

For segments, this is the proportion of total crashes for unlighted roadway segments that occur at night. It is denoted by p_{nr} . The tables below show the nighttime crash proportions for unlighted roadway segments based on roadway type.

Rural Two-Lane, Two-Way Roads (Chapter 10)

	Proportion of Total Nighttime Cra	shes by Severity Level	Proportion of Crashes that Occur at Night
Roadway Type	Fatal and Injury P _{inr}	PDO p_{pnr}	P_{nr}
2U	0.382	0.618	0.370

Note: Based on HSIS data for Washington (2002-2006)

Rural Multilane Highways (Chapter 11)

Roadway Type	Proportion of Total Night-Time	Crashes by Severity Level	Proportion of Crashes that Occur at Night
	Fatal and Injury p _{inr}	PDO p _{pnr}	P _{nr}
4U	0.361	0.639	0.255
	Proportion of Total Nighttime	Crashes by Severity Level	Proportion of Crashes that Occur at Night
Roadway Type	Fatality and Injury Pinr	PDO p _{pnr}	P _{nr}
4D	0.323	0.677	0.426

Urban and Suburban Arterials (Chapter 12)

	Proportion of Total Nighttime C	rashes by Severity Level	Proportion of Crashes that Occur at Night
Roadway Segment Type	Fatal and Injury P _{int}	PDO P _{pnr}	\mathbf{p}_{nr}
2U	0.424	0.576	0.316
3T	0.429	0.571	0.304
4U	0.517	0.483	0.365
4D	0.364	0.636	0.410
5T	0.432	0.568	0.274

For intersections, this is the proportion of total crashes for unlighted intersections that occur at night. It is denoted by p_{ni} . The tables below show the nighttime crash proportions for unlighted intersections.

Rural Two-Lane, Two-Way Roads (Chapter 10)

	Proportion of Crashes that Occur at Night	
Intersection Type	P_{ni}	
3ST	0.260	
4ST	0.244	
4SG	0.286	

Note: Based on HSIS data for California (2002-2006)

Rural Multilane Highways (Chapter 11)

Intersection Type	Proportion of Crashes that Occur at Night, $p_{\scriptscriptstyle ni}$	
3ST	0.276	
4ST	0.273	

Urban and Suburban Arterials (Chapter 12)

	Proportion of Crashes that Occur at Night	
Intersection Type	\mathbf{p}_{ni}	
3ST	0.238	
4ST	0.229	
3SG and 4SG	0.235	

Proportion of Fatal-and-Injury Crashes for Combined Sites

Since there are no models for fatal-and-injury crashes at three- and four-leg stop-controlled urban intersections (3ST and 4ST) in HSM Table 12-12, HSM Equation 12-25 is replaced with the following equation in these cases:

 $N_{bisv(FI)} = N_{bisv(total)} \times f_{bisv}$

where:

 f_{bisv} = proportion of fatal-and-injury crashes for combined sites.

The default value of f_{bisv} is 0.31 for 3ST and 0.28 for 4ST intersections. It is recommended that these default values be updated based on locally available data.

Proportion of Length Adjacent to Speed Change Lane

If there is a speed change area due to a second merging or diverging ramp, this is the length of that speed change area divided by the length of the segment.


Proportion of Length Adjacent to Taper

This is the length of the taper within the segment divided by the segment length.

Proportion of Length within a Type B Weaving Section

This weaving section has the following characteristics: (a) one of the two weaving movements can be made without making any lane changes, (b) the other weaving movement requires at most one lane change, and (c) the ramp entrance and ramp exit associated with the weaving section are located on the right side of the freeway.

Typical Type B weaving sections are shown in the figure below.



Other weaving section types are addressed directly by the predictive method.

The proportion is the length of the weaving section located in the segment divided by the length of the segment. This value is computed separately for the increasing and decreasing milepost directions.

Proportion of Length within a Weaving Segment

Computed as the ratio of the length of the weaving section in the segment to the length of the segment. If the segment is wholly located in the weaving section, then this variable is equal to 1.0.

Proportion of Median Barrier Length

Length of barrier present divided by the length of segment. A barrier is associated with the freeway if the offset from the near edge of traveled way is 30 feet (or 9.1 meters in metric) or less. Barrier adjacent to a ramp, but also within 30 feet (or 9.1 meters in metric) of the freeway traveled way should also be associated with the freeway.

Proportion of Multiple-Vehicle Crashes Represented by Rear-End Collisions

This is the proportion of crashes that are multiple-vehicle, rear-end collisions and it is denoted by p_{re} . The proportion of multiple-vehicle fatal-and-injury crashes represented by rear-end collisions is denoted by $p_{remv(FI)}$. The proportion of multiple-vehicle property-damage-only crashes represented by rear-end collisions is denoted by $p_{remv(PDO)}$.

These proportions are used in the calculation of the Red Light Cameras CMF, rather than the proportions provided in the crash distributions tables. The defaults between the two are the same, but they can all be edited.

Proportion of Multiple-Vehicle Crashes Represented by Right-Angle Collisions

This is the proportion of crashes that are multiple-vehicle, right-angle collisions and it is denoted by p_{ra} . The proportion of multiple-vehicle fatal-and-injury crashes represented by right-angle collisions is denoted by $p_{ramv(Fl)}$.

The proportion of multiple-vehicle property-damage-only crashes represented by right-angle collisions is denoted by $p_{ramv(PDO)}$.

These proportions are used in the calculation of the Red Light Cameras CMF, rather than the proportions provided in the crash distributions tables. The defaults between the two are the same, but they can all be edited.

Proportion of Nighttime Crashes that Involve a Fatality

0.323

This is the proportion of total nighttime crashes for unlighted roadway segments that involve a fatality or injury. It is denoted by p_{inr} . The tables below show the nighttime crash proportions for unlighted roadway segments based on roadway type.

Rural Two-Lane, Two-Way Roads (Chapter 10)

Roadway Type	Proportion of Total Nighttime Crashes by Severity Level		Proportion of Crashes that Occur at Night
	Fatal and Injury p_{inr}	PDO p_{pnr}	P_{nr}
2U	0.382	0.618	0.370

Note: Based on HSIS data for Washington (2002-2006)

Rural Multilane Highways (Chapter 11)

Roadway Type	Proportion of Total Night-Time	Proportion of Crashes that Occur at Night	
	Fatal and Injury p _{inr}	PDO p _{pnr}	P _{nr}
4U	0.361	0.639	0.255
	Proportion of Total Nighttime	Crashes by Severity Level	Proportion of Crashes that Occur at Night
Roadway Type	Fatality and Injury n	PDO n	n.

0.677

4D

0.426

Urban and Suburban Arterials (Chapter 12)

	Proportion of Total Nighttime Crashes by Severity Level		Proportion of Crashes that Occur at Nigh	
Roadway Segment Type	Fatal and Injury P _{int}	PDO p _{pnr}	\mathbf{p}_{nr}	
2U	0.424	0.576	0.316	
3T	0.429	0.571	0.304	
4U	0.517	0.483	0.365	
4D	0.364	0.636	0.410	
5T	0.432	0.568	0.274	

Proportion of Nighttime Crashes that Involve Property Damage

This is the proportion of total nighttime crashes for unlighted roadway segments that involve property damage only. It is denoted by p_{pnr} . The tables below show the nighttime crash proportions for unlighted roadway segments based on roadway type.

Rural Two-Lane, Two-Way Roads (Chapter 10)

	Proportion of Total Nighttime Crashes by Severity Level		Proportion of Crashes that Occur at Night
Roadway Type	Fatal and Injury p_{inr}	$PDO p_{pnr}$	p_{nr}
2U	0.382	0.618	0.370

Note: Based on HSIS data for Washington (2002-2006)

Rural Multilane Highways (Chapter 11)

Roadway Type	Proportion of Total Night-Time	Crashes by Severity Level	Proportion of Crashes that Occur at Night
	Fatal and Injury p _{inr}	PDO p _{pnr}	P _{nr}
4U	0.361	0.639	0.255

Roadway Type	Proportion of Total Nighttime (Proportion of Crashes that Occur at Night	
	Fatality and Injury Pin	PDO p _{pre}	\mathbf{p}_{nr}
4D	0.323	0.677	0.426

Urban and Suburban Arterials (Chapter 12)

	Proportion of Total Nighttime Crashes by Severity Level		Proportion of Crashes that Occur at Night	
Roadway Segment Type	Fatal and Injury p _{int}	PDO p _{pnr}	\mathbf{p}_{nr}	
2U	0.424	0.576	0.316	
3T	0.429	0.571	0.304	
4U	0.517	0.483	0.365	
4D	0.364	0.636	0.410	
5T	0.432	0.568	0.274	

Proportion of Related Crashes

This is the proportion of total crashes constituted by related crashes. It is denoted by p_{ra} .

Proportion of Rumble Strips on Inside Shoulders

Length of rumble strips divided by the length of the roadway. Rumble strips are devices designed to give strong auditory and tactile feedback to errant vehicles leaving the travel way.

Proportion of Rumble Strips on Outside Shoulders

Length of rumble strips divided by the length of the roadway. Rumble strips are devices designed to give strong auditory and tactile feedback to errant vehicles leaving the travel way.

Protected Left-Turn


This information is needed for each crossroad left-turn movement that exists at the terminal. An affirmative response is indicated if the left-turn operates as protected only. If it operates as permissive or protected-permissive, then the response is negative.

Ramp Length


Length of entrance or exit ramp. Measured from the gore point to the taper point.

Ramp Terminal Type


There are many different configurations of crossroad ramp terminals used at interchanges. Configurations include D3ex, D3en, D4, A4, B4, A2, B2, SP, and TD. They are identified below. Differences among the terminals shown below reflect the number of ramp legs, number of left-turn movements, location of crossroad left-turn storage (i.e., inside or outside of the interchange), and control type (i.e., signalized or stop controlled).




Three-Leg Ramp Terminal with Diagonal Exit Ramp (D3ex)




Three-Leg Ramp Terminal with Diagonal Exit Ramp (D3ex)




Three-Leg Ramp Terminal with Diagonal Exit Ramp (D3ex)




Three-Leg Ramp Terminal with Diagonal Entrance Ramp (D3en)




Three-Leg Ramp Terminal with Diagonal Entrance Ramp (D3en)




Three-Leg Ramp Terminal with Diagonal Entrance Ramp (D3en)




Four-Leg Ramp Terminal with Diagonal Ramps (D4)




Four-Leg Ramp Terminal with Diagonal Ramps (D4)




Four-Leg Ramp Terminal with Diagonal Ramps (D4)




Four-Leg Ramp Terminal at Four-Quadrant Partial Cloverleaf A (A4)




Four-Leg Ramp Terminal at Four-Quadrant Partial Cloverleaf A (A4)




Four-Leg Ramp Terminal at Four-Quadrant Partial Cloverleaf A (A4)




Four-Leg Ramp Terminal at Four-Quadrant Partial Cloverleaf B (B4)




Four-Leg Ramp Terminal at Four-Quadrant Partial Cloverleaf B (B4)




Four-Leg Ramp Terminal at Four-Quadrant Partial Cloverleaf B (B4)




Three-Leg Ramp Terminal at Two-Quadrant Partial Cloverleaf A (A2)




Three-Leg Ramp Terminal at Two-Quadrant Partial Cloverleaf A (A2)




Three-Leg Ramp Terminal at Two-Quadrant Partial Cloverleaf A (A2)




Three-Leg Ramp Terminal at Two-Quadrant Partial Cloverleaf B (B2)




Three-Leg Ramp Terminal at Two-Quadrant Partial Cloverleaf B (B2)



Three-Leg Ramp Terminal at Two-Quadrant Partial Cloverleaf B (B2)



Single-Point Diamond Interchange Ramp Terminal



Tight Diamond Interchange Ramp Terminal

Ramp Type

There are two types of ramps: entrance ramp and exit ramp. An entrance ramp is a ramp from a crossroad to a freeway. An exit ramp is a ramp from a freeway to a crossroad.

Red Light Cameras

These are cameras installed for enforcement of red signal violations at a signalized intersection.

The base condition for red light cameras is their absence. A study indicates a CMF for red light camera installation of 0.74 for right-angle conditions and a CMF of 1.18 for rear-end collisions. In other words, red light cameras would typically be expected to reduce right-angle collisions and increase rear-end collisions. There is no evidence that red light camera installation affects other collision types.

Right Shoulder Width

For one-way arterials, the right shoulder width is measured at successive points along the roadway. An average shoulder width is computed for each point and this average is rounded to the nearest 1.0 ft. A new segment is started if the rounded value for the current point changes from that of the previous point (e.g., from 6 to 7 ft). Right shoulder width is measured in feet (or meters in metric) and is used in the calculation of the Right Shoulder Width CMF.

Right-Turn Bypass Lane

A right-turn bypass lane is a lane, typically for right turns but sometimes for through movements at T-intersections, that is separated from the adjacent entry lane either by a channelized island or pavement markings used to create physical, horizontal separation between the bypass lane and the adjacent roundabout entry lanes. Right-turn bypass lanes should not be included in the count of number of entering lanes on a leg.

Right-Turn Channelization

This channelization creates a turning roadway that serves right-turn vehicles. It is separated from the intersection by a triangular channelizing island (delineated by markings or raised curb). The gore point at the upstream end of the island must be within 200 ft (or 61.0 meters in metric) of the downstream stop line for the right turn channelization to be considered "present". If this distance exceeds 200 ft (or 61.0 meters in metric), then the right-turn movement can be free-flow, stop, or yield controlled.

Right-Turn Lane Present on Crossroad Leg

The lane (or bay) can have one or two lanes. A lane (or bay is considered to be present when it (a) is for the exclusive use of a turn movement, (b) extends 100 ft (or 30.5 meters in metric) or more back from the stop line, and (c) satisfies one of the following rules:

- If the bay or turn lane does not have island channelization at the intersection, then it must end at the intersection stop line.
- If the bay or turn lane has island channelization at the intersection, then the bay or turn lane must have (a) stop, yield, or signal control at its downstream end, and (b) an exit gore point that is within 200 ft (or 61.0 meters in metric) of the intersection.

The Crossroad Right-Turn Lane CMF is applicable to any crossroad approach that is either signalized or uncontrolled. It is not applicable to a stop-controlled approach. The CMF value is applicable to turn bays that have a design that is consistent with agency policy such that their length adequately provides for vehicle storage or deceleration, as appropriate.

Right-Turn Lanes

The lane (or bay) can have one or two lanes. A lane (or bay is considered to be present when it (a) is for the exclusive use of a turn movement, (b) extends 100 ft (or 30.5 meters in metric) or more back from the stop line, and (c) satisfies one of the following rules:

- If the bay or turn lane does not have island channelization at the intersection, then it must end at the intersection stop line.
- If the bay or turn lane has island channelization at the intersection, then the bay or turn lane must have (a) stop, yield, or signal control at its downstream end, and (b) an exit gore point that is within 200 ft (or 61.0 meters in metric) of the intersection.

The base condition for intersection right-turn lanes is the absence of right-turn lanes on the intersection approaches. CMFs apply to installation of right-turn lanes on any approach to a signalized intersection, but only on uncontrolled major road approaches to stop-controlled intersections. The CMFs for installation of right-turn lanes on multiple approaches to an intersection are equal to the corresponding CMF for installation of a right-turn lane on one approach raised to a power equal to the number of approaches with right-turn lanes. There is no indication of any safety effect for providing a right-turn lane on an approach controlled by a stop sign, so the presence of a right-turn lane on a stop-controlled approach is not considered in applying the table found below:

Intersection Type		Number of Approaches with Right-Turn Lanesa				
	Intersection Traffic Control	One Approach	Two Approaches	Three Approaches	Four Approaches	
Three-Leg Intersection	Minor road stop controlb	0.86	0.74	_		
Four-Leg Intersection	Minor road stop controlb	0.86	0.74	_		
	Traffic signal	0.96	0.92	0.88	0.85	

a Stop-controlled approaches are not considered in determining the number of approaches with right-turn lanes.

The CMFs in the table apply to total intersection crashes. A CMF values of 1.00 is always used when no right-turn lanes are present. This CMF applies only to right-turn lanes that are identified by marking or signing. The CMF is not applicable to long tapers, flares, or paved shoulders that may be used informally by right-turn traffic.

Road Type

Road Type refers to the land use. There are two categories of Road Type. These include: *Residential/Other* and *Commercial or Industrial/Institutional*.

Roadside

The area between the outside shoulder edge and the right-of-way limits. The area between roadways of a divided highway may also be considered roadside.

Roadside geometry refers to the physical layout of the roadside, such as curbs, foreslopes, backslopes, and transverse slopes.

Designing a roadside environment to be clear of fixed objects with stable flattened slopes is intended to increase the opportunity for errant vehicles to regain the roadway safely or to come to a stop on the roadside. This type of roadside environment, called a "forgiving roadside," is also designed to reduce the chance of serious consequences if a vehicle leaves the roadway.

Roadside features include signs, signals, luminaire supports, utility poles, trees, driver-aid call boxes, railroad crossing warning devices, fire hydrants, mailboxes, bus shelters, and other similar roadside features.

^b Stop signs present on minor road approaches only.

Roadside Barrier

A longitudinal device used to shield drivers from natural or man-made objects located along either side of a traveled way. It may also be used to protect bystanders, pedestrians, and cyclists from vehicular traffic under special conditions.

Roadside Fixed Objects

These are objects fixed on the side of the roadway.

The base condition is the absence of roadside fixed objects on a roadway segment.

Roadside Hazard Rating

Considers the clear zone in conjunction with the roadside slope, roadside surface roughness, recoverability of the roadside, and other elements beyond the clear zone such as barriers or trees. As the RHR increases from 1 to 7, the crash risk for frequency and/or severity increases.

Roadway

The portion of a highway, including shoulders, for vehicular use.

Roadway Segment

A portion of a road that has a consistent roadway cross-section and is defined by two endpoints.

Rumble Strips

Devices designed to give strong auditory and tactile feedback to errant vehicles leaving the travel way.

Centerline rumble strips are installed on undivided highways along the centerline of the roadway which divides opposing directions of traffic flow. Centerline rumble strips are incorporated in the roadway surface to alert drivers who unintentionally cross, or begin to cross, the roadway centerline. The base condition for centerline rumble strips is the absence of rumble strips.

Rural Areas

Places outside the boundaries of urban growth boundary where the population is less than 5,000 inhabitants.

Safety

The number of crashes, by severity, expected to occur on the entity per unit of time. An entity may be a signalized intersection, a road segment, a driver, a fleet of trucks, etc.

Safety Performance Function (SPF)

An equation used to estimate or predict the expected average crash frequency per year at a location as a function of traffic volume and in some cases roadway or intersection characteristics (e.g., number of lanes, traffic control, or type of median).

Section

The sections of a facility are numbered in a natural order (1, 2, 3, etc.). A drop-down menu is provided to select which section details to show.

Section Name

This field is provided for each section to identify the section or specify the start point and end point of the section under analysis.

Section Type

This specifies whether the section being analyzed is a Segment or an Intersection.

Segment

A portion of a facility on which a crash analysis is performed. A segment is defined by two endpoints. See also *Roadway Segment*.

Shoulder

A portion of the roadway contiguous with the traveled way for accommodation of pedestrians, bicycles, stopped vehicles, emergency use, as well as lateral support of the subbase, base, and surface courses.

Shoulder Type

There exists four shoulder types: paved, gravel, composite, and turf.

Shoulder Width

The width of the shoulder, in feet (or meters in metric).

Sideslope

A sideslope is a roadway cross-section element. It is the slope of the cut or fill expressed as a ratio of vertical distance to horizontal distance. The CMF for the sideslope for undivided roadway segments of rural multilane highways is presented in the following table:

1:2 or Steeper	1:3	1:4	1:5	1:6	1:7 or Flatter
1.18	1.15	1.12	1.09	1.05	1.00

The base conditions are for a sideslope of 1:7 or flatter.

Site

Project location consisting of, but not limited to, intersections, ramps, interchanges, at-grade rail crossings, roadway segments, etc.

Site Type

The following table identifies the site types on rural two-lane, two-way roads for which SPFs have been developed from predicting average crash frequency, severity, and collision type.

Site Type	Site Types with SPFs in Chapter 10	
Roadway Segments	Undivided rural two-lane, two-way roadway segments (2U)	
	Unsignalized three-leg (stop control on minor-road approaches) (3ST)	
Intersections	Unsignalized four-leg (stop control on minor-road approaches) (4ST)	
	Signalized four-leg (4SG)	

These specific site types are defined as follows:

- Undivided roadway segment (2U)—a roadway consisting of two lanes with a continuous cross-section providing two directions of travel in which the lanes are not physically separated by either distance or a barrier. In addition, the definition includes a section with three lanes where the center lane is a two-way left-turn lane (TWLTL) or a section with added lanes in one or both directions of travel to provide increased passing opportunities (e.g., passing lanes, climbing lanes, and short four-lane sections).
- Three-leg intersection with stop control (3ST)—an intersection of a rural two-lane, two-way road and a minor road. A stop sign is provided on the minor road approach to the intersection only.
- Four-leg intersection with stop control (4ST)—an intersection of a rural two-lane, two-way road and two minor roads. A stop sign is provided on both minor road approaches to the intersection.
- Four-leg signalized intersection (4SG)—an intersection of a rural two-lane, two-way road and two other rural two-lane, two-way roads. Signalized control is provided at the intersection by traffic lights.

The following table identifies the site types on rural multilane highways for which predictive models have been developed for estimating expected average crash frequency, severity, and collision type. The four-leg signalized intersection models do not have base conditions and, therefore, can be used only for generalized predictions of crash frequencies.

Site Type	Site Types with SPFs in Chapter 11	
Roadway Segments	Rural four-lane undivided segments (4U)	
	Rural four-lane divided segments (4D)	
Intersections	Unsignalized three-leg (Stop control on minor-road approaches) (3ST)	
	Unsignalized four-leg (Stop control on minor-road approaches) (4ST)	
	Signalized four-leg (4SG) ^a	

These specific site types are defined as follows:

- Undivided four-lane roadway segment (4U)—a roadway consisting of four lanes with a continuous cross-section which provides two directions of travel in which the lanes are not physically separated by either distance or a barrier. When multilane roadways whose opposing lanes are separated by a flush median (i.e., a painted median) are considered undivided facilities, not divided facilities, the predictive models in Chapter 11 do not address rural multilane highways with flush separators.
- Divided four-lane roadway segment (4D)—Divided highways are non-freeway facilities (i.e., facilities without full control of access) that have the lanes in the two directions of travel separated by a raised, depressed, or flush median which is not designed to be traversed by a vehicle; this may include raised or depressed medians with or without a physical median barrier, or flush medians with physical median barriers.
- Three-leg intersection with stop control (3ST)—an intersection of a rural multilane highway (i.e., four lane divided or undivided roadway) and a minor road. A stop sign is provided on the minor-road approach to the intersection only.

- Four-leg intersection with stop control (4ST)—an intersection of a rural multilane highway (i.e., four lane divided or undivided roadway) and two minor roads. A stop sign is provided on both minor-road approaches to the intersection.
- Four-leg signalized intersection (4SG)—an intersection of a rural multilane highway (i.e., four lane divided or undivided roadway) and two other rural roads which may be two lane or four land rural highways. Signalized control is provided at the intersection by traffic lights.

The following table identifies the specific site types on urban and suburban arterial highways that have predictive models. Separate SPFs are used for each individual site to predict multiple-vehicle nondriveway collisions, single-vehicle collisions, driveway-related collisions, vehicle-pedestrian collisions, and vehicle-bicycle collisions for both roadway segments and intersections. These are combined to predict the total average crash frequency at an individual site.

Site Type	Site Types with SPFs in Chapter 12	
Roadway Segments	Two-lane undivided arterials (2U)	
	Three-lane arterials including a center TWLTL (3T)	
	Four-lane undivided arterials (4U)	
	Four-lane divided arterials (including a raised or depressed median) (4D)	
	Five-lane arterials including a center TWLTL (5T)	
	Six-lane undivided arterials (6U)	
	Six-lane divided arterials (including a raised or depressed median) (6D)	
	Seven-lane arterials including a center TWLTL (7T)	
	Eight-lane divided arterials (including a raised or depressed median) (8D)	
	Two-lane one-way arterials (2O)	
	Three-lane one-way arterials (3O)	
	Four-lane one-way arterials (4O)	
Intersections	Unsignalized three-leg intersection (stop control on minor-road approaches) (3ST)	
	Signalized three-leg intersection (3SG)	
	Unsignalized four-leg intersection (stop control on minor-road approaches) (4ST)	
	Signalized four-leg intersection (4SG)	


These specific site types are defined as follows:

- Two-lane undivided arterial (2U)—a roadway consisting of two lanes with a continuous cross-section providing two directions of travel in which the lanes are not physically separated by either distance or barrier.
- Three-lane arterials including a center TWLTL (3T)—a roadway consisting of three lanes with a continuous cross-section providing two directions of travel in which center lane is a two-way left-turn lane (TWLTL).
- Four-lane undivided arterials (4U)—a roadway consisting of four lanes with a continuous cross-section providing two directions of travel in which the lanes are not physically separated by either distance or a barrier.
- Four-lane divided arterials (including a raised or depressed median) (4D)—a roadway consisting of four lanes with a continuous cross-section providing two directions of travel in which the lanes are physically separated by either distance or a barrier.
- Five-lane arterials including a center TWLTL (5T)—a roadway consisting of five lanes with a continuous cross-section providing two directions of travel in which the center lane is a two-way left-turn lane (TWLTL).
- Six-lane undivided arterial (6U)—a roadway consisting of six lanes with a continuous cross-section providing two directions of travel in which the lanes are not physically separated by either distance or a barrier.
- Six-lane divided arterials (including a raised or depressed median) (6D)—a roadway consisting of six lanes with a continuous cross-section providing two directions of travel in which the lanes are physically separated by either distance or a barrier.

- Seven-lane arterials including a center TWLTL (7T)—a roadway consisting of seven lanes with a continuous cross-section providing two directions of travel in which the center lane is a TWLTL.
- Eight-lane divided arterials (including a raised or depressed median) (8D)—a roadway consisting of right lanes with a continuous cross-section providing two directions of travel in which the lanes are physically separated by either distance or a barrier.
- Two-lane one-way arterial (20)—a roadway consisting of two lanes with a continuous cross-section
 providing one direction of travel in which the lanes are not physically separated by either distance or a
 barrier.
- Three-lane one-way arterial (3O)—a roadway consisting of three lanes with a continuous cross-section
 providing one direction of travel in which the lanes are not physically separated by either distance or a
 barrier.
- Four-lane one-way arterial (40)—a roadway consisting of four lanes with a continuous cross-section providing one direction of travel in which the lanes are not physically separated by either distance or a barrier.
- Three-leg intersection with stop control (3ST)—an intersection of an urban or suburban arterial and a minor road. A stop sign is provided on the minor road approach to the intersection only.
- Three-leg signalized intersection (3SG)—an intersection of an urban or suburban arterial and one minor road. Signalized control is provided at the intersection by traffic signals.
- Four-leg intersection with stop control (4ST)—an intersection of an urban or suburban arterial and two minor roads. A stop sign is provided on both the minor road approaches to the intersection.
- Four-leg signalized intersection (4SG)—an intersection of an urban or suburban arterial and two minor roads. Signalized control is provided at the intersection by traffic signals.

Skew Angle, Exit Ramp

Skew angle equals 90 minus the intersection angle, in degrees. The intersection angle is the acute angle between the crossroad centerline and a line along the center of an imaginary vehicle stopped at the end of the ramp (i.e., where it joins the crossroad). The vehicle is centered in the traveled way and behind the stop line. If vehicles can exit the ramp as left- or right-turn movements, then use a left-turning vehicle as the vehicle of reference. This information is needed only for terminals with one-way stop control. At a B4 terminal configuration, the skew angle represents that for the diagonal exit ramp (not the loop exit ramp). The following figure shows the exit ramp skew angle (one-way stop control):



Skew Angle, Intersection

The skew angle for an intersection is defined as the absolute value of the deviation from an intersection angle of 90 degrees. The absolute value is used in the definition of skew angle because positive and negative skew angles are considered to have similar detrimental effect. The base condition of intersection skew angle is zero degrees of skew (i.e., an intersection angle of 90 degrees).


If the skew angle differs for the two minor road legs at a four-leg stop-controlled intersection, values of CMF $_{1i}$ is computed separately for each minor road leg and then averaged.

Since the traffic signal separates most movements from conflicting approaches, the risk of collisions related to skew angle between the intersecting approaches is limited at a signalized intersection. Therefore, the CMF for skew angle at four-leg signalized intersections is 1.00 for all cases.


Speed-Change Lane

When using the predictive method, the freeway within the defined project limits is divided into individual sites. A site is either a homogenous freeway segment or a speed-change lane. A facility consists of a contiguous set of individual sites. A roadway network consists of a number of contiguous facilities.

A speed-change land site is defined as the section of the roadway area located (a) between the marked gore and taper points of a ramp merge or diverge area, and (b) on the same side of the freeway as the merge or diverge area. The location of the gore and taper points is defined in the figure below.



Two speed-change lanes are shown schematically in the figure below. The speed-change lane associated with an entrance ramp is labeled SC_{en} and that associated with an exit ramp is labeled SC_{ex} .



Note: Freeway segment length does not include the length of speed-change lanes if these lanes are adjacent to the segment.

Spiral Transition

A spiral transition provides a gradual transition from moving in a straight line to moving in a curve around a point, and vice versa. Spiral transitions are considered part of the horizontal curve they adjoin.

When a horizontal curve is present, it is necessary to specify the presence or absence of a spiral transition curve at the beginning and end of the horizontal curve, even if the beginning and/or end of the horizontal curve are beyond the limits of the segment being analyzed.

Superelevation

The banking of a roadway in a curve to counteract lateral acceleration.

Superelevation Variance

This represents the superelevation rate contained in the AASHTO Green Book minus the actual superelevation of the curve. This is denoted by *SV* and is measured in ft/ft (or m/m in metric).

Taper Area

An area characterized by a reduction or increase in pavement width, typically located between mainline and ramp or areas with lane reductions.

Traffic Barrier

A device used to prevent a vehicle from striking a more severe obstacle or feature located on the roadside or in the median or to prevent crossover median crashes. There are four classes of traffic barriers, namely, roadside barriers, median barriers, bridge railings, and crash cushions.

Traveled Way

Lanes, excluding the shoulders.

Turn Bay

The lane (or bay) can have one or two lanes. A lane (or bay) is considered to be present when it (a) is for the exclusive use of a turn movement, (b) extends 100 ft (or 30.5 m in metric) or more back from the stop line, and (c) ends at the intersection stop line.

Two-Way Left-Turn Lanes

The installation of a center two-way left-turn lane (TWLTL) on a rural two-lane, two-way highway to create a three-lane cross-section can reduce crashes related to turning maneuvers at driveways. The base condition for two-way left-turn lanes is the absence of a TWLTL.

The CMF for TWLTL installation is not applied unless the driveway density is greater than or equal to five driveways per mile. If the driveway density is less than five driveways per mile, the CMF for TWLTL installation is 1.00

Urban Environment

An area typified by high densities of development or concentrations of population, drawing people from several areas within a region.

User-Defined CMF Description

In the User-Defined CMFs table, the user can specify a longer detailed description of a CMF for any added user-defined CMFs.

User-Defined CMF Name

In the User-Defined CMFs table, the user can specify a short name for a CMF for any added user-defined CMFs.

User-Defined CMF Type

In the User-Defined CMFs table, the user can specify the type of CMF for any added user-defined CMFs. The different CMF types include the following: Total, FI, PDO. Depending on the type selected, the user-defined CMF will get applied with the calculated CMFs in the methodology for the facility/model type combination established.

User-Defined CMF Value


In the User-Defined CMFs table, the user can specify the value of the CMF for any added user-defined CMFs. This value will then get applied in the analysis based on the CMF type established for it.

Volume

The number of persons or vehicles passing a point on a lane, roadway, or other traffic-way during some time interval, often one hour, expressed in vehicles, bicycles, or persons per hour.

Weaving Section Length

This is the total length of the Type B weaving section length. This length is measured along the edge of the freeway traveled way from the gore point of the ramp entrance to the gore point of the next ramp exit, as shown in the figure below.



The gore point is located where the pair of solid white pavement edge markings that separate the ramp from the freeway main lanes are 2.0 ft (or 0.61 m in metric) apart. If the markings do not extend to a point where they are 2.0 ft (or 0.61 m in metric) apart, then the gore point is found by extrapolating both markings until the extrapolated portion is 2.0 ft (or 0.61 m in metric) apart. If the measured gore-to-gore distance exceeds 0.85 miles, or 1.368 kilometers in metric (4,500 ft, or 1371.6 m in metric), then a weaving section is not considered to exist. Rather, the entrance ramp is a "lane add" and the exit ramp is a "lane drop".

This value is computed separately for the increasing and decreasing milepost directions.

Index

Acknowledgements 6

Α

AADT 61 Add Horizontal Curve 62 Add Section 63 Add User-Defined CMF 63 Agency 63 Analysis Type 63 Analysis Year 63 Analyst 63 Angle 63 Any Ramps within 0.5 mi 63 Apply User-Defined CMFs 50 Approach 63 Approaches for which Right-Turn-On-Red is Prohibited 64 Approaches for which U-Turn is Prohibited 64 Approaches with Turn Lanes 64 Area Type 64 Automated Speed Enforcement 64 Average Entry Speed 64

В

Base Model 66 Bicycle Crash Adjustment Factor 66

C

Calibration Factor 68
California State 68
Change Parameters 35
Circulating AADT 68
Circulating Width 68
Clear Zone 69
Clear Zone Width 69
Controlled Right Turn at Exit Ramp 69
Close a File 32
Crash 69

Crash Distribution 69
Crash Frequency 70
Crash Modification Factor (CMF) 70
Crash Prediction Algorithm 70
Crash Rate 71
Crash Rate Method 71
Crash Reduction Factor (CRF) 71
Crash Severity 71
Create a New File 24
Cross Section Lanes 71
Crossroad Median Width 71

Curb Length with On-Street Parking 71

D

Daily Pedestrian Volume 71
Date 71
Delete Horizontal Curve 72
Default Settings 9
Delete Section 72
Delete User-Defined CMF 72
Distance from Inside Shoulder to Barrier 72
Distance from Outside Shoulder to Barrier 72
Distance from Segment to Downstream Ramp 72
Distance from Segment to Upstream Ramp 72
Distance to Adjacent Intersection 73
Distance to Adjacent Ramp 73
Driveway Density 73
Driveway Type 73

Ε

Economic Analysis 74

Edit the Default Settings 34
Empirical Bayes Analysis 74
Entering AADT 74
Entrance/Exit 75
Entrance/Exit Ramp Name 75
Entry Width 75
Exit Ramp with Free-Flow Right Turn 75
Exit the Program 32
Exiting AADT 75
Expected Average Crash Frequency 75
Expected Average Crash Frequency, Change in 75
Expected Crashes 75
Export Template 9
Export to CSV 9,42

F

Facility 75
Facility Type 75
Fixed-Object Density 76

Fixed-Object Offset 76
Forward Direction 76
Freeway and Ramp Facility Analysis 21
Freeway Segment 76

G

General Controls 8 Getting Started 7 Glossary of Terms 61 Grade 77

Н

Help 7 Highway Safety 10 Highway Safety Manual 10 Horizontal Curve 78 Horizontal Curve Length 78 Horizontal Curve Radius 78 How To 24

I

Illinois State 78 Import Template 9 Include Horizontal Curves 79 Initial Steps 11 Inscribed Circle Diameter 79 Insert Horizontal Curve 79 Insert Section 79 Inside Shoulder Width 79 Interchange 80 Interchange Ramp Terminal 80 Intersection 80 Intersection Analysis 14 Intersection Related Crash 80 Introduction 1 Is Left Side Ramp 80 Is Major Street One-Way 80 Is Minor Street One-Way 80

J

Jurisdiction 80

Κ

KABCO 80

L

Lane Width 81
Lanes Added 81
Lanes Dropped 81
Lanes, Primary Direction 81
Lanes, Secondary Direction 81
Left-Turn Lane Present on Crossroad Leg 81
Left-Turn Lane Width 81
Left-Turn Lanes 81
Left-Turn Phasing 82
Length 82
License Agreement 1
Lighting 82

M

Major Street Posted Speed 82
Maximum Lanes Crossed by Pedestrian 82
Median 82
Median Barriers 83
Median Width 83
Menu Items 8
Method Type 17,83
Michigan State 83
Minor Street 83
Model Type 83
Multilane Highway 83

Ν

New 8 Non-Ramp Public Street Leg 84 Number of Access Points 84 Number of Alcohol Sales Establishments 84 Number of Bus Stops 84 Number of Channelized Right-Turn Approaches 84 Number of Circulating Lanes 84 Number of Crossroad Lanes 84 Number of Driveways 85 Number of Entering Lanes 85 Number of Exiting Lanes 85 Number of Lanes Serving the Exit Ramp 85 Number of Leas 85 Number of Luminaires 85 Number of Railroad Crossings 85 Number of Through Lanes on Major Street 85 Number of Through Lanes on Minor Street 86 Number of Traffic Lanes that Oppose Left Turn 86 Number of Unsignalized Driveways 86 Number of Unsignalized Public Street Approaches 86 Number of Years of Observed Crashes 86

0 95 Protected Left-Turn 95 **Observed Crashes 86** Open 8 Open an Existing File 26 R Outbound Leg associated with a Ramp Terminal 86 Outside Shoulder Width 87 Ramp Length 95 Ramp Terminal Type 95 Ramp Type 107 Ρ Red Light Cameras 107 Parameter Template 9 Parameters 12,14 Report 23 Parking 87 Parking Type 87 Passing Lane 87 Right-Turn Lanes 108 Pedestrian 87 Pedestrian Activity 87

Pedestrian Crash Adjustment Factor 88 Pedestrian Crosswalk 89

Pedestrian Refuge 89

pLT/D 89 Posted Speed 89

Predicted Average Crash Frequency 89

Predictive Method 89 Presence of School 89 **Project Description 90** Project-Level Parameters 90

Print 8

Print a Report 58 **Print Preview 8**

Proportion of AADT during High Volume Hours 90 Proportion of Barrier on Outside Shoulder 90 Proportion of Crashes the Occur at Night 90

Proportion of Fatal-and-Injury Crashes for Combined Sites 91

Proportion of Length Adjacent to Speed Change Lane 92

Proportion of Length Adjacent to Taper 92 Proportion of Length within a Type B Weaving Section 92

Proportion of Length within a Weaving Segment 92

Proportion of Median Barrier Length 93

Proportion of Multiple-Vehicle Crashes Represented by Rear-End Collisions 93

Proportion of Multiple-Vehicle Crashes Represented by Right-Angle Crashes 93

Proportion of Nighttime Crashes that Involve a Fatality 93

Proportion of Nighttime Crashes that Involve

Property Damage 94

Proportion of Related Crashes 94

Proportion of Rumble Strips on Inside Shoulders 95 Proportion of Rumble Strips on Outside Shoulders

Right Shoulder Width 107 Right-Turn Bypass Lane 107

Right-Turn Channelization 107

Right-Turn Lane Present on Crossroad Leg 107

Road Type 108 Roadside 108 Roadside Barrier 109

Roadside Fixed Objects 109 Roadside Hazard Rating 109

Roadway 109

Roadway Segment 109 Roundabout Analysis 17 Rumble Strips 109

Run an Economic Analysis 47 Run an Empirical Bayes Analysis 44

Rural Areas 109

Rural Facility Analysis 17

S

Safety 109

Safety Performance Function (SPF) 109

Save 8 Save a File 30 Save As... 8 Section 109

Section Name 110 Section Type 110 Segment 110

Segment Analysis 11

Shoulder 110 Shoulder Type 110 Shoulder Width 110 Sideslope 110 Site 110

Site Type 110

Skew Angle, Exit Ramp 113 Skew Angle, Intersection 114 Speed-Change Lane 114 Spiral Transition 115 Superelevation 115

Superelevation Variance 116

T

Taper Area 116
Trademarks and Copyrights 6
Traffic Barrier 116
Traveled Way 116
Turn Bay 116
Two-Way Left-Turn Lanes 116

U

Urban Environment 116
User-Defined CMF Description 116
User-Defined CMF Name 116
User-Defined CMF Type 116
User-Defined CMF Value 117
Urban Facility Analysis 19

V

View Results of the Analysis 53 View/Edit Template 9 Volume 117

W

Weaving Section Length 117